



TabScan - BAICSenova - V2.61 Diagnostic Coverage

NOTE:

●: This function is supported
○: This function is not supported

▲: This function is the new feature in this version
※: This function may be supported which depends on the actual condition of the vehicle

Area	Vehicle Model	System Name	Information	Read TroubleCode	Clear TroubleCode	Read DataStream	Active Test
BAIC Senova	D20	PCM (ME1788)	●	●	●	●	●
BAIC Senova	D20	MITSUBISHI_ME788	●	●	●	●	●
BAIC Senova	D20	Automatic Transmission System (AT)	●	●	●	●	●
BAIC Senova	D20	Anti-Lock brake system (ABS)	●	●	●	●	●
BAIC Senova	D20	Supplementary Restraint System(SRS)	●	●	●	●	●
BAIC Senova	D20	Instrument cluster system (ICM/IP)	●	●	●	●	●
BAIC Senova	D20	Body control system (BCM)	●	●	●	●	●
BAIC Senova	D50	Engine Management System (EMS)	●	●	●	●	●
BAIC Senova	D50	Automatic Transmission System (AT)	●	●	●	●	●
BAIC Senova	D50	Anti-Lock Brake System (ABS)	●	●	●	●	●
BAIC Senova	D50	ESP CONTI	●	●	●	●	●
BAIC Senova	D50	ESP BWI	●	●	●	●	●
BAIC Senova	D50	Supplementary Restraint System(SRS)	●	●	●	●	●
BAIC Senova	D50	Instrument cluster system (ICM/IP)	●	●	●	●	●
BAIC Senova	D50	TPMS	●	●	●	●	○
BAIC Senova	D50	Automatic air conditioning system (AC)	●	●	●	●	●
BAIC Senova	D50	Keyless start system (PEPS)	●	●	●	●	●
BAIC Senova	D50	Electronic Steering Column Lock System (ESCL)	●	●	●	●	○
BAIC Senova	D50	Central Information Display (CID)	●	●	●	●	●
BAIC Senova	D50	Body control system (BCM)	●	●	●	●	●
BAIC Senova	D50	Navigation system (GPS)	●	●	●	●	●
BAIC Senova	D50	T module (TMOD)	●	●	●	●	●
BAIC Senova	D60	Engine Management System (EMS)	●	●	●	●	●
BAIC Senova	D60	Automatic Transmission System (AT)	●	●	●	●	●
BAIC Senova	D60	Electronic stability program (ESP)	●	●	●	●	●
BAIC Senova	D60	Supplementary Restraint System(SRS)	●	●	●	●	●
BAIC Senova	D60	Instrument cluster system (ICM/IP)	●	●	●	●	●
BAIC Senova	D60	TPMS	●	●	●	●	○
BAIC Senova	D60	ACC	●	●	●	●	●
BAIC Senova	D60	EAC	●	●	●	●	●
BAIC Senova	D60	Keyless start system (PEPS)	●	●	●	●	●
BAIC Senova	D60	Body control system (BCM)	●	●	●	●	●
BAIC Senova	D60	Electronic Steering Column Lock System (ESCL)	●	●	●	●	○
BAIC Senova	D60	AHL	●	●	●	●	●
BAIC Senova	D60	Parking assist system (PAS)	●	●	●	●	○
BAIC Senova	D60	Driver Seat Module (DSM)	●	●	●	●	●

Area	Vehicle Model	System Name	Information	Read TroubleCode	Clear TroubleCode	Read DataStream	Active Test
BAIC Senova	D60	Navigation system (GPS)	●	●	●	●	●
BAIC Senova	D60	T module (TMOD)	●	●	●	●	●
BAIC Senova	D70	Engine Management System (EMS)	●	●	●	●	●
BAIC Senova	D70	Automatic Transmission System (AT)	●	●	●	●	●
BAIC Senova	D70	Electronic stability program (ESP)	●	●	●	●	●
BAIC Senova	D70	Supplementary Restraint System(SRS)	●	●	●	●	●
BAIC Senova	D70	Instrument cluster system (ICM/IP)	●	●	●	●	●
BAIC Senova	D70	TPMS	●	●	●	●	○
BAIC Senova	D70	Automatic air conditioning system (AC)	●	●	●	●	●
BAIC Senova	D70	Keyless start system (PEPS)	●	●	●	●	●
BAIC Senova	D70	BCM(LEAR)	●	●	●	●	●
BAIC Senova	D70	BCM(UAES)	●	●	●	●	●
BAIC Senova	D70	Electronic Steering Column Lock System (ESCL)	●	●	●	●	○
BAIC Senova	D70	AHL	●	●	●	●	●
BAIC Senova	D70	Parking assist system (PAS)	●	●	●	●	○
BAIC Senova	D70	Driver Seat Module (DSM)	●	●	●	●	●
BAIC Senova	D70	Reverse video control system(RVC)	●	●	●	●	○
BAIC Senova	D70	Navigation system (GPS)	●	●	●	●	●
BAIC Senova	D70	T module (TMOD)	●	●	●	●	●
BAIC Senova	X25	Engine Management System (EMS)	●	●	●	●	●
BAIC Senova	X25	Automatic Transmission System (AT)	●	●	●	●	●
BAIC Senova	X25	Anti-Lock brake system (ABS)	●	●	●	●	●
BAIC Senova	X25	Supplementary Restraint System(SRS)	●	●	●	●	●
BAIC Senova	X25	Instrument cluster system (ICM/IP)	●	●	●	●	●
BAIC Senova	X25	Automatic air conditioning system (AC)	●	●	●	●	●
BAIC Senova	X25	Electronic Power Steering System (EPS)	●	●	●	●	○
BAIC Senova	X25	Body control system (BCM)	●	●	●	●	●
BAIC Senova	X25	Navigation system (GPS)	●	●	●	●	●
BAIC Senova	X35	Engine Management System (EMS)	●	●	●	●	●
BAIC Senova	X35	Automatic Transmission System (AT)	●	●	●	●	●
BAIC Senova	X35	Anti-Lock Brake System (ABS)	●	●	●	●	●
BAIC Senova	X35	ESP	●	●	●	●	●
BAIC Senova	X35	Supplementary Restraint System(SRS)	●	●	●	●	●
BAIC Senova	X35	Instrument cluster system (ICM/IP)	●	●	●	●	●
BAIC Senova	X35	Automatic air conditioning system (AC)	●	●	●	●	●
BAIC Senova	X35	Electronic Power Steering System (EPS)	●	●	●	●	○
BAIC Senova	X35	Body control system (BCM)	●	●	●	●	●
BAIC Senova	X35	Navigation system (GPS)	●	●	●	●	●
BAIC Senova	X55	Engine Management System (EMS)	●	●	●	●	●

Area	Vehicle Model	System Name	Information	Read TroubleCode	Clear TroubleCode	Read DataStream	Active Test
BAIC Senova	X55	Automatic Transmission System (AT)	●	●	●	●	●
BAIC Senova	X55	Anti-Lock Brake System (ABS)	●	●	●	●	●
BAIC Senova	X55	ESP	●	●	●	●	○
BAIC Senova	X55	Supplementary Restraint System(SRS)	●	●	●	●	●
BAIC Senova	X55	Instrument cluster system (ICM/IP)	●	●	●	●	●
BAIC Senova	X55	TPMS	●	●	●	●	○
BAIC Senova	X55	Automatic air conditioning system (AC)	●	●	●	●	●
BAIC Senova	X55	Electronic Power Steering System (EPS)	●	●	●	●	○
BAIC Senova	X55	Electronic Steering Column Lock System (ESCL)	●	●	●	●	○
BAIC Senova	X55	Keyless start system (PEPS)	●	●	●	●	●
BAIC Senova	X55	Body control system (BCM)	●	●	●	●	●
BAIC Senova	X55	Navigation system (GPS)	●	●	●	●	●
BAIC Senova	X55	T module (TMOD)	●	●	●	●	○
BAIC Senova	X65	Engine Management System (EMS)	●	●	●	●	●
BAIC Senova	X65	Automatic Transmission System (AT)	●	●	●	●	●
BAIC Senova	X65	Anti-Lock Brake System (ABS)	●	●	●	●	●
BAIC Senova	X65	ESP CONTI	●	●	●	●	●
BAIC Senova	X65	Supplementary Restraint System(SRS)	●	●	●	●	●
BAIC Senova	X65	Instrument cluster system (ICM/IP)	●	●	●	●	●
BAIC Senova	X65	TPMS	●	●	●	●	○
BAIC Senova	X65	Automatic air conditioning system (AC)	●	●	●	●	●
BAIC Senova	X65	Keyless start system (PEPS)	●	●	●	●	●
BAIC Senova	X65	BCMHD	●	●	●	●	●
BAIC Senova	X65	BCM	●	●	●	●	●
BAIC Senova	X65	Electronic Steering Column Lock System (ESCL)	●	●	●	●	○
BAIC Senova	X65	AHL	●	●	●	●	●
BAIC Senova	X65	Driver Seat Module (DSM)	●	●	●	●	●
BAIC Senova	X65	AVM	●	●	●	○	○
BAIC Senova	X65	Navigation system (GPS)	●	●	●	●	●
BAIC Senova	X65	T module (TMOD)	●	●	●	●	○
BAIC Senova	CC	Engine Management System (EMS)	●	●	●	●	●
BAIC Senova	CC	Automatic Transmission System (AT)	●	●	●	●	●
BAIC Senova	CC	Electronic stability program (ESP)	●	●	●	●	●
BAIC Senova	CC	Supplementary Restraint System(SRS)	●	●	●	●	●
BAIC Senova	CC	Instrument cluster system (ICM/IP)	●	●	●	●	●
BAIC Senova	CC	TPMS	●	●	●	●	○
BAIC Senova	CC	ACC	●	●	●	●	●
BAIC Senova	CC	EAC	●	●	●	●	●
BAIC Senova	CC	Keyless start system (PEPS)	●	●	●	●	●

Area	Vehicle Model	System Name	Information	Read TroubleCode	Clear TroubleCode	Read DataStream	Active Test
BAIC Senova	CC	Body control system (BCM)	●	●	●	●	●
BAIC Senova	CC	Electronic Steering Column Lock System (ESCL)	●	●	●	●	○
BAIC Senova	CC	AHL	●	●	●	●	●
BAIC Senova	CC	Parking assist system (PAS)	●	●	●	●	○
BAIC Senova	CC	Driver Seat Module (DSM)	●	●	●	●	●
BAIC Senova	CC	Navigation system (GPS)	●	●	●	●	●
BAIC Senova	CC	T module (TMOD)	●	●	●	●	●