

**NOTE:**

●: This function is supported

▲: This function is the new feature in this version

○: This function is not supported

※: This function may be supported which depends on the actual condition of the vehicle

Vehicle model	Year	Engine Type/Chassis Number	System Name	Information	Read TroubleCode	Clear TroubleCode	Read DataStream
F-Type	2014-2015	Supercharged V6 3.0L engine	AAM - Audio amplifier module	●	●	●	●
F-Type	2014-2015	Supercharged V6 3.0L engine	ABS - ABS control module	●	●	●	●
F-Type	2014-2015	Supercharged V6 3.0L engine	ACM - Audio front control module	●	●	●	●
F-Type	2014-2015	Supercharged V6 3.0L engine	ATCM - All terrain control module	●	●	●	●
F-Type	2014-2015	Supercharged V6 3.0L engine	BCM - Body control module	●	●	●	●
F-Type	2014-2015	Supercharged V6 3.0L engine	CAV - Connect and view module	●	●	●	●
F-Type	2014-2015	Supercharged V6 3.0L engine	CHCM - Chassis control module	●	●	●	●
F-Type	2014-2015	Supercharged V6 3.0L engine	DABM - Digital audio broadcast module	●	●	●	●
F-Type	2014-2015	Supercharged V6 3.0L engine	DDM - Driver's door module	●	●	●	●
F-Type	2014-2015	Supercharged V6 3.0L engine	DSM - Driver's seat module	●	●	●	●
F-Type	2014-2015	Supercharged V6 3.0L engine	front)	●	●	●	●
F-Type	2014-2015	Supercharged V6 3.0L engine	FCIM - Integrated control panel	●	●	●	●
F-Type	2014-2015	Supercharged V6 3.0L engine	FTCM - Folding top control module	●	●	●	●
F-Type	2014-2015	Supercharged V6 3.0L engine	FTCMB - Folding top control module B	●	●	●	●
F-Type	2014-2015	Supercharged V6 3.0L engine	GSM - Gear shift module	●	●	●	●
F-Type	2014-2015	Supercharged V6 3.0L engine	GWM - Gateway module	●	●	●	●
F-Type	2014-2015	Supercharged V6 3.0L engine	HCM - Headlamp control module	●	●	●	●
F-Type	2014-2015	Supercharged V6 3.0L engine	HCMB - Headlamp control module B	●	●	●	●
F-Type	2014-2015	Supercharged V6 3.0L engine	HVAC - Heating ventilation and air conditioning control module	●	●	●	●
F-Type	2014-2015	Supercharged V6 3.0L engine	IPC - Instrument cluster control module.	●	●	●	●
F-Type	2014-2015	Supercharged V6 3.0L engine	IPMB - Image processing module B	●	●	●	●
F-Type	2014-2015	Supercharged V6 3.0L engine	NCM - Navigation control module	●	●	●	●
F-Type	2014-2015	Supercharged V6 3.0L engine	OCS - Restraints occupant classification system module	●	●	●	●
F-Type	2014-2015	Supercharged V6 3.0L engine	PAM - Parking assist control module	●	●	●	●
F-Type	2014-2015	Supercharged V6 3.0L engine	PBM - Parking brake control module	●	●	●	●
F-Type	2014-2015	Supercharged V6 3.0L engine	PCM - Powertrain control module	●	●	●	●
F-Type	2014-2015	Supercharged V6 3.0L engine	PDM - Passenger's door module	●	●	●	●
F-Type	2014-2015	Supercharged V6 3.0L engine	PSM - Passenger's seat module	●	●	●	●
F-Type	2014-2015	Supercharged V6 3.0L engine	RCM - Restraints control module	●	●	●	●
F-Type	2014-2015	Supercharged V6 3.0L engine	RDCM - Rear differential control module	●	●	●	●
F-Type	2014-2015	Supercharged V6 3.0L engine	RFA - Keyless vehicle module	●	●	●	●
F-Type	2014-2015	Supercharged V6 3.0L engine	RGTM - Rear gate / trunk module	●	●	●	●
F-Type	2014-2015	Supercharged V6 3.0L engine	SODL - Side object detection control module - Left	●	●	●	●
F-Type	2014-2015	Supercharged V6 3.0L engine	SODR - Side object detection control module - Right	●	●	●	●
F-Type	2014-2015	Supercharged V6 3.0L engine	SRM - Satellite audio unit module.	●	●	●	●
F-Type	2014-2015	Supercharged V6 3.0L engine	TCM - Transmission control module	●	●	●	●
F-Type	2014-2015	Supercharged V6 3.0L engine	TVM - Television module	●	●	●	●
F-Type	2014-2015	Supercharged V6 3.0L engine	VIM - Vehicle immobilizer control module	●	●	●	●
F-Type	2014-2015	Supercharged V8. 5.0L engine	AAM - Audio amplifier module	●	●	●	●
F-Type	2014-2015	Supercharged V8. 5.0L engine	ABS - ABS control module	●	●	●	●
F-Type	2014-2015	Supercharged V8. 5.0L engine	ACM - Audio front control module	●	●	●	●
F-Type	2014-2015	Supercharged V8. 5.0L engine	ATCM - All terrain control module	●	●	●	●
F-Type	2014-2015	Supercharged V8. 5.0L engine	BCM - Body control module	●	●	●	●
F-Type	2014-2015	Supercharged V8. 5.0L engine	CAV - Connect and view module	●	●	●	●
F-Type	2014-2015	Supercharged V8. 5.0L engine	CHCM - Chassis control module	●	●	●	●
F-Type	2014-2015	Supercharged V8. 5.0L engine	DABM - Digital audio broadcast module	●	●	●	●
F-Type	2014-2015	Supercharged V8. 5.0L engine	DDM - Driver's door module	●	●	●	●
F-Type	2014-2015	Supercharged V8. 5.0L engine	DSM - Driver's seat module	●	●	●	●
F-Type	2014-2015	Supercharged V8. 5.0L engine	front)	●	●	●	●
F-Type	2014-2015	Supercharged V8. 5.0L engine	FCIM - Integrated control panel	●	●	●	●
F-Type	2014-2015	Supercharged V8. 5.0L engine	FTCM - Folding top control module	●	●	●	●
F-Type	2014-2015	Supercharged V8. 5.0L engine	FTCMB - Folding top control module B	●	●	●	●
F-Type	2014-2015	Supercharged V8. 5.0L engine	GSM - Gear shift module	●	●	●	●
F-Type	2014-2015	Supercharged V8. 5.0L engine	GWM - Gateway module	●	●	●	●
F-Type	2014-2015	Supercharged V8. 5.0L engine	HCM - Headlamp control module	●	●	●	●
F-Type	2014-2015	Supercharged V8. 5.0L engine	HCMB - Headlamp control module B	●	●	●	●
F-Type	2014-2015	Supercharged V8. 5.0L engine	HVAC - Heating ventilation and air conditioning control module	●	●	●	●
F-Type	2014-2015	Supercharged V8. 5.0L engine	IPC - Instrument cluster control module.	●	●	●	●
F-Type	2014-2015	Supercharged V8. 5.0L engine	IPMB - Image processing module B	●	●	●	●
F-Type	2014-2015	Supercharged V8. 5.0L engine	NCM - Navigation control module	●	●	●	●
F-Type	2014-2015	Supercharged V8. 5.0L engine	OCS - Restraints occupant classification system module	●	●	●	●
F-Type	2014-2015	Supercharged V8. 5.0L engine	PAM - Parking assist control module	●	●	●	●
F-Type	2014-2015	Supercharged V8. 5.0L engine	PBM - Parking brake control module	●	●	●	●
F-Type	2014-2015	Supercharged V8. 5.0L engine	PCM - Powertrain control module	●	●	●	●
F-Type	2014-2015	Supercharged V8. 5.0L engine	PDM - Passenger's door module	●	●	●	●
F-Type	2014-2015	Supercharged V8. 5.0L engine	PSM - Passenger's seat module	●	●	●	●
F-Type	2014-2015	Supercharged V8. 5.0L engine	RCM - Restraints control module	●	●	●	●
F-Type	2014-2015	Supercharged V8. 5.0L engine	RDCM - Rear differential control module	●	●	●	●
F-Type	2014-2015	Supercharged V8. 5.0L engine	RFA - Keyless vehicle module	●	●	●	●
F-Type	2014-2015	Supercharged V8. 5.0L engine	RGTM - Rear gate / trunk module	●	●	●	●
F-Type	2014-2015	Supercharged V8. 5.0L engine	SODL - Side object detection control module - Left	●	●	●	●
F-Type	2014-2015	Supercharged V8. 5.0L engine	SODR - Side object detection control module - Right	●	●	●	●
F-Type	2014-2015	Supercharged V8. 5.0L engine	SRM - Satellite audio unit module.	●	●	●	●
F-Type	2014-2015	Supercharged V8. 5.0L engine	TCM - Transmission control module	●	●	●	●
F-Type	2014-2015	Supercharged V8. 5.0L engine	TVM - Television module	●	●	●	●
F-Type	2014-2015	Supercharged V8. 5.0L engine	VIM - Vehicle immobilizer control module	●	●	●	●
F-Type	2016 -	Supercharged V6 3.0L engine	AAM - Audio amplifier module	●	●	●	●

Vehcile model	Year	Engine Type/Chassis Number	System Name	Information	Read TroubleCode	Clear TroubleCode	Read DataStream
F-Type	2016 -	Supercharged V6 3.0L engine	ABS - ABS control module	●	●	●	●
F-Type	2016 -	Supercharged V6 3.0L engine	ACM - Audio front control module	●	●	●	●
F-Type	2016 -	Supercharged V6 3.0L engine	AHU - InControl Touch audio head unit	●	●	●	○
F-Type	2016 -	Supercharged V6 3.0L engine	ATCM - All terrain control module	●	●	●	●
F-Type	2016 -	Supercharged V6 3.0L engine	BCM - Body control module	●	●	●	●
F-Type	2016 -	Supercharged V6 3.0L engine	CAV - Connect and view module	●	●	●	●
F-Type	2016 -	Supercharged V6 3.0L engine	CHCM - Chassis control module	●	●	●	●
F-Type	2016 -	Supercharged V6 3.0L engine	DABM - Digital audio broadcast module	●	●	●	●
F-Type	2016 -	Supercharged V6 3.0L engine	DDM - Driver's door module	●	●	●	●
F-Type	2016 -	Supercharged V6 3.0L engine	DSM - Driver's seat module	●	●	●	●
F-Type	2016 -	Supercharged V6 3.0L engine	front)	●	●	●	●
F-Type	2016 -	Supercharged V6 3.0L engine	FCIM - Integrated control panel	●	●	●	●
F-Type	2016 -	Supercharged V6 3.0L engine	FTCM - Folding top control module	●	●	●	●
F-Type	2016 -	Supercharged V6 3.0L engine	FTCMB - Folding top control module B	●	●	●	●
F-Type	2016 -	Supercharged V6 3.0L engine	GSM - Gear shift module	●	●	●	●
F-Type	2016 -	Supercharged V6 3.0L engine	GWM - Gateway module	●	●	●	●
F-Type	2016 -	Supercharged V6 3.0L engine	HCM - Headlamp control module	●	●	●	●
F-Type	2016 -	Supercharged V6 3.0L engine	HVAC - Heating ventilation and air conditioning control module	●	●	●	●
F-Type	2016 -	Supercharged V6 3.0L engine	IPC - Instrument cluster control module.	●	●	●	●
F-Type	2016 -	Supercharged V6 3.0L engine	IPMA - Image processing control module A	●	●	●	●
F-Type	2016 -	Supercharged V6 3.0L engine	IPMB - Image processing module B	●	●	●	○
F-Type	2016 -	Supercharged V6 3.0L engine	NAV - Navigation control module	●	●	●	○
F-Type	2016 -	Supercharged V6 3.0L engine	NCM - Navigation control module	●	●	●	●
F-Type	2016 -	Supercharged V6 3.0L engine	OCS - Restraints occupant classification system module	●	●	●	●
F-Type	2016 -	Supercharged V6 3.0L engine	PAM - Parking assist control module	●	●	●	●
F-Type	2016 -	Supercharged V6 3.0L engine	PBM - Parking brake control module	●	●	●	●
F-Type	2016 -	Supercharged V6 3.0L engine	PCM - Powertrain control module	●	●	●	●
F-Type	2016 -	Supercharged V6 3.0L engine	PDM - Passenger's door module	●	●	●	●
F-Type	2016 -	Supercharged V6 3.0L engine	PSCM - Power steering control module	●	●	●	●
F-Type	2016 -	Supercharged V6 3.0L engine	PSM - Passenger's seat module	●	●	●	●
F-Type	2016 -	Supercharged V6 3.0L engine	RCM - Restraints control module	●	●	●	●
F-Type	2016 -	Supercharged V6 3.0L engine	RDCM - Rear differential control module	●	●	●	●
F-Type	2016 -	Supercharged V6 3.0L engine	RFA - Keyless vehicle module	●	●	●	●
F-Type	2016 -	Supercharged V6 3.0L engine	RGTM - Rear gate / trunk module	●	●	●	●
F-Type	2016 -	Supercharged V6 3.0L engine	SASM - Steering angle sensor module	●	●	●	●
F-Type	2016 -	Supercharged V6 3.0L engine	SODL - Side object detection control module - Left	●	●	●	●
F-Type	2016 -	Supercharged V6 3.0L engine	SODR - Side object detection control module - Right	●	●	●	●
F-Type	2016 -	Supercharged V6 3.0L engine	SRM - Satellite audio unit module.	●	●	●	●
F-Type	2016 -	Supercharged V6 3.0L engine	TCCM - Transfer case control module	●	●	●	●
F-Type	2016 -	Supercharged V6 3.0L engine	TCM - Transmission control module	●	●	●	●
F-Type	2016 -	Supercharged V6 3.0L engine	TCU - Telematic control unit module	●	●	●	●
F-Type	2016 -	Supercharged V6 3.0L engine	TPM - Tire pressure monitor module	●	●	●	●
F-Type	2016 -	Supercharged V6 3.0L engine	TVM - Television module	●	●	●	●
F-Type	2016 -	Supercharged V6 3.0L engine	VIM - Vehicle immobilizer control module	●	●	●	●
F-Type	2016 -	Supercharged V8. 5.0L engine	AAM - Audio amplifier module	●	●	●	●
F-Type	2016 -	Supercharged V8. 5.0L engine	ABS - ABS control module	●	●	●	●
F-Type	2016 -	Supercharged V8. 5.0L engine	ACM - Audio front control module	●	●	●	●
F-Type	2016 -	Supercharged V8. 5.0L engine	AHU - InControl Touch audio head unit	●	●	●	○
F-Type	2016 -	Supercharged V8. 5.0L engine	ATCM - All terrain control module	●	●	●	●
F-Type	2016 -	Supercharged V8. 5.0L engine	BCM - Body control module	●	●	●	●
F-Type	2016 -	Supercharged V8. 5.0L engine	CAV - Connect and view module	●	●	●	●
F-Type	2016 -	Supercharged V8. 5.0L engine	CHCM - Chassis control module	●	●	●	●
F-Type	2016 -	Supercharged V8. 5.0L engine	DABM - Digital audio broadcast module	●	●	●	●
F-Type	2016 -	Supercharged V8. 5.0L engine	DDM - Driver's door module	●	●	●	●
F-Type	2016 -	Supercharged V8. 5.0L engine	DSM - Driver's seat module	●	●	●	●
F-Type	2016 -	Supercharged V8. 5.0L engine	front)	●	●	●	●
F-Type	2016 -	Supercharged V8. 5.0L engine	FCIM - Integrated control panel	●	●	●	●
F-Type	2016 -	Supercharged V8. 5.0L engine	FTCM - Folding top control module	●	●	●	●
F-Type	2016 -	Supercharged V8. 5.0L engine	FTCMB - Folding top control module B	●	●	●	●
F-Type	2016 -	Supercharged V8. 5.0L engine	GSM - Gear shift module	●	●	●	●
F-Type	2016 -	Supercharged V8. 5.0L engine	GWM - Gateway module	●	●	●	●
F-Type	2016 -	Supercharged V8. 5.0L engine	HCM - Headlamp control module	●	●	●	●
F-Type	2016 -	Supercharged V8. 5.0L engine	HVAC - Heating ventilation and air conditioning control module	●	●	●	●
F-Type	2016 -	Supercharged V8. 5.0L engine	IPC - Instrument cluster control module.	●	●	●	●
F-Type	2016 -	Supercharged V8. 5.0L engine	IPMA - Image processing control module A	●	●	●	●
F-Type	2016 -	Supercharged V8. 5.0L engine	IPMB - Image processing module B	●	●	●	○
F-Type	2016 -	Supercharged V8. 5.0L engine	NAV - Navigation control module	●	●	●	○
F-Type	2016 -	Supercharged V8. 5.0L engine	NCM - Navigation control module	●	●	●	●
F-Type	2016 -	Supercharged V8. 5.0L engine	OCS - Restraints occupant classification system module	●	●	●	●
F-Type	2016 -	Supercharged V8. 5.0L engine	PAM - Parking assist control module	●	●	●	●
F-Type	2016 -	Supercharged V8. 5.0L engine	PBM - Parking brake control module	●	●	●	●
F-Type	2016 -	Supercharged V8. 5.0L engine	PCM - Powertrain control module	●	●	●	●
F-Type	2016 -	Supercharged V8. 5.0L engine	PDM - Passenger's door module	●	●	●	●
F-Type	2016 -	Supercharged V8. 5.0L engine	PSCM - Power steering control module	●	●	●	●
F-Type	2016 -	Supercharged V8. 5.0L engine	PSM - Passenger's seat module	●	●	●	●
F-Type	2016 -	Supercharged V8. 5.0L engine	RCM - Restraints control module	●	●	●	●
F-Type	2016 -	Supercharged V8. 5.0L engine	RDCM - Rear differential control module	●	●	●	●
F-Type	2016 -	Supercharged V8. 5.0L engine	RFA - Keyless vehicle module	●	●	●	●
F-Type	2016 -	Supercharged V8. 5.0L engine	RGTM - Rear gate / trunk module	●	●	●	●
F-Type	2016 -	Supercharged V8. 5.0L engine	SASM - Steering angle sensor module	●	●	●	●
F-Type	2016 -	Supercharged V8. 5.0L engine	SODL - Side object detection control module - Left	●	●	●	●
F-Type	2016 -	Supercharged V8. 5.0L engine	SODR - Side object detection control module - Right	●	●	●	●
F-Type	2016 -	Supercharged V8. 5.0L engine	SRM - Satellite audio unit module.	●	●	●	●
F-Type	2016 -	Supercharged V8. 5.0L engine	TCCM - Transfer case control module	●	●	●	●
F-Type	2016 -	Supercharged V8. 5.0L engine	TCM - Transmission control module	●	●	●	●
F-Type	2016 -	Supercharged V8. 5.0L engine	TCU - Telematic control unit module	●	●	●	●
F-Type	2016 -	Supercharged V8. 5.0L engine	TPM - Tire pressure monitor module	●	●	●	●

Vehcile model	Year	Engine Type/Chassis Number	System Name	Information	Read TroubleCode	Clear TroubleCode	Read DataStream
F-Type	2016 -	Supercharged V8. 5.0L engine	TVM - Television module	●	●	●	●
F-Type	2016 -	Supercharged V8. 5.0L engine	VIM - Vehicle immobilizer control module	●	●	●	●
Jaguar XF	2008-2009	Diesel V6	AAM - Audio amplifier module	●	●	●	●
Jaguar XF	2008-2009	Diesel V6	ABS - ABS control module	●	●	●	●
Jaguar XF	2008-2009	Diesel V6	ACM - Audio front control module	●	●	●	●
Jaguar XF	2008-2009	Diesel V6	ADCM - Adaptive damping control module	●	●	●	●
Jaguar XF	2008-2009	Diesel V6	APIM - Accessory protocol interface module	●	●	●	●
Jaguar XF	2008-2009	Diesel V6	CCM - Speed control module	●	●	●	●
Jaguar XF	2008-2009	Diesel V6	DABM - Digital audio broadcast module	●	●	●	●
Jaguar XF	2008-2009	Diesel V6	DCSM - Driver's climate seat module	●	●	●	●
Jaguar XF	2008-2009	Diesel V6	DDM - Driver's door module	●	●	●	●
Jaguar XF	2008-2009	Diesel V6	DSM - Driver's seat module	●	●	●	●
Jaguar XF	2008-2009	Diesel V6	front)	●	●	●	●
Jaguar XF	2008-2009	Diesel V6	FLR - Forward looking radar	●	○	●	○
Jaguar XF	2008-2009	Diesel V6	FSJB - Central junction box (body control module)	●	●	●	●
Jaguar XF	2008-2009	Diesel V6	GSM - Gear shift module	●	●	●	●
Jaguar XF	2008-2009	Diesel V6	HCM - Headlamp control module	●	●	●	●
Jaguar XF	2008-2009	Diesel V6	HVAC - Heating ventilation and air conditioning control module	●	●	●	●
Jaguar XF	2008-2009	Diesel V6	ICM - Infotainment control module.	●	●	●	●
Jaguar XF	2008-2009	Diesel V6	ICP - Integrated control panel	●	●	●	○
Jaguar XF	2008-2009	Diesel V6	ICS - Impact classification system	●	●	●	●
Jaguar XF	2008-2009	Diesel V6	IPC - Instrument cluster control module.	●	●	●	●
Jaguar XF	2008-2009	Diesel V6	KVM - Keyless vehicle module	●	●	●	●
Jaguar XF	2008-2009	Diesel V6	NCM - Navigation control module	●	●	●	●
Jaguar XF	2008-2009	Diesel V6	OCS - Restraints occupant classification system module	●	●	●	●
Jaguar XF	2008-2009	Diesel V6	PAM - Parking assist control module	●	●	●	●
Jaguar XF	2008-2009	Diesel V6	PBM - Parking brake control module	●	●	●	●
Jaguar XF	2008-2009	Diesel V6	PCM - Powertrain control module	●	●	●	●
Jaguar XF	2008-2009	Diesel V6	PDM - Passenger's door module	●	●	●	●
Jaguar XF	2008-2009	Diesel V6	RCM - Restraints control module	●	●	●	●
Jaguar XF	2008-2009	Diesel V6	RSJB - Auxiliary junction box (body control module B)	●	●	●	●
Jaguar XF	2008-2009	Diesel V6	SODL - Side object detection control module - Left	●	●	●	●
Jaguar XF	2008-2009	Diesel V6	SODR - Side object detection control module - Right	●	●	●	●
Jaguar XF	2008-2009	Diesel V6	SRM - Satellite audio unit module.	●	●	●	○
Jaguar XF	2008-2009	Diesel V6	TCM - Transmission control module	●	●	●	●
Jaguar XF	2008-2009	Diesel V6	TEL - Cellular telephone control module	●	●	●	●
Jaguar XF	2008-2009	Diesel V6	TPM - Tire pressure monitor module	●	●	●	●
Jaguar XF	2008-2009	Diesel V6	TVM - Television module	●	●	●	●
Jaguar XF	2008-2009	Diesel V6	VIM - Vehicle immobilizer control module	●	●	●	●
Jaguar XF	2008-2009	Normally aspirated V6	AAM - Audio amplifier module	●	●	●	●
Jaguar XF	2008-2009	Normally aspirated V6	ABS - ABS control module	●	●	●	●
Jaguar XF	2008-2009	Normally aspirated V6	ACM - Audio front control module	●	●	●	●
Jaguar XF	2008-2009	Normally aspirated V6	ADCM - Adaptive damping control module	●	●	●	●
Jaguar XF	2008-2009	Normally aspirated V6	APIM - Accessory protocol interface module	●	●	●	●
Jaguar XF	2008-2009	Normally aspirated V6	CCM - Speed control module	●	●	●	●
Jaguar XF	2008-2009	Normally aspirated V6	DABM - Digital audio broadcast module	●	●	●	●
Jaguar XF	2008-2009	Normally aspirated V6	DCSM - Driver's climate seat module	●	●	●	●
Jaguar XF	2008-2009	Normally aspirated V6	DDM - Driver's door module	●	●	●	●
Jaguar XF	2008-2009	Normally aspirated V6	DSM - Driver's seat module	●	●	●	●
Jaguar XF	2008-2009	Normally aspirated V6	front)	●	●	●	●
Jaguar XF	2008-2009	Normally aspirated V6	FLR - Forward looking radar	●	○	●	○
Jaguar XF	2008-2009	Normally aspirated V6	FSJB - Central junction box (body control module)	●	●	●	●
Jaguar XF	2008-2009	Normally aspirated V6	GSM - Gear shift module	●	●	●	●
Jaguar XF	2008-2009	Normally aspirated V6	HCM - Headlamp control module	●	●	●	●
Jaguar XF	2008-2009	Normally aspirated V6	HVAC - Heating ventilation and air conditioning control module	●	●	●	●
Jaguar XF	2008-2009	Normally aspirated V6	ICM - Infotainment control module.	●	●	●	●
Jaguar XF	2008-2009	Normally aspirated V6	ICP - Integrated control panel	●	●	●	○
Jaguar XF	2008-2009	Normally aspirated V6	ICS - Impact classification system	●	●	●	●
Jaguar XF	2008-2009	Normally aspirated V6	IPC - Instrument cluster control module.	●	●	●	●
Jaguar XF	2008-2009	Normally aspirated V6	KVM - Keyless vehicle module	●	●	●	●
Jaguar XF	2008-2009	Normally aspirated V6	NCM - Navigation control module	●	●	●	●
Jaguar XF	2008-2009	Normally aspirated V6	OCS - Restraints occupant classification system module	●	●	●	●
Jaguar XF	2008-2009	Normally aspirated V6	PAM - Parking assist control module	●	●	●	●
Jaguar XF	2008-2009	Normally aspirated V6	PBM - Parking brake control module	●	●	●	●
Jaguar XF	2008-2009	Normally aspirated V6	PCM - Powertrain control module	●	●	●	●
Jaguar XF	2008-2009	Normally aspirated V6	PDM - Passenger's door module	●	●	●	●
Jaguar XF	2008-2009	Normally aspirated V6	RCM - Restraints control module	●	●	●	●
Jaguar XF	2008-2009	Normally aspirated V6	RSJB - Auxiliary junction box (body control module B)	●	●	●	●
Jaguar XF	2008-2009	Normally aspirated V6	SODL - Side object detection control module - Left	●	●	●	●
Jaguar XF	2008-2009	Normally aspirated V6	SODR - Side object detection control module - Right	●	●	●	●
Jaguar XF	2008-2009	Normally aspirated V6	SRM - Satellite audio unit module.	●	●	●	○
Jaguar XF	2008-2009	Normally aspirated V6	TCM - Transmission control module	●	●	●	●
Jaguar XF	2008-2009	Normally aspirated V6	TEL - Cellular telephone control module	●	●	●	●
Jaguar XF	2008-2009	Normally aspirated V6	TPM - Tire pressure monitor module	●	●	●	●
Jaguar XF	2008-2009	Normally aspirated V6	TVM - Television module	●	●	●	●
Jaguar XF	2008-2009	Normally aspirated V6	VIM - Vehicle immobilizer control module	●	●	●	●
Jaguar XF	2008-2009	Normally aspirated V8	AAM - Audio amplifier module	●	●	●	●
Jaguar XF	2008-2009	Normally aspirated V8	ABS - ABS control module	●	●	●	●
Jaguar XF	2008-2009	Normally aspirated V8	ACM - Audio front control module	●	●	●	●
Jaguar XF	2008-2009	Normally aspirated V8	ADCM - Adaptive damping control module	●	●	●	●
Jaguar XF	2008-2009	Normally aspirated V8	APIM - Accessory protocol interface module	●	●	●	●
Jaguar XF	2008-2009	Normally aspirated V8	CCM - Speed control module	●	●	●	●
Jaguar XF	2008-2009	Normally aspirated V8	DABM - Digital audio broadcast module	●	●	●	●
Jaguar XF	2008-2009	Normally aspirated V8	DCSM - Driver's climate seat module	●	●	●	●
Jaguar XF	2008-2009	Normally aspirated V8	DDM - Driver's door module	●	●	●	●
Jaguar XF	2008-2009	Normally aspirated V8	DSM - Driver's seat module	●	●	●	●
Jaguar XF	2008-2009	Normally aspirated V8	front)	●	●	●	●

Vehcile model	Year	Engine Type/Chassis Number	System Name	Information	Read TroubleCode	Clear TroubleCode	Read DataStream
Jaguar XF	2008-2009	Normally aspirated V8	FLR - Forward looking radar	●	○	●	○
Jaguar XF	2008-2009	Normally aspirated V8	FSJB - Central junction box (body control module)	●	●	●	●
Jaguar XF	2008-2009	Normally aspirated V8	GSM - Gear shift module	●	●	●	●
Jaguar XF	2008-2009	Normally aspirated V8	HCM - Headlamp control module	●	●	●	●
Jaguar XF	2008-2009	Normally aspirated V8	HVAC - Heating ventilation and air conditioning control module	●	●	●	●
Jaguar XF	2008-2009	Normally aspirated V8	ICM - Infotainment control module.	●	●	●	●
Jaguar XF	2008-2009	Normally aspirated V8	ICP - Integrated control panel	●	●	●	○
Jaguar XF	2008-2009	Normally aspirated V8	ICS - Impact classification system	●	●	●	●
Jaguar XF	2008-2009	Normally aspirated V8	IPC - Instrument cluster control module.	●	●	●	●
Jaguar XF	2008-2009	Normally aspirated V8	KVM - Keyless vehicle module	●	●	●	●
Jaguar XF	2008-2009	Normally aspirated V8	NCM - Navigation control module	●	●	●	●
Jaguar XF	2008-2009	Normally aspirated V8	OCS - Restraints occupant classification system module	●	●	●	●
Jaguar XF	2008-2009	Normally aspirated V8	PAM - Parking assist control module	●	●	●	●
Jaguar XF	2008-2009	Normally aspirated V8	PBM - Parking brake control module	●	●	●	●
Jaguar XF	2008-2009	Normally aspirated V8	PCM - Powertrain control module	●	●	●	●
Jaguar XF	2008-2009	Normally aspirated V8	PDM - Passenger's door module	●	●	●	●
Jaguar XF	2008-2009	Normally aspirated V8	RCM - Restraints control module	●	●	●	●
Jaguar XF	2008-2009	Normally aspirated V8	RSJB - Auxiliary junction box (body control module B)	●	●	●	●
Jaguar XF	2008-2009	Normally aspirated V8	SODL - Side object detection control module - Left	●	●	●	●
Jaguar XF	2008-2009	Normally aspirated V8	SODR - Side object detection control module - Right	●	●	●	●
Jaguar XF	2008-2009	Normally aspirated V8	SRM - Satellite audio unit module.	●	●	●	○
Jaguar XF	2008-2009	Normally aspirated V8	TCM - Transmission control module	●	●	●	●
Jaguar XF	2008-2009	Normally aspirated V8	TEL - Cellular telephone control module	●	●	●	●
Jaguar XF	2008-2009	Normally aspirated V8	TPM - Tire pressure monitor module	●	●	●	●
Jaguar XF	2008-2009	Normally aspirated V8	TVM - Television module	●	●	●	●
Jaguar XF	2008-2009	Normally aspirated V8	VIM - Vehicle immobilizer control module	●	●	●	●
Jaguar XF	2008-2009	Supercharged V8	AAM - Audio amplifier module	●	●	●	●
Jaguar XF	2008-2009	Supercharged V8	ABS - ABS control module	●	●	●	●
Jaguar XF	2008-2009	Supercharged V8	ACM - Audio front control module	●	●	●	●
Jaguar XF	2008-2009	Supercharged V8	ADCM - Adaptive damping control module	●	●	●	●
Jaguar XF	2008-2009	Supercharged V8	APIM - Accessory protocol interface module	●	●	●	●
Jaguar XF	2008-2009	Supercharged V8	CCM - Speed control module	●	●	●	●
Jaguar XF	2008-2009	Supercharged V8	DABM - Digital audio broadcast module	●	●	●	●
Jaguar XF	2008-2009	Supercharged V8	DCSM - Driver's climate seat module	●	●	●	●
Jaguar XF	2008-2009	Supercharged V8	DDM - Driver's door module	●	●	●	●
Jaguar XF	2008-2009	Supercharged V8	DSM - Driver's seat module (front)	●	●	●	●
Jaguar XF	2008-2009	Supercharged V8	FLR - Forward looking radar	●	○	●	○
Jaguar XF	2008-2009	Supercharged V8	FSJB - Central junction box (body control module)	●	●	●	●
Jaguar XF	2008-2009	Supercharged V8	GSM - Gear shift module	●	●	●	●
Jaguar XF	2008-2009	Supercharged V8	HCM - Headlamp control module	●	●	●	●
Jaguar XF	2008-2009	Supercharged V8	HVAC - Heating ventilation and air conditioning control module	●	●	●	●
Jaguar XF	2008-2009	Supercharged V8	ICM - Infotainment control module.	●	●	●	●
Jaguar XF	2008-2009	Supercharged V8	ICP - Integrated control panel	●	●	●	○
Jaguar XF	2008-2009	Supercharged V8	ICS - Impact classification system	●	●	●	●
Jaguar XF	2008-2009	Supercharged V8	IPC - Instrument cluster control module.	●	●	●	●
Jaguar XF	2008-2009	Supercharged V8	KVM - Keyless vehicle module	●	●	●	●
Jaguar XF	2008-2009	Supercharged V8	NCM - Navigation control module	●	●	●	●
Jaguar XF	2008-2009	Supercharged V8	OCS - Restraints occupant classification system module	●	●	●	●
Jaguar XF	2008-2009	Supercharged V8	PAM - Parking assist control module	●	●	●	●
Jaguar XF	2008-2009	Supercharged V8	PBM - Parking brake control module	●	●	●	●
Jaguar XF	2008-2009	Supercharged V8	PCM - Powertrain control module	●	●	●	●
Jaguar XF	2008-2009	Supercharged V8	PDM - Passenger's door module	●	●	●	●
Jaguar XF	2008-2009	Supercharged V8	RCM - Restraints control module	●	●	●	●
Jaguar XF	2008-2009	Supercharged V8	RSJB - Auxiliary junction box (body control module B)	●	●	●	●
Jaguar XF	2008-2009	Supercharged V8	SODL - Side object detection control module - Left	●	●	●	●
Jaguar XF	2008-2009	Supercharged V8	SODR - Side object detection control module - Right	●	●	●	●
Jaguar XF	2008-2009	Supercharged V8	SRM - Satellite audio unit module.	●	●	●	○
Jaguar XF	2008-2009	Supercharged V8	TCM - Transmission control module	●	●	●	●
Jaguar XF	2008-2009	Supercharged V8	TEL - Cellular telephone control module	●	●	●	●
Jaguar XF	2008-2009	Supercharged V8	TPM - Tire pressure monitor module	●	●	●	●
Jaguar XF	2008-2009	Supercharged V8	TVM - Television module	●	●	●	●
Jaguar XF	2008-2009	Supercharged V8	VIM - Vehicle immobilizer control module	●	●	●	●
Jaguar XF	2010-2011	Diesel V6	AAM - Audio amplifier module	●	●	●	●
Jaguar XF	2010-2011	Diesel V6	ABS - ABS control module	●	●	●	●
Jaguar XF	2010-2011	Diesel V6	ACM - Audio front control module	●	●	●	●
Jaguar XF	2010-2011	Diesel V6	ADCM - Adaptive damping control module	●	●	●	●
Jaguar XF	2010-2011	Diesel V6	APIM - Accessory protocol interface module	●	●	●	●
Jaguar XF	2010-2011	Diesel V6	CCM - Speed control module	●	●	●	●
Jaguar XF	2010-2011	Diesel V6	DABM - Digital audio broadcast module	●	●	●	●
Jaguar XF	2010-2011	Diesel V6	DACMC - Digital audio control module C	●	●	●	●
Jaguar XF	2010-2011	Diesel V6	DCSM - Driver's climate seat module	●	●	●	●
Jaguar XF	2010-2011	Diesel V6	DDM - Driver's door module	●	●	●	●
Jaguar XF	2010-2011	Diesel V6	DSM - Driver's seat module (front)	●	●	●	●
Jaguar XF	2010-2011	Diesel V6	FLR - Forward looking radar	●	○	●	○
Jaguar XF	2010-2011	Diesel V6	FSJB - Central junction box (body control module)	●	●	●	●
Jaguar XF	2010-2011	Diesel V6	GSM - Gear shift module	●	●	●	●
Jaguar XF	2010-2011	Diesel V6	HCM - Headlamp control module	●	●	●	●
Jaguar XF	2010-2011	Diesel V6	HVAC - Heating ventilation and air conditioning control module	●	●	●	●
Jaguar XF	2010-2011	Diesel V6	ICM - Infotainment control module.	●	●	●	●
Jaguar XF	2010-2011	Diesel V6	ICP - Integrated control panel	●	●	●	●
Jaguar XF	2010-2011	Diesel V6	ICS - Impact classification system	●	●	●	●
Jaguar XF	2010-2011	Diesel V6	IPC - Instrument cluster control module.	●	●	●	●
Jaguar XF	2010-2011	Diesel V6	KVM - Keyless vehicle module	●	●	●	●
Jaguar XF	2010-2011	Diesel V6	NCM - Navigation control module	●	●	●	●
Jaguar XF	2010-2011	Diesel V6	OCS - Restraints occupant classification system module	●	●	●	●

Vehcile model	Year	Engine Type/Chassis Number	System Name	Information	Read TroubleCode	Clear TroubleCode	Read DataStream
Jaguar XF	2010-2011	Diesel V6	PAM - Parking assist control module	●	●	●	●
Jaguar XF	2010-2011	Diesel V6	PBM - Parking brake control module	●	●	●	●
Jaguar XF	2010-2011	Diesel V6	PCM - Powertrain control module	●	●	●	●
Jaguar XF	2010-2011	Diesel V6	PDM - Passenger's door module	●	●	●	●
Jaguar XF	2010-2011	Diesel V6	RCM - Restraints control module	●	●	●	●
Jaguar XF	2010-2011	Diesel V6	RDCM - Rear differential control module	●	●	●	●
Jaguar XF	2010-2011	Diesel V6	RSJB - Auxiliary junction box (body control module B)	●	●	●	●
Jaguar XF	2010-2011	Diesel V6	SODL - Side object detection control module - Left	●	●	●	●
Jaguar XF	2010-2011	Diesel V6	SODR - Side object detection control module - Right	●	●	●	●
Jaguar XF	2010-2011	Diesel V6	SRM - Satellite audio unit module.	●	●	●	●
Jaguar XF	2010-2011	Diesel V6	TCM - Transmission control module	●	●	●	●
Jaguar XF	2010-2011	Diesel V6	TEL - Cellular telephone control module	●	●	●	●
Jaguar XF	2010-2011	Diesel V6	TPM - Tire pressure monitor module	●	●	●	●
Jaguar XF	2010-2011	Diesel V6	TVM - Television module	●	●	●	●
Jaguar XF	2010-2011	Diesel V6	VIM - Vehicle immobilizer control module	●	●	●	●
Jaguar XF	2010-2011	Normally aspirated V6	AAM - Audio amplifier module	●	●	●	●
Jaguar XF	2010-2011	Normally aspirated V6	ABS - ABS control module	●	●	●	●
Jaguar XF	2010-2011	Normally aspirated V6	ACM - Audio front control module	●	●	●	●
Jaguar XF	2010-2011	Normally aspirated V6	ADCM - Adaptive damping control module	●	●	●	●
Jaguar XF	2010-2011	Normally aspirated V6	APIM - Accessory protocol interface module	●	●	●	●
Jaguar XF	2010-2011	Normally aspirated V6	CCM - Speed control module	●	●	●	●
Jaguar XF	2010-2011	Normally aspirated V6	DABM - Digital audio broadcast module	●	●	●	●
Jaguar XF	2010-2011	Normally aspirated V6	DACMC - Digital audio control module C	●	●	●	●
Jaguar XF	2010-2011	Normally aspirated V6	DCSM - Driver's climate seat module	●	●	●	●
Jaguar XF	2010-2011	Normally aspirated V6	DDM - Driver's door module	●	●	●	●
Jaguar XF	2010-2011	Normally aspirated V6	DSM - Driver's seat module	●	●	●	●
Jaguar XF	2010-2011	Normally aspirated V6	front)	●	●	●	●
Jaguar XF	2010-2011	Normally aspirated V6	FLR - Forward looking radar	●	○	●	○
Jaguar XF	2010-2011	Normally aspirated V6	FSJB - Central junction box (body control module)	●	●	●	●
Jaguar XF	2010-2011	Normally aspirated V6	GSM - Gear shift module	●	●	●	●
Jaguar XF	2010-2011	Normally aspirated V6	HCM - Headlamp control module	●	●	●	●
Jaguar XF	2010-2011	Normally aspirated V6	HVAC - Heating ventilation and air conditioning control module	●	●	●	●
Jaguar XF	2010-2011	Normally aspirated V6	ICM - Infotainment control module.	●	●	●	●
Jaguar XF	2010-2011	Normally aspirated V6	ICP - Integrated control panel	●	●	●	●
Jaguar XF	2010-2011	Normally aspirated V6	ICS - Impact classification system	●	●	●	●
Jaguar XF	2010-2011	Normally aspirated V6	IPC - Instrument cluster control module.	●	●	●	●
Jaguar XF	2010-2011	Normally aspirated V6	KVM - Keyless vehicle module	●	●	●	●
Jaguar XF	2010-2011	Normally aspirated V6	NCM - Navigation control module	●	●	●	●
Jaguar XF	2010-2011	Normally aspirated V6	OCS - Restraints occupant classification system module	●	●	●	●
Jaguar XF	2010-2011	Normally aspirated V6	PAM - Parking assist control module	●	●	●	●
Jaguar XF	2010-2011	Normally aspirated V6	PBM - Parking brake control module	●	●	●	●
Jaguar XF	2010-2011	Normally aspirated V6	PCM - Powertrain control module	●	●	●	●
Jaguar XF	2010-2011	Normally aspirated V6	PDM - Passenger's door module	●	●	●	●
Jaguar XF	2010-2011	Normally aspirated V6	RCM - Restraints control module	●	●	●	●
Jaguar XF	2010-2011	Normally aspirated V6	RDCM - Rear differential control module	●	●	●	●
Jaguar XF	2010-2011	Normally aspirated V6	RSJB - Auxiliary junction box (body control module B)	●	●	●	●
Jaguar XF	2010-2011	Normally aspirated V6	SODL - Side object detection control module - Left	●	●	●	●
Jaguar XF	2010-2011	Normally aspirated V6	SODR - Side object detection control module - Right	●	●	●	●
Jaguar XF	2010-2011	Normally aspirated V6	SRM - Satellite audio unit module.	●	●	●	●
Jaguar XF	2010-2011	Normally aspirated V6	TCM - Transmission control module	●	●	●	●
Jaguar XF	2010-2011	Normally aspirated V6	TEL - Cellular telephone control module	●	●	●	●
Jaguar XF	2010-2011	Normally aspirated V6	TPM - Tire pressure monitor module	●	●	●	●
Jaguar XF	2010-2011	Normally aspirated V6	TVM - Television module	●	●	●	●
Jaguar XF	2010-2011	Normally aspirated V6	VIM - Vehicle immobilizer control module	●	●	●	●
Jaguar XF	2010-2011	Normally aspirated V8 4.2L engine	AAM - Audio amplifier module	●	●	●	●
Jaguar XF	2010-2011	Normally aspirated V8 4.2L engine	ABS - ABS control module	●	●	●	●
Jaguar XF	2010-2011	Normally aspirated V8 4.2L engine	ACM - Audio front control module	●	●	●	●
Jaguar XF	2010-2011	Normally aspirated V8 4.2L engine	ADCM - Adaptive damping control module	●	●	●	●
Jaguar XF	2010-2011	Normally aspirated V8 4.2L engine	APIM - Accessory protocol interface module	●	●	●	●
Jaguar XF	2010-2011	Normally aspirated V8 4.2L engine	CCM - Speed control module	●	●	●	●
Jaguar XF	2010-2011	Normally aspirated V8 4.2L engine	DABM - Digital audio broadcast module	●	●	●	●
Jaguar XF	2010-2011	Normally aspirated V8 4.2L engine	DACMC - Digital audio control module C	●	●	●	●
Jaguar XF	2010-2011	Normally aspirated V8 4.2L engine	DCSM - Driver's climate seat module	●	●	●	●
Jaguar XF	2010-2011	Normally aspirated V8 4.2L engine	DDM - Driver's door module	●	●	●	●
Jaguar XF	2010-2011	Normally aspirated V8 4.2L engine	DSM - Driver's seat module	●	●	●	●
Jaguar XF	2010-2011	Normally aspirated V8 4.2L engine	front)	●	●	●	●
Jaguar XF	2010-2011	Normally aspirated V8 4.2L engine	FLR - Forward looking radar	●	○	●	○
Jaguar XF	2010-2011	Normally aspirated V8 4.2L engine	FSJB - Central junction box (body control module)	●	●	●	●
Jaguar XF	2010-2011	Normally aspirated V8 4.2L engine	GSM - Gear shift module	●	●	●	●
Jaguar XF	2010-2011	Normally aspirated V8 4.2L engine	HCM - Headlamp control module	●	●	●	●
Jaguar XF	2010-2011	Normally aspirated V8 4.2L engine	HVAC - Heating ventilation and air conditioning control module	●	●	●	●
Jaguar XF	2010-2011	Normally aspirated V8 4.2L engine	ICM - Infotainment control module.	●	●	●	●
Jaguar XF	2010-2011	Normally aspirated V8 4.2L engine	ICP - Integrated control panel	●	●	●	●
Jaguar XF	2010-2011	Normally aspirated V8 4.2L engine	ICS - Impact classification system	●	●	●	●
Jaguar XF	2010-2011	Normally aspirated V8 4.2L engine	IPC - Instrument cluster control module.	●	●	●	●
Jaguar XF	2010-2011	Normally aspirated V8 4.2L engine	KVM - Keyless vehicle module	●	●	●	●
Jaguar XF	2010-2011	Normally aspirated V8 4.2L engine	NCM - Navigation control module	●	●	●	●
Jaguar XF	2010-2011	Normally aspirated V8 4.2L engine	OCS - Restraints occupant classification system module	●	●	●	●
Jaguar XF	2010-2011	Normally aspirated V8 4.2L engine	PAM - Parking assist control module	●	●	●	●
Jaguar XF	2010-2011	Normally aspirated V8 4.2L engine	PBM - Parking brake control module	●	●	●	●
Jaguar XF	2010-2011	Normally aspirated V8 4.2L engine	PCM - Powertrain control module	●	●	●	●
Jaguar XF	2010-2011	Normally aspirated V8 4.2L engine	PDM - Passenger's door module	●	●	●	●
Jaguar XF	2010-2011	Normally aspirated V8 4.2L engine	RCM - Restraints control module	●	●	●	●
Jaguar XF	2010-2011	Normally aspirated V8 4.2L engine	RDCM - Rear differential control module	●	●	●	●
Jaguar XF	2010-2011	Normally aspirated V8 4.2L engine	RSJB - Auxiliary junction box (body control module B)	●	●	●	●
Jaguar XF	2010-2011	Normally aspirated V8 4.2L engine	SODL - Side object detection control module - Left	●	●	●	●
Jaguar XF	2010-2011	Normally aspirated V8 4.2L engine	SODR - Side object detection control module - Right	●	●	●	●



Vevhicle model	Year	Engine Type/Chassis Number	System Name	Information	Read TroubleCode	Clear TroubleCode	Read DataStream
Jaguar XF	2010-2011	Normally aspirated V8 4.2L engine	SRM - Satellite audio unit module.	●	●	●	●
Jaguar XF	2010-2011	Normally aspirated V8 4.2L engine	TCM - Transmission control module	●	●	●	●
Jaguar XF	2010-2011	Normally aspirated V8 4.2L engine	TEL - Cellular telephone control module	●	●	●	●
Jaguar XF	2010-2011	Normally aspirated V8 4.2L engine	TPM - Tire pressure monitor module	●	●	●	●
Jaguar XF	2010-2011	Normally aspirated V8 4.2L engine	TVM - Television module	●	●	●	●
Jaguar XF	2010-2011	Normally aspirated V8 4.2L engine	VIM - Vehicle immobilizer control module	●	●	●	●
Jaguar XF	2010-2011	Normally aspirated V8 5.0L engine	AAM - Audio amplifier module	●	●	●	●
Jaguar XF	2010-2011	Normally aspirated V8 5.0L engine	ABS - ABS control module	●	●	●	●
Jaguar XF	2010-2011	Normally aspirated V8 5.0L engine	ACM - Audio front control module	●	●	●	●
Jaguar XF	2010-2011	Normally aspirated V8 5.0L engine	ADCM - Adaptive damping control module	●	●	●	●
Jaguar XF	2010-2011	Normally aspirated V8 5.0L engine	APIM - Accessory protocol interface module	●	●	●	●
Jaguar XF	2010-2011	Normally aspirated V8 5.0L engine	CCM - Speed control module	●	●	●	●
Jaguar XF	2010-2011	Normally aspirated V8 5.0L engine	DABM - Digital audio broadcast module	●	●	●	●
Jaguar XF	2010-2011	Normally aspirated V8 5.0L engine	DACMC - Digital audio control module C	●	●	●	●
Jaguar XF	2010-2011	Normally aspirated V8 5.0L engine	DCSM - Driver's climate seat module	●	●	●	●
Jaguar XF	2010-2011	Normally aspirated V8 5.0L engine	DDM - Driver's door module	●	●	●	●
Jaguar XF	2010-2011	Normally aspirated V8 5.0L engine	DSM - Driver's seat module	●	●	●	●
Jaguar XF	2010-2011	Normally aspirated V8 5.0L engine	front)	●	●	●	●
Jaguar XF	2010-2011	Normally aspirated V8 5.0L engine	FLR - Forward looking radar	●	○	●	○
Jaguar XF	2010-2011	Normally aspirated V8 5.0L engine	FSJB - Central junction box (body control module)	●	●	●	●
Jaguar XF	2010-2011	Normally aspirated V8 5.0L engine	GSM - Gear shift module	●	●	●	●
Jaguar XF	2010-2011	Normally aspirated V8 5.0L engine	HCM - Headlamp control module	●	●	●	●
Jaguar XF	2010-2011	Normally aspirated V8 5.0L engine	HVAC - Heating ventilation and air conditioning control module	●	●	●	●
Jaguar XF	2010-2011	Normally aspirated V8 5.0L engine	ICM - Infotainment control module.	●	●	●	●
Jaguar XF	2010-2011	Normally aspirated V8 5.0L engine	ICP - Integrated control panel	●	●	●	●
Jaguar XF	2010-2011	Normally aspirated V8 5.0L engine	ICS - Impact classification system	●	●	●	●
Jaguar XF	2010-2011	Normally aspirated V8 5.0L engine	IPC - Instrument cluster control module.	●	●	●	●
Jaguar XF	2010-2011	Normally aspirated V8 5.0L engine	KVM - Keyless vehicle module	●	●	●	●
Jaguar XF	2010-2011	Normally aspirated V8 5.0L engine	NCM - Navigation control module	●	●	●	●
Jaguar XF	2010-2011	Normally aspirated V8 5.0L engine	OCS - Restraints occupant classification system module	●	●	●	●
Jaguar XF	2010-2011	Normally aspirated V8 5.0L engine	PAM - Parking assist control module	●	●	●	●
Jaguar XF	2010-2011	Normally aspirated V8 5.0L engine	PBM - Parking brake control module	●	●	●	●
Jaguar XF	2010-2011	Normally aspirated V8 5.0L engine	PCM - Powertrain control module	●	●	●	●
Jaguar XF	2010-2011	Normally aspirated V8 5.0L engine	PDM - Passenger's door module	●	●	●	●
Jaguar XF	2010-2011	Normally aspirated V8 5.0L engine	RCM - Restraints control module	●	●	●	●
Jaguar XF	2010-2011	Normally aspirated V8 5.0L engine	RDCM - Rear differential control module	●	●	●	●
Jaguar XF	2010-2011	Normally aspirated V8 5.0L engine	RSJB - Auxiliary junction box (body control module B)	●	●	●	●
Jaguar XF	2010-2011	Normally aspirated V8 5.0L engine	SODL - Side object detection control module - Left	●	●	●	●
Jaguar XF	2010-2011	Normally aspirated V8 5.0L engine	SODR - Side object detection control module - Right	●	●	●	●
Jaguar XF	2010-2011	Normally aspirated V8 5.0L engine	SRM - Satellite audio unit module.	●	●	●	●
Jaguar XF	2010-2011	Normally aspirated V8 5.0L engine	TCM - Transmission control module	●	●	●	●
Jaguar XF	2010-2011	Normally aspirated V8 5.0L engine	TEL - Cellular telephone control module	●	●	●	●
Jaguar XF	2010-2011	Normally aspirated V8 5.0L engine	TPM - Tire pressure monitor module	●	●	●	●
Jaguar XF	2010-2011	Normally aspirated V8 5.0L engine	TVM - Television module	●	●	●	●
Jaguar XF	2010-2011	Normally aspirated V8 5.0L engine	VIM - Vehicle immobilizer control module	●	●	●	●
Jaguar XF	2010-2011	Supercharged V8. 5.0L engine	AAM - Audio amplifier module	●	●	●	●
Jaguar XF	2010-2011	Supercharged V8. 5.0L engine	ABS - ABS control module	●	●	●	●
Jaguar XF	2010-2011	Supercharged V8. 5.0L engine	ACM - Audio front control module	●	●	●	●
Jaguar XF	2010-2011	Supercharged V8. 5.0L engine	ADCM - Adaptive damping control module	●	●	●	●
Jaguar XF	2010-2011	Supercharged V8. 5.0L engine	APIM - Accessory protocol interface module	●	●	●	●
Jaguar XF	2010-2011	Supercharged V8. 5.0L engine	CCM - Speed control module	●	●	●	●
Jaguar XF	2010-2011	Supercharged V8. 5.0L engine	DABM - Digital audio broadcast module	●	●	●	●
Jaguar XF	2010-2011	Supercharged V8. 5.0L engine	DACMC - Digital audio control module C	●	●	●	●
Jaguar XF	2010-2011	Supercharged V8. 5.0L engine	DCSM - Driver's climate seat module	●	●	●	●
Jaguar XF	2010-2011	Supercharged V8. 5.0L engine	DDM - Driver's door module	●	●	●	●
Jaguar XF	2010-2011	Supercharged V8. 5.0L engine	DSM - Driver's seat module	●	●	●	●
Jaguar XF	2010-2011	Supercharged V8. 5.0L engine	front)	●	●	●	●
Jaguar XF	2010-2011	Supercharged V8. 5.0L engine	FLR - Forward looking radar	●	○	●	○
Jaguar XF	2010-2011	Supercharged V8. 5.0L engine	FSJB - Central junction box (body control module)	●	●	●	●
Jaguar XF	2010-2011	Supercharged V8. 5.0L engine	GSM - Gear shift module	●	●	●	●
Jaguar XF	2010-2011	Supercharged V8. 5.0L engine	HCM - Headlamp control module	●	●	●	●
Jaguar XF	2010-2011	Supercharged V8. 5.0L engine	HVAC - Heating ventilation and air conditioning control module	●	●	●	●
Jaguar XF	2010-2011	Supercharged V8. 5.0L engine	ICM - Infotainment control module.	●	●	●	●
Jaguar XF	2010-2011	Supercharged V8. 5.0L engine	ICP - Integrated control panel	●	●	●	●
Jaguar XF	2010-2011	Supercharged V8. 5.0L engine	ICS - Impact classification system	●	●	●	●
Jaguar XF	2010-2011	Supercharged V8. 5.0L engine	IPC - Instrument cluster control module.	●	●	●	●
Jaguar XF	2010-2011	Supercharged V8. 5.0L engine	KVM - Keyless vehicle module	●	●	●	●
Jaguar XF	2010-2011	Supercharged V8. 5.0L engine	NCM - Navigation control module	●	●	●	●
Jaguar XF	2010-2011	Supercharged V8. 5.0L engine	OCS - Restraints occupant classification system module	●	●	●	●
Jaguar XF	2010-2011	Supercharged V8. 5.0L engine	PAM - Parking assist control module	●	●	●	●
Jaguar XF	2010-2011	Supercharged V8. 5.0L engine	PBM - Parking brake control module	●	●	●	●
Jaguar XF	2010-2011	Supercharged V8. 5.0L engine	PCM - Powertrain control module	●	●	●	●
Jaguar XF	2010-2011	Supercharged V8. 5.0L engine	PDM - Passenger's door module	●	●	●	●
Jaguar XF	2010-2011	Supercharged V8. 5.0L engine	RCM - Restraints control module	●	●	●	●
Jaguar XF	2010-2011	Supercharged V8. 5.0L engine	RDCM - Rear differential control module	●	●	●	●
Jaguar XF	2010-2011	Supercharged V8. 5.0L engine	RSJB - Auxiliary junction box (body control module B)	●	●	●	●
Jaguar XF	2010-2011	Supercharged V8. 5.0L engine	SODL - Side object detection control module - Left	●	●	●	●
Jaguar XF	2010-2011	Supercharged V8. 5.0L engine	SODR - Side object detection control module - Right	●	●	●	●
Jaguar XF	2010-2011	Supercharged V8. 5.0L engine	SRM - Satellite audio unit module.	●	●	●	●
Jaguar XF	2010-2011	Supercharged V8. 5.0L engine	TCM - Transmission control module	●	●	●	●
Jaguar XF	2010-2011	Supercharged V8. 5.0L engine	TEL - Cellular telephone control module	●	●	●	●
Jaguar XF	2010-2011	Supercharged V8. 5.0L engine	TPM - Tire pressure monitor module	●	●	●	●
Jaguar XF	2010-2011	Supercharged V8. 5.0L engine	TVM - Television module	●	●	●	●
Jaguar XF	2010-2011	Supercharged V8. 5.0L engine	VIM - Vehicle immobilizer control module	●	●	●	●
Jaguar XF	2012	Diesel I4 2.2L engine	AAM - Audio amplifier module	●	●	●	●
Jaguar XF	2012	Diesel I4 2.2L engine	ABS - ABS control module	●	●	●	●
Jaguar XF	2012	Diesel I4 2.2L engine	ACM - Audio front control module	●	●	●	●

Vehchile model	Year	Engine Type/Chassis Number	System Name	Information	Read TroubleCode	Clear TroubleCode	Read DataStream
Jaguar XF	2012	Diesel I4 2.2L engine	CCM - Speed control module	●	●	●	●
Jaguar XF	2012	Diesel I4 2.2L engine	DABM - Digital audio broadcast module	●	●	●	●
Jaguar XF	2012	Diesel I4 2.2L engine	DDM - Driver's door module	●	●	●	●
Jaguar XF	2012	Diesel I4 2.2L engine	DSM - Driver's seat module	●	●	●	●
Jaguar XF	2012	Diesel I4 2.2L engine	front)	●	●	●	●
Jaguar XF	2012	Diesel I4 2.2L engine	panel)	●	●	●	●
Jaguar XF	2012	Diesel I4 2.2L engine	FSJB - Central junction box (body control module)	●	●	●	●
Jaguar XF	2012	Diesel I4 2.2L engine	GSM - Gear shift module	●	●	●	●
Jaguar XF	2012	Diesel I4 2.2L engine	GWM - Gateway module	●	●	●	●
Jaguar XF	2012	Diesel I4 2.2L engine	HCM - Headlamp control module	●	●	●	●
Jaguar XF	2012	Diesel I4 2.2L engine	HCMB - Headlamp control module 'B'	●	●	●	●
Jaguar XF	2012	Diesel I4 2.2L engine	HVAC - Heating ventilation and air conditioning control module	●	●	●	●
Jaguar XF	2012	Diesel I4 2.2L engine	IPC - Instrument cluster control module.	●	●	●	●
Jaguar XF	2012	Diesel I4 2.2L engine	NCM - Navigation control module	●	●	●	●
Jaguar XF	2012	Diesel I4 2.2L engine	OCS - Restraints occupant classification system module	●	●	●	●
Jaguar XF	2012	Diesel I4 2.2L engine	PAM - Parking assist control module	●	●	●	●
Jaguar XF	2012	Diesel I4 2.2L engine	PBM - Parking brake control module	●	●	●	●
Jaguar XF	2012	Diesel I4 2.2L engine	PCM - Powertrain control module	●	●	●	●
Jaguar XF	2012	Diesel I4 2.2L engine	PDM - Passenger's door module	●	●	●	●
Jaguar XF	2012	Diesel I4 2.2L engine	PSM - Passenger's seat module	●	●	●	●
Jaguar XF	2012	Diesel I4 2.2L engine	RCM - Restraints control module	●	●	●	●
Jaguar XF	2012	Diesel I4 2.2L engine	RDCM - Rear differential control module	●	●	●	●
Jaguar XF	2012	Diesel I4 2.2L engine	RFA - Keyless vehicle module	●	●	●	●
Jaguar XF	2012	Diesel I4 2.2L engine	RSJB - Auxiliary junction box (body control module B)	●	●	●	●
Jaguar XF	2012	Diesel I4 2.2L engine	SCME - Driver's climate seat module	●	●	●	●
Jaguar XF	2012	Diesel I4 2.2L engine	SODL - Side object detection control module - Left	●	●	●	●
Jaguar XF	2012	Diesel I4 2.2L engine	SODR - Side object detection control module - Right	●	●	●	●
Jaguar XF	2012	Diesel I4 2.2L engine	SPMA - Safety belt pretensioner control module A - drivers side	●	●	●	●
Jaguar XF	2012	Diesel I4 2.2L engine	SPMB - Safety belt pretensioner control module B - passengers side	●	●	●	●
Jaguar XF	2012	Diesel I4 2.2L engine	SRM - Satellite audio unit module.	●	●	●	●
Jaguar XF	2012	Diesel I4 2.2L engine	SUMB - Adaptive damping control module	●	●	●	●
Jaguar XF	2012	Diesel I4 2.2L engine	TCM - Transmission control module	●	●	●	●
Jaguar XF	2012	Diesel I4 2.2L engine	TPM - Tire pressure monitor module	●	●	●	●
Jaguar XF	2012	Diesel I4 2.2L engine	TVM - Television module	●	●	●	●
Jaguar XF	2012	Diesel I4 2.2L engine	VIM - Vehicle immobilizer control module	●	●	●	●
Jaguar XF	2012	Diesel V6	AAM - Audio amplifier module	●	●	●	●
Jaguar XF	2012	Diesel V6	ABS - ABS control module	●	●	●	●
Jaguar XF	2012	Diesel V6	ACM - Audio front control module	●	●	●	●
Jaguar XF	2012	Diesel V6	CCM - Speed control module	●	●	●	●
Jaguar XF	2012	Diesel V6	DABM - Digital audio broadcast module	●	●	●	●
Jaguar XF	2012	Diesel V6	DDM - Driver's door module	●	●	●	●
Jaguar XF	2012	Diesel V6	DSM - Driver's seat module	●	●	●	●
Jaguar XF	2012	Diesel V6	front)	●	●	●	●
Jaguar XF	2012	Diesel V6	panel)	●	●	●	●
Jaguar XF	2012	Diesel V6	FSJB - Central junction box (body control module)	●	●	●	●
Jaguar XF	2012	Diesel V6	GSM - Gear shift module	●	●	●	●
Jaguar XF	2012	Diesel V6	GWM - Gateway module	●	●	●	●
Jaguar XF	2012	Diesel V6	HCM - Headlamp control module	●	●	●	●
Jaguar XF	2012	Diesel V6	HCMB - Headlamp control module 'B'	●	●	●	●
Jaguar XF	2012	Diesel V6	HVAC - Heating ventilation and air conditioning control module	●	●	●	●
Jaguar XF	2012	Diesel V6	IPC - Instrument cluster control module.	●	●	●	●
Jaguar XF	2012	Diesel V6	NCM - Navigation control module	●	●	●	●
Jaguar XF	2012	Diesel V6	OCS - Restraints occupant classification system module	●	●	●	●
Jaguar XF	2012	Diesel V6	PAM - Parking assist control module	●	●	●	●
Jaguar XF	2012	Diesel V6	PBM - Parking brake control module	●	●	●	●
Jaguar XF	2012	Diesel V6	PCM - Powertrain control module	●	●	●	●
Jaguar XF	2012	Diesel V6	PDM - Passenger's door module	●	●	●	●
Jaguar XF	2012	Diesel V6	PSM - Passenger's seat module	●	●	●	●
Jaguar XF	2012	Diesel V6	RCM - Restraints control module	●	●	●	●
Jaguar XF	2012	Diesel V6	RDCM - Rear differential control module	●	●	●	●
Jaguar XF	2012	Diesel V6	RFA - Keyless vehicle module	●	●	●	●
Jaguar XF	2012	Diesel V6	RSJB - Auxiliary junction box (body control module B)	●	●	●	●
Jaguar XF	2012	Diesel V6	SCME - Driver's climate seat module	●	●	●	●
Jaguar XF	2012	Diesel V6	SODL - Side object detection control module - Left	●	●	●	●
Jaguar XF	2012	Diesel V6	SODR - Side object detection control module - Right	●	●	●	●
Jaguar XF	2012	Diesel V6	SPMA - Safety belt pretensioner control module A - drivers side	●	●	●	●
Jaguar XF	2012	Diesel V6	SPMB - Safety belt pretensioner control module B - passengers side	●	●	●	●
Jaguar XF	2012	Diesel V6	SRM - Satellite audio unit module.	●	●	●	●
Jaguar XF	2012	Diesel V6	SUMB - Adaptive damping control module	●	●	●	●
Jaguar XF	2012	Diesel V6	TCM - Transmission control module	●	●	●	●
Jaguar XF	2012	Diesel V6	TPM - Tire pressure monitor module	●	●	●	●
Jaguar XF	2012	Diesel V6	TVM - Television module	●	●	●	●
Jaguar XF	2012	Diesel V6	VIM - Vehicle immobilizer control module	●	●	●	●
Jaguar XF	2012	Normally aspirated V6	AAM - Audio amplifier module	●	●	●	●
Jaguar XF	2012	Normally aspirated V6	ABS - ABS control module	●	●	●	●
Jaguar XF	2012	Normally aspirated V6	ACM - Audio front control module	●	●	●	●
Jaguar XF	2012	Normally aspirated V6	CCM - Speed control module	●	●	●	●
Jaguar XF	2012	Normally aspirated V6	DABM - Digital audio broadcast module	●	●	●	●
Jaguar XF	2012	Normally aspirated V6	DDM - Driver's door module	●	●	●	●
Jaguar XF	2012	Normally aspirated V6	DSM - Driver's seat module	●	●	●	●
Jaguar XF	2012	Normally aspirated V6	front)	●	●	●	●
Jaguar XF	2012	Normally aspirated V6	panel)	●	●	●	●
Jaguar XF	2012	Normally aspirated V6	FSJB - Central junction box (body control module)	●	●	●	●
Jaguar XF	2012	Normally aspirated V6	GSM - Gear shift module	●	●	●	●
Jaguar XF	2012	Normally aspirated V6	GWM - Gateway module	●	●	●	●
Jaguar XF	2012	Normally aspirated V6	HCM - Headlamp control module	●	●	●	●
Jaguar XF	2012	Normally aspirated V6	HCMB - Headlamp control module 'B'	●	●	●	●

Vehicle model	Year	Engine Type/Chassis Number	System Name	Information	Read TroubleCode	Clear TroubleCode	Read DataStream
Jaguar XF	2012	Normally aspirated V6	HVAC - Heating ventilation and air conditioning control module	●	●	●	●
Jaguar XF	2012	Normally aspirated V6	IPC - Instrument cluster control module.	●	●	●	●
Jaguar XF	2012	Normally aspirated V6	NCM - Navigation control module	●	●	●	●
Jaguar XF	2012	Normally aspirated V6	OCS - Restraints occupant classification system module	●	●	●	●
Jaguar XF	2012	Normally aspirated V6	PAM - Parking assist control module	●	●	●	●
Jaguar XF	2012	Normally aspirated V6	PBM - Parking brake control module	●	●	●	●
Jaguar XF	2012	Normally aspirated V6	PCM - Powertrain control module	●	●	●	●
Jaguar XF	2012	Normally aspirated V6	PDM - Passenger's door module	●	●	●	●
Jaguar XF	2012	Normally aspirated V6	PSM - Passenger's seat module	●	●	●	●
Jaguar XF	2012	Normally aspirated V6	RCM - Restraints control module	●	●	●	●
Jaguar XF	2012	Normally aspirated V6	RDCM - Rear differential control module	●	●	●	●
Jaguar XF	2012	Normally aspirated V6	RFA - Keyless vehicle module	●	●	●	●
Jaguar XF	2012	Normally aspirated V6	RSJB - Auxiliary junction box (body control module B)	●	●	●	●
Jaguar XF	2012	Normally aspirated V6	SCME - Driver's climate seat module	●	●	●	●
Jaguar XF	2012	Normally aspirated V6	SODL - Side object detection control module - Left	●	●	●	●
Jaguar XF	2012	Normally aspirated V6	SODR - Side object detection control module - Right	●	●	●	●
Jaguar XF	2012	Normally aspirated V6	SPMA - Safety belt pretensioner control module A - drivers side	●	●	●	●
Jaguar XF	2012	Normally aspirated V6	SPMB - Safety belt pretensioner control module B - passengers side	●	●	●	●
Jaguar XF	2012	Normally aspirated V6	SRM - Satellite audio unit module.	●	●	●	●
Jaguar XF	2012	Normally aspirated V6	SUMB - Adaptive damping control module	●	●	●	●
Jaguar XF	2012	Normally aspirated V6	TCM - Transmission control module	●	●	●	●
Jaguar XF	2012	Normally aspirated V6	TPM - Tire pressure monitor module	●	●	●	●
Jaguar XF	2012	Normally aspirated V6	TVM - Television module	●	●	●	●
Jaguar XF	2012	Normally aspirated V6	VIM - Vehicle immobilizer control module	●	●	●	●
Jaguar XF	2012	Normally aspirated V8 5.0L engine	AAM - Audio amplifier module	●	●	●	●
Jaguar XF	2012	Normally aspirated V8 5.0L engine	ABS - ABS control module	●	●	●	●
Jaguar XF	2012	Normally aspirated V8 5.0L engine	ACM - Audio front control module	●	●	●	●
Jaguar XF	2012	Normally aspirated V8 5.0L engine	CCM - Speed control module	●	●	●	●
Jaguar XF	2012	Normally aspirated V8 5.0L engine	DABM - Digital audio broadcast module	●	●	●	●
Jaguar XF	2012	Normally aspirated V8 5.0L engine	DDM - Driver's door module	●	●	●	●
Jaguar XF	2012	Normally aspirated V8 5.0L engine	DSM - Driver's seat module	●	●	●	●
Jaguar XF	2012	Normally aspirated V8 5.0L engine	front)	●	●	●	●
Jaguar XF	2012	Normally aspirated V8 5.0L engine	panel)	●	●	●	●
Jaguar XF	2012	Normally aspirated V8 5.0L engine	FSJB - Central junction box (body control module)	●	●	●	●
Jaguar XF	2012	Normally aspirated V8 5.0L engine	GSM - Gear shift module	●	●	●	●
Jaguar XF	2012	Normally aspirated V8 5.0L engine	GWM - Gateway module	●	●	●	●
Jaguar XF	2012	Normally aspirated V8 5.0L engine	HCM - Headlamp control module	●	●	●	●
Jaguar XF	2012	Normally aspirated V8 5.0L engine	HCMB - Headlamp control module 'B'	●	●	●	●
Jaguar XF	2012	Normally aspirated V8 5.0L engine	HVAC - Heating ventilation and air conditioning control module	●	●	●	●
Jaguar XF	2012	Normally aspirated V8 5.0L engine	IPC - Instrument cluster control module.	●	●	●	●
Jaguar XF	2012	Normally aspirated V8 5.0L engine	NCM - Navigation control module	●	●	●	●
Jaguar XF	2012	Normally aspirated V8 5.0L engine	OCS - Restraints occupant classification system module	●	●	●	●
Jaguar XF	2012	Normally aspirated V8 5.0L engine	PAM - Parking assist control module	●	●	●	●
Jaguar XF	2012	Normally aspirated V8 5.0L engine	PBM - Parking brake control module	●	●	●	●
Jaguar XF	2012	Normally aspirated V8 5.0L engine	PCM - Powertrain control module	●	●	●	●
Jaguar XF	2012	Normally aspirated V8 5.0L engine	PDM - Passenger's door module	●	●	●	●
Jaguar XF	2012	Normally aspirated V8 5.0L engine	PSM - Passenger's seat module	●	●	●	●
Jaguar XF	2012	Normally aspirated V8 5.0L engine	RCM - Restraints control module	●	●	●	●
Jaguar XF	2012	Normally aspirated V8 5.0L engine	RDCM - Rear differential control module	●	●	●	●
Jaguar XF	2012	Normally aspirated V8 5.0L engine	RFA - Keyless vehicle module	●	●	●	●
Jaguar XF	2012	Normally aspirated V8 5.0L engine	RSJB - Auxiliary junction box (body control module B)	●	●	●	●
Jaguar XF	2012	Normally aspirated V8 5.0L engine	SCME - Driver's climate seat module	●	●	●	●
Jaguar XF	2012	Normally aspirated V8 5.0L engine	SODL - Side object detection control module - Left	●	●	●	●
Jaguar XF	2012	Normally aspirated V8 5.0L engine	SODR - Side object detection control module - Right	●	●	●	●
Jaguar XF	2012	Normally aspirated V8 5.0L engine	SPMA - Safety belt pretensioner control module A - drivers side	●	●	●	●
Jaguar XF	2012	Normally aspirated V8 5.0L engine	SPMB - Safety belt pretensioner control module B - passengers side	●	●	●	●
Jaguar XF	2012	Normally aspirated V8 5.0L engine	SRM - Satellite audio unit module.	●	●	●	●
Jaguar XF	2012	Normally aspirated V8 5.0L engine	SUMB - Adaptive damping control module	●	●	●	●
Jaguar XF	2012	Normally aspirated V8 5.0L engine	TCM - Transmission control module	●	●	●	●
Jaguar XF	2012	Normally aspirated V8 5.0L engine	TPM - Tire pressure monitor module	●	●	●	●
Jaguar XF	2012	Normally aspirated V8 5.0L engine	TVM - Television module	●	●	●	●
Jaguar XF	2012	Normally aspirated V8 5.0L engine	VIM - Vehicle immobilizer control module	●	●	●	●
Jaguar XF	2012	Supercharged V8. 5.0L engine	AAM - Audio amplifier module	●	●	●	●
Jaguar XF	2012	Supercharged V8. 5.0L engine	ABS - ABS control module	●	●	●	●
Jaguar XF	2012	Supercharged V8. 5.0L engine	ACM - Audio front control module	●	●	●	●
Jaguar XF	2012	Supercharged V8. 5.0L engine	CCM - Speed control module	●	●	●	●
Jaguar XF	2012	Supercharged V8. 5.0L engine	DABM - Digital audio broadcast module	●	●	●	●
Jaguar XF	2012	Supercharged V8. 5.0L engine	DDM - Driver's door module	●	●	●	●
Jaguar XF	2012	Supercharged V8. 5.0L engine	DSM - Driver's seat module	●	●	●	●
Jaguar XF	2012	Supercharged V8. 5.0L engine	front)	●	●	●	●
Jaguar XF	2012	Supercharged V8. 5.0L engine	panel)	●	●	●	●
Jaguar XF	2012	Supercharged V8. 5.0L engine	FSJB - Central junction box (body control module)	●	●	●	●
Jaguar XF	2012	Supercharged V8. 5.0L engine	GSM - Gear shift module	●	●	●	●
Jaguar XF	2012	Supercharged V8. 5.0L engine	GWM - Gateway module	●	●	●	●
Jaguar XF	2012	Supercharged V8. 5.0L engine	HCM - Headlamp control module	●	●	●	●
Jaguar XF	2012	Supercharged V8. 5.0L engine	HCMB - Headlamp control module 'B'	●	●	●	●
Jaguar XF	2012	Supercharged V8. 5.0L engine	HVAC - Heating ventilation and air conditioning control module	●	●	●	●
Jaguar XF	2012	Supercharged V8. 5.0L engine	IPC - Instrument cluster control module.	●	●	●	●
Jaguar XF	2012	Supercharged V8. 5.0L engine	NCM - Navigation control module	●	●	●	●
Jaguar XF	2012	Supercharged V8. 5.0L engine	OCS - Restraints occupant classification system module	●	●	●	●
Jaguar XF	2012	Supercharged V8. 5.0L engine	PAM - Parking assist control module	●	●	●	●
Jaguar XF	2012	Supercharged V8. 5.0L engine	PBM - Parking brake control module	●	●	●	●
Jaguar XF	2012	Supercharged V8. 5.0L engine	PCM - Powertrain control module	●	●	●	●
Jaguar XF	2012	Supercharged V8. 5.0L engine	PDM - Passenger's door module	●	●	●	●
Jaguar XF	2012	Supercharged V8. 5.0L engine	PSM - Passenger's seat module	●	●	●	●
Jaguar XF	2012	Supercharged V8. 5.0L engine	RCM - Restraints control module	●	●	●	●
Jaguar XF	2012	Supercharged V8. 5.0L engine	RDCM - Rear differential control module	●	●	●	●



Vehcile model	Year	Engine Type/Chassis Number	System Name	Information	Read TroubleCode	Clear TroubleCode	Read DataStream
Jaguar XF	2012	Supercharged V8. 5.0L engine	RFA - Keyless vehicle module	●	●	●	●
Jaguar XF	2012	Supercharged V8. 5.0L engine	RSJB - Auxiliary junction box (body control module B)	●	●	●	●
Jaguar XF	2012	Supercharged V8. 5.0L engine	SCME - Driver's climate seat module	●	●	●	●
Jaguar XF	2012	Supercharged V8. 5.0L engine	SODL - Side object detection control module - Left	●	●	●	●
Jaguar XF	2012	Supercharged V8. 5.0L engine	SODR - Side object detection control module - Right	●	●	●	●
Jaguar XF	2012	Supercharged V8. 5.0L engine	SPMA - Safety belt pretensioner control module A - drivers side	●	●	●	●
Jaguar XF	2012	Supercharged V8. 5.0L engine	SPMB - Safety belt pretensioner control module B - passengers side	●	●	●	●
Jaguar XF	2012	Supercharged V8. 5.0L engine	SRM - Satellite audio unit module.	●	●	●	●
Jaguar XF	2012	Supercharged V8. 5.0L engine	SUMB - Adaptive damping control module	●	●	●	●
Jaguar XF	2012	Supercharged V8. 5.0L engine	TCM - Transmission control module	●	●	●	●
Jaguar XF	2012	Supercharged V8. 5.0L engine	TPM - Tire pressure monitor module	●	●	●	●
Jaguar XF	2012	Supercharged V8. 5.0L engine	TVM - Television module	●	●	●	●
Jaguar XF	2012	Supercharged V8. 5.0L engine	VIM - Vehicle immobilizer control module	●	●	●	●
Jaguar XF	2013-2015	Diesel I4 2.2L engine	AAM - Audio amplifier module	●	●	●	●
Jaguar XF	2013-2015	Diesel I4 2.2L engine	ABS - ABS control module	●	●	●	●
Jaguar XF	2013-2015	Diesel I4 2.2L engine	ACM - Audio front control module	●	●	●	●
Jaguar XF	2013-2015	Diesel I4 2.2L engine	BCM - Central junction box (body control module)	●	●	●	●
Jaguar XF	2013-2015	Diesel I4 2.2L engine	BCMB - Auxiliary junction box (body control module B)	●	●	●	●
Jaguar XF	2013-2015	Diesel I4 2.2L engine	CCM - Speed control module	●	●	●	●
Jaguar XF	2013-2015	Diesel I4 2.2L engine	CHCM - Chassis control module	●	●	●	●
Jaguar XF	2013-2015	Diesel I4 2.2L engine	DABM - Digital audio broadcast module	●	●	●	●
Jaguar XF	2013-2015	Diesel I4 2.2L engine	DDM - Driver's door module	●	●	●	●
Jaguar XF	2013-2015	Diesel I4 2.2L engine	DSM - Driver's seat module	●	●	●	●
Jaguar XF	2013-2015	Diesel I4 2.2L engine	front)	●	●	●	●
Jaguar XF	2013-2015	Diesel I4 2.2L engine	panel)	●	●	●	●
Jaguar XF	2013-2015	Diesel I4 2.2L engine	FSJB - Central junction box (body control module)	●	●	●	●
Jaguar XF	2013-2015	Diesel I4 2.2L engine	GSM - Gear shift module	●	●	●	●
Jaguar XF	2013-2015	Diesel I4 2.2L engine	GWM - Gateway module	●	●	●	●
Jaguar XF	2013-2015	Diesel I4 2.2L engine	HCM - Headlamp control module	●	●	●	●
Jaguar XF	2013-2015	Diesel I4 2.2L engine	HCMB - Headlamp control module B	●	●	●	●
Jaguar XF	2013-2015	Diesel I4 2.2L engine	HVAC - Heating ventilation and air conditioning control module	●	●	●	●
Jaguar XF	2013-2015	Diesel I4 2.2L engine	IPC - Instrument cluster control module.	●	●	●	●
Jaguar XF	2013-2015	Diesel I4 2.2L engine	NCM - Navigation control module	●	●	●	●
Jaguar XF	2013-2015	Diesel I4 2.2L engine	OCS - Restraints occupant classification system module	●	●	●	●
Jaguar XF	2013-2015	Diesel I4 2.2L engine	PAM - Parking assist control module	●	●	●	●
Jaguar XF	2013-2015	Diesel I4 2.2L engine	PBM - Parking brake control module	●	●	●	●
Jaguar XF	2013-2015	Diesel I4 2.2L engine	PCM - Powertrain control module	●	●	●	●
Jaguar XF	2013-2015	Diesel I4 2.2L engine	PDM - Passenger's door module	●	●	●	●
Jaguar XF	2013-2015	Diesel I4 2.2L engine	PSM - Passenger's seat module	●	●	●	●
Jaguar XF	2013-2015	Diesel I4 2.2L engine	RCM - Restraints control module	●	●	●	●
Jaguar XF	2013-2015	Diesel I4 2.2L engine	RDCM - Rear differential control module	●	●	●	●
Jaguar XF	2013-2015	Diesel I4 2.2L engine	RFA - Keyless vehicle module	●	●	●	●
Jaguar XF	2013-2015	Diesel I4 2.2L engine	RGTM - Rear gate / trunk module	●	●	●	●
Jaguar XF	2013-2015	Diesel I4 2.2L engine	RSJB - Auxiliary junction box (body control module B)	●	●	●	●
Jaguar XF	2013-2015	Diesel I4 2.2L engine	SCME - Driver's climate seat module	●	●	●	●
Jaguar XF	2013-2015	Diesel I4 2.2L engine	SODL - Side object detection control module - Left	●	●	●	●
Jaguar XF	2013-2015	Diesel I4 2.2L engine	SODR - Side object detection control module - Right	●	●	●	●
Jaguar XF	2013-2015	Diesel I4 2.2L engine	SPMA - Safety belt pretensioner control module A - drivers side	●	●	●	●
Jaguar XF	2013-2015	Diesel I4 2.2L engine	SPMB - Safety belt pretensioner control module B - passengers side	●	●	●	●
Jaguar XF	2013-2015	Diesel I4 2.2L engine	SRM - Satellite audio unit module.	●	●	●	●
Jaguar XF	2013-2015	Diesel I4 2.2L engine	SUMB - Adaptive damping control module	●	●	●	●
Jaguar XF	2013-2015	Diesel I4 2.2L engine	TCCM - Transfer case control module	●	●	●	●
Jaguar XF	2013-2015	Diesel I4 2.2L engine	TCM - Transmission control module	●	●	●	●
Jaguar XF	2013-2015	Diesel I4 2.2L engine	TPM - Tire pressure monitor module	●	●	●	●
Jaguar XF	2013-2015	Diesel I4 2.2L engine	TVM - Television module	●	●	●	●
Jaguar XF	2013-2015	Diesel I4 2.2L engine	VIM - Vehicle immobilizer control module	●	●	●	●
Jaguar XF	2013-2015	Diesel V6	AAM - Audio amplifier module	●	●	●	●
Jaguar XF	2013-2015	Diesel V6	ABS - ABS control module	●	●	●	●
Jaguar XF	2013-2015	Diesel V6	ACM - Audio front control module	●	●	●	●
Jaguar XF	2013-2015	Diesel V6	BCM - Central junction box (body control module)	●	●	●	●
Jaguar XF	2013-2015	Diesel V6	BCMB - Auxiliary junction box (body control module B)	●	●	●	●
Jaguar XF	2013-2015	Diesel V6	CCM - Speed control module	●	●	●	●
Jaguar XF	2013-2015	Diesel V6	CHCM - Chassis control module	●	●	●	●
Jaguar XF	2013-2015	Diesel V6	DABM - Digital audio broadcast module	●	●	●	●
Jaguar XF	2013-2015	Diesel V6	DDM - Driver's door module	●	●	●	●
Jaguar XF	2013-2015	Diesel V6	DSM - Driver's seat module	●	●	●	●
Jaguar XF	2013-2015	Diesel V6	front)	●	●	●	●
Jaguar XF	2013-2015	Diesel V6	panel)	●	●	●	●
Jaguar XF	2013-2015	Diesel V6	FSJB - Central junction box (body control module)	●	●	●	●
Jaguar XF	2013-2015	Diesel V6	GSM - Gear shift module	●	●	●	●
Jaguar XF	2013-2015	Diesel V6	GWM - Gateway module	●	●	●	●
Jaguar XF	2013-2015	Diesel V6	HCM - Headlamp control module	●	●	●	●
Jaguar XF	2013-2015	Diesel V6	HCMB - Headlamp control module B	●	●	●	●
Jaguar XF	2013-2015	Diesel V6	HVAC - Heating ventilation and air conditioning control module	●	●	●	●
Jaguar XF	2013-2015	Diesel V6	IPC - Instrument cluster control module.	●	●	●	●
Jaguar XF	2013-2015	Diesel V6	NCM - Navigation control module	●	●	●	●
Jaguar XF	2013-2015	Diesel V6	OCS - Restraints occupant classification system module	●	●	●	●
Jaguar XF	2013-2015	Diesel V6	PAM - Parking assist control module	●	●	●	●
Jaguar XF	2013-2015	Diesel V6	PBM - Parking brake control module	●	●	●	●
Jaguar XF	2013-2015	Diesel V6	PCM - Powertrain control module	●	●	●	●
Jaguar XF	2013-2015	Diesel V6	PDM - Passenger's door module	●	●	●	●
Jaguar XF	2013-2015	Diesel V6	PSM - Passenger's seat module	●	●	●	●
Jaguar XF	2013-2015	Diesel V6	RCM - Restraints control module	●	●	●	●
Jaguar XF	2013-2015	Diesel V6	RDCM - Rear differential control module	●	●	●	●
Jaguar XF	2013-2015	Diesel V6	RFA - Keyless vehicle module	●	●	●	●
Jaguar XF	2013-2015	Diesel V6	RGTM - Rear gate / trunk module	●	●	●	●
Jaguar XF	2013-2015	Diesel V6	RSJB - Auxiliary junction box (body control module B)	●	●	●	●

Vehcile model	Year	Engine Type/Chassis Number	System Name	Information	Read TroubleCode	Clear TroubleCode	Read DataStream
Jaguar XF	2013-2015	Diesel V6	SCME - Driver's climate seat module	●	●	●	●
Jaguar XF	2013-2015	Diesel V6	SODL - Side object detection control module - Left	●	●	●	●
Jaguar XF	2013-2015	Diesel V6	SODR - Side object detection control module - Right	●	●	●	●
Jaguar XF	2013-2015	Diesel V6	SPMA - Safety belt pretensioner control module A - drivers side	●	●	●	●
Jaguar XF	2013-2015	Diesel V6	SPMB - Safety belt pretensioner control module B - passengers side	●	●	●	●
Jaguar XF	2013-2015	Diesel V6	SRM - Satellite audio unit module.	●	●	●	●
Jaguar XF	2013-2015	Diesel V6	SUMB - Adaptive damping control module	●	●	●	●
Jaguar XF	2013-2015	Diesel V6	TCCM - Transfer case control module	●	●	●	●
Jaguar XF	2013-2015	Diesel V6	TCM - Transmission control module	●	●	●	●
Jaguar XF	2013-2015	Diesel V6	TPM - Tire pressure monitor module	●	●	●	●
Jaguar XF	2013-2015	Diesel V6	TVM - Television module	●	●	●	●
Jaguar XF	2013-2015	Diesel V6	VIM - Vehicle immobilizer control module	●	●	●	●
Jaguar XF	2013-2015	GTDI 2.0L engine	AAM - Audio amplifier module	●	●	●	●
Jaguar XF	2013-2015	GTDI 2.0L engine	ABS - ABS control module	●	●	●	●
Jaguar XF	2013-2015	GTDI 2.0L engine	ACM - Audio front control module	●	●	●	●
Jaguar XF	2013-2015	GTDI 2.0L engine	BCM - Central junction box (body control module)	●	●	●	●
Jaguar XF	2013-2015	GTDI 2.0L engine	BCMB - Auxiliary junction box (body control module B)	●	●	●	●
Jaguar XF	2013-2015	GTDI 2.0L engine	CCM - Speed control module	●	●	●	●
Jaguar XF	2013-2015	GTDI 2.0L engine	CHCM - Chassis control module	●	●	●	●
Jaguar XF	2013-2015	GTDI 2.0L engine	DABM - Digital audio broadcast module	●	●	●	●
Jaguar XF	2013-2015	GTDI 2.0L engine	DDM - Driver's door module	●	●	●	●
Jaguar XF	2013-2015	GTDI 2.0L engine	DSM - Driver's seat module	●	●	●	●
Jaguar XF	2013-2015	GTDI 2.0L engine	front)	●	●	●	●
Jaguar XF	2013-2015	GTDI 2.0L engine	panel)	●	●	●	●
Jaguar XF	2013-2015	GTDI 2.0L engine	FSJB - Central junction box (body control module)	●	●	●	●
Jaguar XF	2013-2015	GTDI 2.0L engine	GSM - Gear shift module	●	●	●	●
Jaguar XF	2013-2015	GTDI 2.0L engine	GWM - Gateway module	●	●	●	●
Jaguar XF	2013-2015	GTDI 2.0L engine	HCM - Headlamp control module	●	●	●	●
Jaguar XF	2013-2015	GTDI 2.0L engine	HCMB - Headlamp control module B	●	●	●	●
Jaguar XF	2013-2015	GTDI 2.0L engine	HVAC - Heating ventilation and air conditioning control module	●	●	●	●
Jaguar XF	2013-2015	GTDI 2.0L engine	IPC - Instrument cluster control module.	●	●	●	●
Jaguar XF	2013-2015	GTDI 2.0L engine	NCM - Navigation control module	●	●	●	●
Jaguar XF	2013-2015	GTDI 2.0L engine	OCS - Restraints occupant classification system module	●	●	●	●
Jaguar XF	2013-2015	GTDI 2.0L engine	PAM - Parking assist control module	●	●	●	●
Jaguar XF	2013-2015	GTDI 2.0L engine	PBM - Parking brake control module	●	●	●	●
Jaguar XF	2013-2015	GTDI 2.0L engine	PCM - Powertrain control module	●	●	●	●
Jaguar XF	2013-2015	GTDI 2.0L engine	PDM - Passenger's door module	●	●	●	●
Jaguar XF	2013-2015	GTDI 2.0L engine	PSM - Passenger's seat module	●	●	●	●
Jaguar XF	2013-2015	GTDI 2.0L engine	RCM - Restraints control module	●	●	●	●
Jaguar XF	2013-2015	GTDI 2.0L engine	RDCM - Rear differential control module	●	●	●	●
Jaguar XF	2013-2015	GTDI 2.0L engine	RFA - Keyless vehicle module	●	●	●	●
Jaguar XF	2013-2015	GTDI 2.0L engine	RGTM - Rear gate / trunk module	●	●	●	●
Jaguar XF	2013-2015	GTDI 2.0L engine	RSJB - Auxiliary junction box (body control module B)	●	●	●	●
Jaguar XF	2013-2015	GTDI 2.0L engine	SCME - Driver's climate seat module	●	●	●	●
Jaguar XF	2013-2015	GTDI 2.0L engine	SODL - Side object detection control module - Left	●	●	●	●
Jaguar XF	2013-2015	GTDI 2.0L engine	SODR - Side object detection control module - Right	●	●	●	●
Jaguar XF	2013-2015	GTDI 2.0L engine	SPMA - Safety belt pretensioner control module A - drivers side	●	●	●	●
Jaguar XF	2013-2015	GTDI 2.0L engine	SPMB - Safety belt pretensioner control module B - passengers side	●	●	●	●
Jaguar XF	2013-2015	GTDI 2.0L engine	SRM - Satellite audio unit module.	●	●	●	●
Jaguar XF	2013-2015	GTDI 2.0L engine	SUMB - Adaptive damping control module	●	●	●	●
Jaguar XF	2013-2015	GTDI 2.0L engine	TCCM - Transfer case control module	●	●	●	●
Jaguar XF	2013-2015	GTDI 2.0L engine	TCM - Transmission control module	●	●	●	●
Jaguar XF	2013-2015	GTDI 2.0L engine	TPM - Tire pressure monitor module	●	●	●	●
Jaguar XF	2013-2015	GTDI 2.0L engine	TVM - Television module	●	●	●	●
Jaguar XF	2013-2015	GTDI 2.0L engine	VIM - Vehicle immobilizer control module	●	●	●	●
Jaguar XF	2013-2015	Supercharged V6	AAM - Audio amplifier module	●	●	●	●
Jaguar XF	2013-2015	Supercharged V6	ABS - ABS control module	●	●	●	●
Jaguar XF	2013-2015	Supercharged V6	ACM - Audio front control module	●	●	●	●
Jaguar XF	2013-2015	Supercharged V6	BCM - Central junction box (body control module)	●	●	●	●
Jaguar XF	2013-2015	Supercharged V6	BCMB - Auxiliary junction box (body control module B)	●	●	●	●
Jaguar XF	2013-2015	Supercharged V6	CCM - Speed control module	●	●	●	●
Jaguar XF	2013-2015	Supercharged V6	CHCM - Chassis control module	●	●	●	●
Jaguar XF	2013-2015	Supercharged V6	DABM - Digital audio broadcast module	●	●	●	●
Jaguar XF	2013-2015	Supercharged V6	DDM - Driver's door module	●	●	●	●
Jaguar XF	2013-2015	Supercharged V6	DSM - Driver's seat module	●	●	●	●
Jaguar XF	2013-2015	Supercharged V6	front)	●	●	●	●
Jaguar XF	2013-2015	Supercharged V6	panel)	●	●	●	●
Jaguar XF	2013-2015	Supercharged V6	FSJB - Central junction box (body control module)	●	●	●	●
Jaguar XF	2013-2015	Supercharged V6	GSM - Gear shift module	●	●	●	●
Jaguar XF	2013-2015	Supercharged V6	GWM - Gateway module	●	●	●	●
Jaguar XF	2013-2015	Supercharged V6	HCM - Headlamp control module	●	●	●	●
Jaguar XF	2013-2015	Supercharged V6	HCMB - Headlamp control module B	●	●	●	●
Jaguar XF	2013-2015	Supercharged V6	HVAC - Heating ventilation and air conditioning control module	●	●	●	●
Jaguar XF	2013-2015	Supercharged V6	IPC - Instrument cluster control module.	●	●	●	●
Jaguar XF	2013-2015	Supercharged V6	NCM - Navigation control module	●	●	●	●
Jaguar XF	2013-2015	Supercharged V6	OCS - Restraints occupant classification system module	●	●	●	●
Jaguar XF	2013-2015	Supercharged V6	PAM - Parking assist control module	●	●	●	●
Jaguar XF	2013-2015	Supercharged V6	PBM - Parking brake control module	●	●	●	●
Jaguar XF	2013-2015	Supercharged V6	PCM - Powertrain control module	●	●	●	●
Jaguar XF	2013-2015	Supercharged V6	PDM - Passenger's door module	●	●	●	●
Jaguar XF	2013-2015	Supercharged V6	PSM - Passenger's seat module	●	●	●	●
Jaguar XF	2013-2015	Supercharged V6	RCM - Restraints control module	●	●	●	●
Jaguar XF	2013-2015	Supercharged V6	RDCM - Rear differential control module	●	●	●	●
Jaguar XF	2013-2015	Supercharged V6	RFA - Keyless vehicle module	●	●	●	●
Jaguar XF	2013-2015	Supercharged V6	RGTM - Rear gate / trunk module	●	●	●	●
Jaguar XF	2013-2015	Supercharged V6	RSJB - Auxiliary junction box (body control module B)	●	●	●	●
Jaguar XF	2013-2015	Supercharged V6	SCME - Driver's climate seat module	●	●	●	●

Vehcile model	Year	Engine Type/Chassis Number	System Name	Information	Read TroubleCode	Clear TroubleCode	Read DataStream
Jaguar XF	2013-2015	Supercharged V6	SODL - Side object detection control module - Left	●	●	●	●
Jaguar XF	2013-2015	Supercharged V6	SODR - Side object detection control module - Right	●	●	●	●
Jaguar XF	2013-2015	Supercharged V6	SPMA - Safety belt pretensioner control module A - drivers side	●	●	●	●
Jaguar XF	2013-2015	Supercharged V6	SPMB - Safety belt pretensioner control module B - passengers side	●	●	●	●
Jaguar XF	2013-2015	Supercharged V6	SRM - Satellite audio unit module.	●	●	●	●
Jaguar XF	2013-2015	Supercharged V6	SUMB - Adaptive damping control module	●	●	●	●
Jaguar XF	2013-2015	Supercharged V6	TCCM - Transfer case control module	●	●	●	●
Jaguar XF	2013-2015	Supercharged V6	TCM - Transmission control module	●	●	●	●
Jaguar XF	2013-2015	Supercharged V6	TPM - Tire pressure monitor module	●	●	●	●
Jaguar XF	2013-2015	Supercharged V6	TVM - Television module	●	●	●	●
Jaguar XF	2013-2015	Supercharged V6	VIM - Vehicle immobilizer control module	●	●	●	●
Jaguar XF	2013-2015	Supercharged V8. 5.0L engine	AAM - Audio amplifier module	●	●	●	●
Jaguar XF	2013-2015	Supercharged V8. 5.0L engine	ABS - ABS control module	●	●	●	●
Jaguar XF	2013-2015	Supercharged V8. 5.0L engine	ACM - Audio front control module	●	●	●	●
Jaguar XF	2013-2015	Supercharged V8. 5.0L engine	BCM - Central junction box (body control module)	●	●	●	●
Jaguar XF	2013-2015	Supercharged V8. 5.0L engine	BCMB - Auxiliary junction box (body control module B)	●	●	●	●
Jaguar XF	2013-2015	Supercharged V8. 5.0L engine	CCM - Speed control module	●	●	●	●
Jaguar XF	2013-2015	Supercharged V8. 5.0L engine	CHCM - Chassis control module	●	●	●	●
Jaguar XF	2013-2015	Supercharged V8. 5.0L engine	DABM - Digital audio broadcast module	●	●	●	●
Jaguar XF	2013-2015	Supercharged V8. 5.0L engine	DDM - Driver's door module	●	●	●	●
Jaguar XF	2013-2015	Supercharged V8. 5.0L engine	DSM - Driver's seat module	●	●	●	●
Jaguar XF	2013-2015	Supercharged V8. 5.0L engine	front)	●	●	●	●
Jaguar XF	2013-2015	Supercharged V8. 5.0L engine	panel)	●	●	●	●
Jaguar XF	2013-2015	Supercharged V8. 5.0L engine	FSJB - Central junction box (body control module)	●	●	●	●
Jaguar XF	2013-2015	Supercharged V8. 5.0L engine	GSM - Gear shift module	●	●	●	●
Jaguar XF	2013-2015	Supercharged V8. 5.0L engine	GWM - Gateway module	●	●	●	●
Jaguar XF	2013-2015	Supercharged V8. 5.0L engine	HCM - Headlamp control module	●	●	●	●
Jaguar XF	2013-2015	Supercharged V8. 5.0L engine	HCMB - Headlamp control module B	●	●	●	●
Jaguar XF	2013-2015	Supercharged V8. 5.0L engine	HVAC - Heating ventilation and air conditioning control module	●	●	●	●
Jaguar XF	2013-2015	Supercharged V8. 5.0L engine	IPC - Instrument cluster control module.	●	●	●	●
Jaguar XF	2013-2015	Supercharged V8. 5.0L engine	NCM - Navigation control module	●	●	●	●
Jaguar XF	2013-2015	Supercharged V8. 5.0L engine	OCS - Restraints occupant classification system module	●	●	●	●
Jaguar XF	2013-2015	Supercharged V8. 5.0L engine	PAM - Parking assist control module	●	●	●	●
Jaguar XF	2013-2015	Supercharged V8. 5.0L engine	PBM - Parking brake control module	●	●	●	●
Jaguar XF	2013-2015	Supercharged V8. 5.0L engine	PCM - Powertrain control module	●	●	●	●
Jaguar XF	2013-2015	Supercharged V8. 5.0L engine	PDM - Passenger's door module	●	●	●	●
Jaguar XF	2013-2015	Supercharged V8. 5.0L engine	PSM - Passenger's seat module	●	●	●	●
Jaguar XF	2013-2015	Supercharged V8. 5.0L engine	RCM - Restraints control module	●	●	●	●
Jaguar XF	2013-2015	Supercharged V8. 5.0L engine	RDCM - Rear differential control module	●	●	●	●
Jaguar XF	2013-2015	Supercharged V8. 5.0L engine	RFA - Keyless vehicle module	●	●	●	●
Jaguar XF	2013-2015	Supercharged V8. 5.0L engine	RGTM - Rear gate / trunk module	●	●	●	●
Jaguar XF	2013-2015	Supercharged V8. 5.0L engine	RSJB - Auxiliary junction box (body control module B)	●	●	●	●
Jaguar XF	2013-2015	Supercharged V8. 5.0L engine	SCME - Driver's climate seat module	●	●	●	●
Jaguar XF	2013-2015	Supercharged V8. 5.0L engine	SODL - Side object detection control module - Left	●	●	●	●
Jaguar XF	2013-2015	Supercharged V8. 5.0L engine	SODR - Side object detection control module - Right	●	●	●	●
Jaguar XF	2013-2015	Supercharged V8. 5.0L engine	SPMA - Safety belt pretensioner control module A - drivers side	●	●	●	●
Jaguar XF	2013-2015	Supercharged V8. 5.0L engine	SPMB - Safety belt pretensioner control module B - passengers side	●	●	●	●
Jaguar XF	2013-2015	Supercharged V8. 5.0L engine	SRM - Satellite audio unit module.	●	●	●	●
Jaguar XF	2013-2015	Supercharged V8. 5.0L engine	SUMB - Adaptive damping control module	●	●	●	●
Jaguar XF	2013-2015	Supercharged V8. 5.0L engine	TCCM - Transfer case control module	●	●	●	●
Jaguar XF	2013-2015	Supercharged V8. 5.0L engine	TCM - Transmission control module	●	●	●	●
Jaguar XF	2013-2015	Supercharged V8. 5.0L engine	TPM - Tire pressure monitor module	●	●	●	●
Jaguar XF	2013-2015	Supercharged V8. 5.0L engine	TVM - Television module	●	●	●	●
Jaguar XF	2013-2015	Supercharged V8. 5.0L engine	VIM - Vehicle immobilizer control module	●	●	●	●
Jaguar XF	2016 -	Diesel I4 2.0L engine	AAM - InControl Touch Pro audio amplifier module	●	●	●	●
Jaguar XF	2016 -	Diesel I4 2.0L engine	ABS - ABS control module	●	●	●	●
Jaguar XF	2016 -	Diesel I4 2.0L engine	AHU - InControl Touch audio head unit	●	●	●	○
Jaguar XF	2016 -	Diesel I4 2.0L engine	ATCM - All terrain control module	●	●	●	●
Jaguar XF	2016 -	Diesel I4 2.0L engine	AUCM - Head-up display cooling fan module	●	●	●	●
Jaguar XF	2016 -	Diesel I4 2.0L engine	BCM - Body control module	●	●	●	●
Jaguar XF	2016 -	Diesel I4 2.0L engine	CCM - Speed control module	●	●	●	●
Jaguar XF	2016 -	Diesel I4 2.0L engine	CHCM - Chassis control module	●	●	●	●
Jaguar XF	2016 -	Diesel I4 2.0L engine	DDM - Driver's door module	●	●	●	●
Jaguar XF	2016 -	Diesel I4 2.0L engine	DRDM - Driver's (side) rear door module.	●	●	●	●
Jaguar XF	2016 -	Diesel I4 2.0L engine	DSM - Driver's seat module	●	●	●	●
Jaguar XF	2016 -	Diesel I4 2.0L engine	FCIM - Integrated control panel	●	●	●	●
Jaguar XF	2016 -	Diesel I4 2.0L engine	GSM - Gear shift module	●	●	●	●
Jaguar XF	2016 -	Diesel I4 2.0L engine	GWM - Gateway module	●	●	●	●
Jaguar XF	2016 -	Diesel I4 2.0L engine	HUD - Head up display	●	●	●	○
Jaguar XF	2016 -	Diesel I4 2.0L engine	HVAC - Heating ventilation and air conditioning control module	●	●	●	●
Jaguar XF	2016 -	Diesel I4 2.0L engine	IMC - InControl Touch Pro infotainment master controller	●	●	●	●
Jaguar XF	2016 -	Diesel I4 2.0L engine	IPC - Instrument cluster control module.	●	●	●	●
Jaguar XF	2016 -	Diesel I4 2.0L engine	IPMA - Image processing control module A	●	●	●	●
Jaguar XF	2016 -	Diesel I4 2.0L engine	IPMB - Image processing module B	●	●	●	●
Jaguar XF	2016 -	Diesel I4 2.0L engine	ISC - InControl Touch Pro infotainment slave controller	●	●	●	○
Jaguar XF	2016 -	Diesel I4 2.0L engine	OCS - Restraints occupant classification system module	●	●	●	●
Jaguar XF	2016 -	Diesel I4 2.0L engine	PAM - Parking assist control module	●	●	●	●
Jaguar XF	2016 -	Diesel I4 2.0L engine	PCM - Powertrain control module	●	●	●	●
Jaguar XF	2016 -	Diesel I4 2.0L engine	PDM - Passenger's door module	●	●	●	●
Jaguar XF	2016 -	Diesel I4 2.0L engine	PRDM - Passenger's (side) rear door module.	●	●	●	●
Jaguar XF	2016 -	Diesel I4 2.0L engine	PSCM - Power steering control module	●	●	●	●
Jaguar XF	2016 -	Diesel I4 2.0L engine	PSM - Passenger's seat module	●	●	●	●
Jaguar XF	2016 -	Diesel I4 2.0L engine	RCM - Restraints control module	●	●	●	●
Jaguar XF	2016 -	Diesel I4 2.0L engine	RFA - Keyless vehicle module	●	●	●	●
Jaguar XF	2016 -	Diesel I4 2.0L engine	RGTM - Rear gate / trunk module	●	●	●	●
Jaguar XF	2016 -	Diesel I4 2.0L engine	module	●	●	●	●
Jaguar XF	2016 -	Diesel I4 2.0L engine	SASM - Steering angle sensor module	●	●	●	●

Vevhicle model	Year	Engine Type/Chassis Number	System Name	Information	Read TroubleCode	Clear TroubleCode	Read DataStream
Jaguar XF	2016 -	Diesel I4 2.0L engine	SODL - Side object detection control module - Left	●	●	●	●
Jaguar XF	2016 -	Diesel I4 2.0L engine	SODR - Side object detection control module - Right	●	●	●	●
Jaguar XF	2016 -	Diesel I4 2.0L engine	TBM - Deployable towbar control module	●	●	●	●
Jaguar XF	2016 -	Diesel I4 2.0L engine	TCCM - Transfer case control module	●	●	●	●
Jaguar XF	2016 -	Diesel I4 2.0L engine	TCM - Transmission control module	●	●	●	●
Jaguar XF	2016 -	Diesel I4 2.0L engine	TCU - Telematic control unit module	●	●	●	●
Jaguar XF	2016 -	Diesel I4 2.0L engine	TPM - Tire pressure monitor module	●	●	●	●
Jaguar XF	2016 -	Diesel I4 2.0L engine	VIM - Vehicle immobilizer control module	●	●	●	●
Jaguar XF	2016 -	Diesel V6	AAM - InControl Touch Pro audio amplifier module	●	●	●	●
Jaguar XF	2016 -	Diesel V6	ABS - ABS control module	●	●	●	●
Jaguar XF	2016 -	Diesel V6	AHU - InControl Touch audio head unit	●	●	●	○
Jaguar XF	2016 -	Diesel V6	ATCM - All terrain control module	●	●	●	●
Jaguar XF	2016 -	Diesel V6	AUCM - Head-up display cooling fan module	●	●	●	●
Jaguar XF	2016 -	Diesel V6	BCM - Body control module	●	●	●	●
Jaguar XF	2016 -	Diesel V6	CCM - Speed control module	●	●	●	●
Jaguar XF	2016 -	Diesel V6	CHCM - Chassis control module	●	●	●	●
Jaguar XF	2016 -	Diesel V6	DDM - Driver's door module	●	●	●	●
Jaguar XF	2016 -	Diesel V6	DRDM - Driver's (side) rear door module.	●	●	●	●
Jaguar XF	2016 -	Diesel V6	DSM - Driver's seat module	●	●	●	●
Jaguar XF	2016 -	Diesel V6	FCIM - Integrated control panel	●	●	●	●
Jaguar XF	2016 -	Diesel V6	GSM - Gear shift module	●	●	●	●
Jaguar XF	2016 -	Diesel V6	GWM - Gateway module	●	●	●	●
Jaguar XF	2016 -	Diesel V6	HUD - Head up display	●	●	●	○
Jaguar XF	2016 -	Diesel V6	HVAC - Heating ventilation and air conditioning control module	●	●	●	●
Jaguar XF	2016 -	Diesel V6	IMC - InControl Touch Pro infotainment master controller	●	●	●	●
Jaguar XF	2016 -	Diesel V6	IPC - Instrument cluster control module.	●	●	●	●
Jaguar XF	2016 -	Diesel V6	IPMA - Image processing control module A	●	●	●	●
Jaguar XF	2016 -	Diesel V6	IPMB - Image processing module B	●	●	●	●
Jaguar XF	2016 -	Diesel V6	ISC - InControl Touch Pro infotainment slave controller	●	●	●	○
Jaguar XF	2016 -	Diesel V6	OCS - Restraints occupant classification system module	●	●	●	●
Jaguar XF	2016 -	Diesel V6	PAM - Parking assist control module	●	●	●	●
Jaguar XF	2016 -	Diesel V6	PCM - Powertrain control module	●	●	●	●
Jaguar XF	2016 -	Diesel V6	PDM - Passenger's door module	●	●	●	●
Jaguar XF	2016 -	Diesel V6	PRDM - Passenger's (side) rear door module.	●	●	●	●
Jaguar XF	2016 -	Diesel V6	PSCM - Power steering control module	●	●	●	●
Jaguar XF	2016 -	Diesel V6	PSM - Passenger's seat module	●	●	●	●
Jaguar XF	2016 -	Diesel V6	RCM - Restraints control module	●	●	●	●
Jaguar XF	2016 -	Diesel V6	RFA - Keyless vehicle module	●	●	●	●
Jaguar XF	2016 -	Diesel V6	RGTM - Rear gate / trunk module	●	●	●	●
Jaguar XF	2016 -	Diesel V6	module	●	●	●	●
Jaguar XF	2016 -	Diesel V6	SASM - Steering angle sensor module	●	●	●	●
Jaguar XF	2016 -	Diesel V6	SODL - Side object detection control module - Left	●	●	●	●
Jaguar XF	2016 -	Diesel V6	SODR - Side object detection control module - Right	●	●	●	●
Jaguar XF	2016 -	Diesel V6	TBM - Deployable towbar control module	●	●	●	●
Jaguar XF	2016 -	Diesel V6	TCCM - Transfer case control module	●	●	●	●
Jaguar XF	2016 -	Diesel V6	TCM - Transmission control module	●	●	●	●
Jaguar XF	2016 -	Diesel V6	TCU - Telematic control unit module	●	●	●	●
Jaguar XF	2016 -	Diesel V6	TPM - Tire pressure monitor module	●	●	●	●
Jaguar XF	2016 -	Diesel V6	VIM - Vehicle immobilizer control module	●	●	●	●
Jaguar XF	2016 -	GTDI 2.0L engine	AAM - InControl Touch Pro audio amplifier module	●	●	●	●
Jaguar XF	2016 -	GTDI 2.0L engine	ABS - ABS control module	●	●	●	●
Jaguar XF	2016 -	GTDI 2.0L engine	AHU - InControl Touch audio head unit	●	●	●	○
Jaguar XF	2016 -	GTDI 2.0L engine	ATCM - All terrain control module	●	●	●	●
Jaguar XF	2016 -	GTDI 2.0L engine	AUCM - Head-up display cooling fan module	●	●	●	●
Jaguar XF	2016 -	GTDI 2.0L engine	BCM - Body control module	●	●	●	●
Jaguar XF	2016 -	GTDI 2.0L engine	CCM - Speed control module	●	●	●	●
Jaguar XF	2016 -	GTDI 2.0L engine	CHCM - Chassis control module	●	●	●	●
Jaguar XF	2016 -	GTDI 2.0L engine	DDM - Driver's door module	●	●	●	●
Jaguar XF	2016 -	GTDI 2.0L engine	DRDM - Driver's (side) rear door module.	●	●	●	●
Jaguar XF	2016 -	GTDI 2.0L engine	DSM - Driver's seat module	●	●	●	●
Jaguar XF	2016 -	GTDI 2.0L engine	FCIM - Integrated control panel	●	●	●	●
Jaguar XF	2016 -	GTDI 2.0L engine	GSM - Gear shift module	●	●	●	●
Jaguar XF	2016 -	GTDI 2.0L engine	GWM - Gateway module	●	●	●	●
Jaguar XF	2016 -	GTDI 2.0L engine	HUD - Head up display	●	●	●	○
Jaguar XF	2016 -	GTDI 2.0L engine	HVAC - Heating ventilation and air conditioning control module	●	●	●	●
Jaguar XF	2016 -	GTDI 2.0L engine	IMC - InControl Touch Pro infotainment master controller	●	●	●	●
Jaguar XF	2016 -	GTDI 2.0L engine	IPC - Instrument cluster control module.	●	●	●	●
Jaguar XF	2016 -	GTDI 2.0L engine	IPMA - Image processing control module A	●	●	●	●
Jaguar XF	2016 -	GTDI 2.0L engine	IPMB - Image processing module B	●	●	●	●
Jaguar XF	2016 -	GTDI 2.0L engine	ISC - InControl Touch Pro infotainment slave controller	●	●	●	○
Jaguar XF	2016 -	GTDI 2.0L engine	OCS - Restraints occupant classification system module	●	●	●	●
Jaguar XF	2016 -	GTDI 2.0L engine	PAM - Parking assist control module	●	●	●	●
Jaguar XF	2016 -	GTDI 2.0L engine	PCM - Powertrain control module	●	●	●	●
Jaguar XF	2016 -	GTDI 2.0L engine	PDM - Passenger's door module	●	●	●	●
Jaguar XF	2016 -	GTDI 2.0L engine	PRDM - Passenger's (side) rear door module.	●	●	●	●
Jaguar XF	2016 -	GTDI 2.0L engine	PSCM - Power steering control module	●	●	●	●
Jaguar XF	2016 -	GTDI 2.0L engine	PSM - Passenger's seat module	●	●	●	●
Jaguar XF	2016 -	GTDI 2.0L engine	RCM - Restraints control module	●	●	●	●
Jaguar XF	2016 -	GTDI 2.0L engine	RFA - Keyless vehicle module	●	●	●	●
Jaguar XF	2016 -	GTDI 2.0L engine	RGTM - Rear gate / trunk module	●	●	●	●
Jaguar XF	2016 -	GTDI 2.0L engine	module	●	●	●	●
Jaguar XF	2016 -	GTDI 2.0L engine	SASM - Steering angle sensor module	●	●	●	●
Jaguar XF	2016 -	GTDI 2.0L engine	SODL - Side object detection control module - Left	●	●	●	●
Jaguar XF	2016 -	GTDI 2.0L engine	SODR - Side object detection control module - Right	●	●	●	●
Jaguar XF	2016 -	GTDI 2.0L engine	TBM - Deployable towbar control module	●	●	●	●
Jaguar XF	2016 -	GTDI 2.0L engine	TCCM - Transfer case control module	●	●	●	●
Jaguar XF	2016 -	GTDI 2.0L engine	TCM - Transmission control module	●	●	●	●

Vehicle model	Year	Engine Type/Chassis Number	System Name	Information	Read TroubleCode	Clear TroubleCode	Read DataStream
Jaguar XF	2016 -	GTDI 2.0L engine	TCU - Telematic control unit module	●	●	●	●
Jaguar XF	2016 -	GTDI 2.0L engine	TPM - Tire pressure monitor module	●	●	●	●
Jaguar XF	2016 -	GTDI 2.0L engine	VIM - Vehicle immobilizer control module	●	●	●	●
Jaguar XF	2016 -	Supercharged V6 3.0L engine	AAM - InControl Touch Pro audio amplifier module	●	●	●	●
Jaguar XF	2016 -	Supercharged V6 3.0L engine	ABS - ABS control module	●	●	●	●
Jaguar XF	2016 -	Supercharged V6 3.0L engine	AHU - InControl Touch audio head unit	●	●	●	○
Jaguar XF	2016 -	Supercharged V6 3.0L engine	ATCM - All terrain control module	●	●	●	●
Jaguar XF	2016 -	Supercharged V6 3.0L engine	AUCM - Head-up display cooling fan module	●	●	●	●
Jaguar XF	2016 -	Supercharged V6 3.0L engine	BCM - Body control module	●	●	●	●
Jaguar XF	2016 -	Supercharged V6 3.0L engine	CCM - Speed control module	●	●	●	●
Jaguar XF	2016 -	Supercharged V6 3.0L engine	CHCM - Chassis control module	●	●	●	●
Jaguar XF	2016 -	Supercharged V6 3.0L engine	DDM - Driver's door module	●	●	●	●
Jaguar XF	2016 -	Supercharged V6 3.0L engine	DRDM - Driver's (side) rear door module.	●	●	●	●
Jaguar XF	2016 -	Supercharged V6 3.0L engine	DSM - Driver's seat module	●	●	●	●
Jaguar XF	2016 -	Supercharged V6 3.0L engine	FCIM - Integrated control panel	●	●	●	●
Jaguar XF	2016 -	Supercharged V6 3.0L engine	GSM - Gear shift module	●	●	●	●
Jaguar XF	2016 -	Supercharged V6 3.0L engine	GWM - Gateway module	●	●	●	●
Jaguar XF	2016 -	Supercharged V6 3.0L engine	HUD - Head up display	●	●	●	○
Jaguar XF	2016 -	Supercharged V6 3.0L engine	HVAC - Heating ventilation and air conditioning control module	●	●	●	●
Jaguar XF	2016 -	Supercharged V6 3.0L engine	IMC - InControl Touch Pro infotainment master controller	●	●	●	●
Jaguar XF	2016 -	Supercharged V6 3.0L engine	IPC - Instrument cluster control module.	●	●	●	●
Jaguar XF	2016 -	Supercharged V6 3.0L engine	IPMA - Image processing control module A	●	●	●	●
Jaguar XF	2016 -	Supercharged V6 3.0L engine	IPMB - Image processing module B	●	●	●	●
Jaguar XF	2016 -	Supercharged V6 3.0L engine	ISC - InControl Touch Pro infotainment slave controller	●	●	●	○
Jaguar XF	2016 -	Supercharged V6 3.0L engine	OCS - Restraints occupant classification system module	●	●	●	●
Jaguar XF	2016 -	Supercharged V6 3.0L engine	PAM - Parking assist control module	●	●	●	●
Jaguar XF	2016 -	Supercharged V6 3.0L engine	PCM - Powertrain control module	●	●	●	●
Jaguar XF	2016 -	Supercharged V6 3.0L engine	PDM - Passenger's door module	●	●	●	●
Jaguar XF	2016 -	Supercharged V6 3.0L engine	PRDM - Passenger's (side) rear door module.	●	●	●	●
Jaguar XF	2016 -	Supercharged V6 3.0L engine	PSCM - Power steering control module	●	●	●	●
Jaguar XF	2016 -	Supercharged V6 3.0L engine	PSM - Passenger's seat module	●	●	●	●
Jaguar XF	2016 -	Supercharged V6 3.0L engine	RCM - Restraints control module	●	●	●	●
Jaguar XF	2016 -	Supercharged V6 3.0L engine	RFA - Keyless vehicle module	●	●	●	●
Jaguar XF	2016 -	Supercharged V6 3.0L engine	RGTM - Rear gate / trunk module	●	●	●	●
Jaguar XF	2016 -	Supercharged V6 3.0L engine	module	●	●	●	●
Jaguar XF	2016 -	Supercharged V6 3.0L engine	SASM - Steering angle sensor module	●	●	●	●
Jaguar XF	2016 -	Supercharged V6 3.0L engine	SODL - Side object detection control module - Left	●	●	●	●
Jaguar XF	2016 -	Supercharged V6 3.0L engine	SODR - Side object detection control module - Right	●	●	●	●
Jaguar XF	2016 -	Supercharged V6 3.0L engine	TBM - Deployable towbar control module	●	●	●	●
Jaguar XF	2016 -	Supercharged V6 3.0L engine	TCCM - Transfer case control module	●	●	●	●
Jaguar XF	2016 -	Supercharged V6 3.0L engine	TCM - Transmission control module	●	●	●	●
Jaguar XF	2016 -	Supercharged V6 3.0L engine	TCU - Telematic control unit module	●	●	●	●
Jaguar XF	2016 -	Supercharged V6 3.0L engine	TPM - Tire pressure monitor module	●	●	●	●
Jaguar XF	2016 -	Supercharged V6 3.0L engine	VIM - Vehicle immobilizer control module	●	●	●	●
Other Vehicle		001001 - 003299	ABS - ABS control module	●	●	●	●
Other Vehicle		001001 - 003299	ACM - Restraints control module	●	●	●	●
Other Vehicle		001001 - 003299	ADS - Adaptive damping system.	●	●	●	●
Other Vehicle		001001 - 003299	BPM - Body processor module	●	○	●	●
Other Vehicle		001001 - 003299	CCM - Climate control module	●	●	●	●
Other Vehicle		001001 - 003299	DDM - Driver's door module	●	○	●	●
Other Vehicle		001001 - 003299	DSM - Driver's seat module	●	○	●	●
Other Vehicle		001001 - 003299	ECM - Engine control module	●	●	●	●
Other Vehicle		001001 - 003299	IPK - Instrument pack	●	●	●	●
Other Vehicle		001001 - 003299	PDM - Passenger's door module	●	○	●	●
Other Vehicle		001001 - 003299	PSM - Passenger's seat module	●	○	●	●
Other Vehicle		001001 - 003299	SLM - Security locking module.	●	○	●	●
Other Vehicle		001001 - 003299	TCM - Transmission control module	●	●	●	●
Other Vehicle		003300 - 018107	ABS - ABS control module	●	●	●	●
Other Vehicle		003300 - 018107	ACM - Restraints control module	●	●	●	●
Other Vehicle		003300 - 018107	ADS - Adaptive damping system.	●	●	●	●
Other Vehicle		003300 - 018107	BPM - Body processor module	●	○	●	●
Other Vehicle		003300 - 018107	CCM - Climate control module	●	●	●	●
Other Vehicle		003300 - 018107	DDM - Driver's door module	●	○	●	●
Other Vehicle		003300 - 018107	DSM - Driver's seat module	●	○	●	●
Other Vehicle		003300 - 018107	ECM - Engine control module	●	●	●	●
Other Vehicle		003300 - 018107	IPK - Instrument pack	●	●	●	●
Other Vehicle		003300 - 018107	PDM - Passenger's door module	●	○	●	●
Other Vehicle		003300 - 018107	PSM - Passenger's seat module	●	○	●	●
Other Vehicle		003300 - 018107	SLM - Security locking module.	●	○	●	●
Other Vehicle		003300 - 018107	TCM - Transmission control module	●	●	●	●
Other Vehicle		018108 - 024686	ABS - ABS control module	●	●	●	●
Other Vehicle		018108 - 024686	ACM - Restraints control module	●	●	●	●
Other Vehicle		018108 - 024686	ADS - Adaptive damping system.	●	●	●	●
Other Vehicle		018108 - 024686	BPM - Body processor module	●	○	●	●
Other Vehicle		018108 - 024686	CCM - Climate control module	●	●	●	●
Other Vehicle		018108 - 024686	DDM - Driver's door module	●	○	●	●
Other Vehicle		018108 - 024686	DSM - Driver's seat module	●	○	●	●
Other Vehicle		018108 - 024686	ECM - Engine control module	●	●	●	●
Other Vehicle		018108 - 024686	IPK - Instrument pack	●	●	●	●
Other Vehicle		018108 - 024686	PDM - Passenger's door module	●	○	●	●
Other Vehicle		018108 - 024686	PSM - Passenger's seat module	●	○	●	●
Other Vehicle		018108 - 024686	SLM - Security locking module.	●	○	●	●
Other Vehicle		018108 - 024686	TCM - Transmission control module	●	●	●	●
Other Vehicle		024687 - 031302	ABS - ABS control module	●	●	●	●
Other Vehicle		024687 - 031302	ACM - Restraints control module	●	●	●	●
Other Vehicle		024687 - 031302	ADS - Adaptive damping system.	●	●	●	●
Other Vehicle		024687 - 031302	BPM - Body processor module	●	○	●	●



Vehicle model	Year	Engine Type/Chassis Number	System Name	Information	Read TroubleCode	Clear TroubleCode	Read DataStream
Other Vehicle		024687 - 031302	CCM - Climate control module	●	●	●	●
Other Vehicle		024687 - 031302	DDM - Driver's door module	●	○	●	●
Other Vehicle		024687 - 031302	DSM - Driver's seat module	●	○	●	●
Other Vehicle		024687 - 031302	ECM - Engine control module	●	●	●	●
Other Vehicle		024687 - 031302	IPK - Instrument pack	●	●	●	●
Other Vehicle		024687 - 031302	PDM - Passenger's door module	●	○	●	●
Other Vehicle		024687 - 031302	PSM - Passenger's seat module	●	○	●	●
Other Vehicle		024687 - 031302	SLM - Security locking module.	●	○	●	●
Other Vehicle		024687 - 031302	TCM - Transmission control module	●	●	●	●
Other Vehicle		031303 - 042775	ABS - ABS control module	●	●	●	●
Other Vehicle		031303 - 042775	ACM - Restraints control module	●	●	●	●
Other Vehicle		031303 - 042775	ADS - Adaptive damping system.	●	●	●	●
Other Vehicle		031303 - 042775	BPM - Body processor module	●	○	●	●
Other Vehicle		031303 - 042775	CCM - Climate control module	●	●	●	●
Other Vehicle		031303 - 042775	DDM - Driver's door module	●	○	●	●
Other Vehicle		031303 - 042775	DSM - Driver's seat module	●	○	●	●
Other Vehicle		031303 - 042775	ECM - Engine control module	●	●	●	●
Other Vehicle		031303 - 042775	IPK - Instrument pack	●	●	●	●
Other Vehicle		031303 - 042775	PDM - Passenger's door module	●	○	●	●
Other Vehicle		031303 - 042775	PSM - Passenger's seat module	●	○	●	●
Other Vehicle		031303 - 042775	SLM - Security locking module.	●	○	●	●
Other Vehicle		031303 - 042775	TCM - Transmission control module	●	●	●	●
Other Vehicle		720001 - 739426	ABS - Anti-lock braking system	●	●	●	●
Other Vehicle		720001 - 739426	BPM - Body processor module	●	○	●	●
Other Vehicle		720001 - 739426	CCM - Climate control module	●	●	●	●
Other Vehicle		720001 - 739426	CMM - Column/mirror memory control module	●	●	●	●
Other Vehicle		720001 - 739426	DSM - Driver's seat module	●	●	●	●
Other Vehicle		720001 - 739426	ECM - Engine control module	●	●	●	●
Other Vehicle		720001 - 739426	IPK - Instrument pack	●	●	●	●
Other Vehicle		720001 - 739426	PSM - Passenger's seat module	●	●	●	●
Other Vehicle		720001 - 739426	SEC - Security system control module	●	○	●	●
Other Vehicle		720001 - 739426	TCM - Transmission control module	●	●	●	○
Other Vehicle		739427 - 746612	ABS - Anti-lock braking system	●	●	●	●
Other Vehicle		739427 - 746612	BPM - Body processor module	●	○	●	●
Other Vehicle		739427 - 746612	CCM - Climate control module	●	●	●	●
Other Vehicle		739427 - 746612	CMM - Column/mirror memory control module	●	●	●	●
Other Vehicle		739427 - 746612	DSM - Driver's seat module	●	●	●	●
Other Vehicle		739427 - 746612	ECM - Engine control module	●	●	●	●
Other Vehicle		739427 - 746612	IPK - Instrument pack	●	●	●	●
Other Vehicle		739427 - 746612	PSM - Passenger's seat module	●	●	●	●
Other Vehicle		739427 - 746612	SEC - Security system control module	●	○	●	●
Other Vehicle		739427 - 746612	TCM - Transmission control module	●	●	●	○
Other Vehicle		746613 - 754303	ABS - Anti-lock braking system	●	●	●	●
Other Vehicle		746613 - 754303	BPM - Body processor module	●	○	●	●
Other Vehicle		746613 - 754303	CCM - Climate control module	●	●	●	●
Other Vehicle		746613 - 754303	CMM - Column/mirror memory control module	●	●	●	●
Other Vehicle		746613 - 754303	DSM - Driver's seat module	●	●	●	●
Other Vehicle		746613 - 754303	ECM - Engine control module	●	●	●	●
Other Vehicle		746613 - 754303	IPK - Instrument pack	●	●	●	●
Other Vehicle		746613 - 754303	PSM - Passenger's seat module	●	●	●	●
Other Vehicle		746613 - 754303	SEC - Security system control module	●	○	●	●
Other Vehicle		746613 - 754303	TCM - Transmission control module	●	●	●	○
Other Vehicle		754304 - 758211	ABS - Anti-lock braking system	●	●	●	●
Other Vehicle		754304 - 758211	BPM - Body processor module	●	○	●	●
Other Vehicle		754304 - 758211	CCM - Climate control module	●	●	●	●
Other Vehicle		754304 - 758211	CMM - Column/mirror memory control module	●	●	●	●
Other Vehicle		754304 - 758211	DSM - Driver's seat module	●	●	●	●
Other Vehicle		754304 - 758211	ECM - Engine control module	●	●	●	●
Other Vehicle		754304 - 758211	IPK - Instrument pack	●	●	●	●
Other Vehicle		754304 - 758211	PSM - Passenger's seat module	●	●	●	●
Other Vehicle		754304 - 758211	SEC - Security system control module	●	○	●	●
Other Vehicle		754304 - 758211	TCM - Transmission control module	●	●	●	○
Other Vehicle		758212 - 787953	ABS - Anti-lock braking system	●	●	●	●
Other Vehicle		758212 - 787953	BPM - Body processor module	●	○	●	●
Other Vehicle		758212 - 787953	CCM - Climate control module	●	●	●	●
Other Vehicle		758212 - 787953	CMM - Column/mirror memory control module	●	●	●	●
Other Vehicle		758212 - 787953	DSM - Driver's seat module	●	●	●	●
Other Vehicle		758212 - 787953	ECM - Engine control module	●	●	●	●
Other Vehicle		758212 - 787953	IPK - Instrument pack	●	●	●	●
Other Vehicle		758212 - 787953	PSM - Passenger's seat module	●	●	●	●
Other Vehicle		758212 - 787953	SEC - Security system control module	●	○	●	●
Other Vehicle		758212 - 787953	TCM - Transmission control module	●	●	●	●
Other Vehicle		787954 - 812316	ABS - Anti-lock braking system	●	●	●	●
Other Vehicle		787954 - 812316	BPM - Body processor module	●	○	●	●
Other Vehicle		787954 - 812316	CCM - Climate control module	●	●	●	●
Other Vehicle		787954 - 812316	CMM - Column/mirror memory control module	●	●	●	●
Other Vehicle		787954 - 812316	DSM - Driver's seat module	●	●	●	●
Other Vehicle		787954 - 812316	ECM - Engine control module	●	●	●	●
Other Vehicle		787954 - 812316	IPK - Instrument pack	●	●	●	●
Other Vehicle		787954 - 812316	PSM - Passenger's seat module	●	●	●	●
Other Vehicle		787954 - 812316	SEC - Security system control module	●	○	●	●
Other Vehicle		787954 - 812316	TCM - Transmission control module	●	●	●	○
Other Vehicle		812317 - 829946	ABS - Anti-lock braking system	●	●	●	●
Other Vehicle		812317 - 829946	ACM - Restraints control module	●	●	●	●
Other Vehicle		812317 - 829946	ADS - Adaptive damping system.	●	●	●	●
Other Vehicle		812317 - 829946	BPM - Body processor module	●	○	●	●
Other Vehicle		812317 - 829946	CCM - Climate control module	●	●	●	●

Vehicle model	Year	Engine Type/Chassis Number	System Name	Information	Read TroubleCode	Clear TroubleCode	Read DataStream
Other Vehicle		812317 - 829946	DDM - Driver's door module	●	○	●	●
Other Vehicle		812317 - 829946	DRDM - Driver's (side) rear door module.	●	○	●	●
Other Vehicle		812317 - 829946	DSM - Driver's seat module	●	○	●	●
Other Vehicle		812317 - 829946	ECM - Engine control module	●	●	●	●
Other Vehicle		812317 - 829946	IPK - Instrument pack	●	●	●	●
Other Vehicle		812317 - 829946	PDM - Passenger's door module	●	○	●	●
Other Vehicle		812317 - 829946	PRDM - Passenger's (side) rear door module.	●	○	●	●
Other Vehicle		812317 - 829946	PSM - Passenger's seat module	●	○	●	●
Other Vehicle		812317 - 829946	SLM - Security locking module.	●	○	●	●
Other Vehicle		812317 - 829946	TCM - Transmission control module	●	●	●	●
Other Vehicle		829947 - 853935	ABS - Anti-lock braking system	●	●	●	●
Other Vehicle		829947 - 853935	ACM - Restraints control module	●	●	●	●
Other Vehicle		829947 - 853935	ADS - Adaptive damping system.	●	●	●	●
Other Vehicle		829947 - 853935	BPM - Body processor module	●	○	●	●
Other Vehicle		829947 - 853935	CCM - Climate control module	●	●	●	●
Other Vehicle		829947 - 853935	DDM - Driver's door module	●	○	●	●
Other Vehicle		829947 - 853935	DRDM - Driver's (side) rear door module.	●	○	●	●
Other Vehicle		829947 - 853935	DSM - Driver's seat module	●	○	●	●
Other Vehicle		829947 - 853935	ECM - Engine control module	●	●	●	●
Other Vehicle		829947 - 853935	IPK - Instrument pack	●	●	●	●
Other Vehicle		829947 - 853935	PDM - Passenger's door module	●	○	●	●
Other Vehicle		829947 - 853935	PRDM - Passenger's (side) rear door module.	●	○	●	●
Other Vehicle		829947 - 853935	PSM - Passenger's seat module	●	○	●	●
Other Vehicle		829947 - 853935	SLM - Security locking module.	●	○	●	●
Other Vehicle		829947 - 853935	TCM - Transmission control module	●	●	●	●
Other Vehicle		853936 - 878717	ABS - Anti-lock braking system	●	●	●	●
Other Vehicle		853936 - 878717	ACM - Restraints control module	●	●	●	●
Other Vehicle		853936 - 878717	ADS - Adaptive damping system.	●	●	●	●
Other Vehicle		853936 - 878717	BPM - Body processor module	●	○	●	●
Other Vehicle		853936 - 878717	CCM - Climate control module	●	●	●	●
Other Vehicle		853936 - 878717	DDM - Driver's door module	●	○	●	●
Other Vehicle		853936 - 878717	DRDM - Driver's (side) rear door module.	●	○	●	●
Other Vehicle		853936 - 878717	DSM - Driver's seat module	●	○	●	●
Other Vehicle		853936 - 878717	ECM - Engine control module	●	●	●	●
Other Vehicle		853936 - 878717	IPK - Instrument pack	●	●	●	●
Other Vehicle		853936 - 878717	PDM - Passenger's door module	●	○	●	●
Other Vehicle		853936 - 878717	PRDM - Passenger's (side) rear door module.	●	○	●	●
Other Vehicle		853936 - 878717	PSM - Passenger's seat module	●	○	●	●
Other Vehicle		853936 - 878717	SLM - Security locking module.	●	○	●	●
Other Vehicle		853936 - 878717	TCM - Transmission control module	●	●	●	●
Other Vehicle		A00001 - A11050	ABS - ABS control module	●	●	●	●
Other Vehicle		A00001 - A11050	ACC - Adaptive speed control control module.	●	●	●	○
Other Vehicle		A00001 - A11050	ACM - Restraints control module	●	●	●	●
Other Vehicle		A00001 - A11050	ADS - Adaptive damping system.	●	●	●	●
Other Vehicle		A00001 - A11050	BPM - Body processor module	●	○	●	●
Other Vehicle		A00001 - A11050	CCM - Climate control module	●	●	●	●
Other Vehicle		A00001 - A11050	DDM - Driver's door module	●	○	●	●
Other Vehicle		A00001 - A11050	DSM - Driver's seat module	●	○	●	●
Other Vehicle		A00001 - A11050	ECM - Engine control module	●	●	●	●
Other Vehicle		A00001 - A11050	IPK - Instrument pack	●	●	●	●
Other Vehicle		A00001 - A11050	PDM - Passenger's door module	●	○	●	●
Other Vehicle		A00001 - A11050	PSM - Passenger's seat module	●	○	●	●
Other Vehicle		A00001 - A11050	SBC - Adaptive speed control booster control module	●	●	●	○
Other Vehicle		A00001 - A11050	SLM - Security locking module.	●	○	●	●
Other Vehicle		A00001 - A11050	TCM - Transmission control module	●	●	●	●
Other Vehicle		A11051 - A30644	ABS - ABS control module	●	●	●	●
Other Vehicle		A11051 - A30644	ACC - Adaptive speed control control module.	●	●	●	○
Other Vehicle		A11051 - A30644	ADS - Adaptive damping system.	●	●	●	●
Other Vehicle		A11051 - A30644	ARM - Restraints control module	●	●	●	●
Other Vehicle		A11051 - A30644	BPM - Body processor module	●	○	●	●
Other Vehicle		A11051 - A30644	CCM - Climate control module	●	●	●	●
Other Vehicle		A11051 - A30644	DDM - Driver's door module	●	○	●	●
Other Vehicle		A11051 - A30644	DHM - Driver's head restraint module	●	●	●	●
Other Vehicle		A11051 - A30644	DSM - Driver's seat module	●	○	●	●
Other Vehicle		A11051 - A30644	ECM - Engine control module	●	●	●	●
Other Vehicle		A11051 - A30644	IPK - Instrument pack	●	●	●	●
Other Vehicle		A11051 - A30644	PDM - Passenger's door module	●	○	●	●
Other Vehicle		A11051 - A30644	PHM - Passenger's head restraint module	●	●	●	●
Other Vehicle		A11051 - A30644	PSM - Passenger's seat module	●	○	●	●
Other Vehicle		A11051 - A30644	SBC - Adaptive speed control booster control module	●	●	●	○
Other Vehicle		A11051 - A30644	SLM - Security locking module.	●	○	●	●
Other Vehicle		A11051 - A30644	TCM - Transmission control module	●	●	●	●
Other Vehicle		A30645 - A99999	ABS - ABS control module	●	●	●	●
Other Vehicle		A30645 - A99999	ACC - Adaptive speed control control module.	●	●	●	●
Other Vehicle		A30645 - A99999	ADHLS - Left lighting control module	●	●	●	●
Other Vehicle		A30645 - A99999	ADHLS - Right lighting control module	●	●	●	●
Other Vehicle		A30645 - A99999	ADRC - Adaptive damping ride control.	○	●	●	●
Other Vehicle		A30645 - A99999	ARM - Restraints control module	●	●	●	●
Other Vehicle		A30645 - A99999	ATC - Climate control module	○	●	●	●
Other Vehicle		A30645 - A99999	BPM - Body processor module	●	●	●	●
Other Vehicle		A30645 - A99999	DDM - Driver's door module	●	●	●	●
Other Vehicle		A30645 - A99999	DHM - Driver's head restraint module	●	●	●	●
Other Vehicle		A30645 - A99999	DSM - Driver's seat module	●	●	●	●
Other Vehicle		A30645 - A99999	ECM - Engine control module	●	●	●	●
Other Vehicle		A30645 - A99999	IP - Instrument pack	●	●	●	●
Other Vehicle		A30645 - A99999	PAM - Parking aid control module.	●	●	●	●
Other Vehicle		A30645 - A99999	PDM - Passenger's door module	●	●	●	●

Vehicle model	Year	Engine Type/Chassis Number	System Name	Information	Read TroubleCode	Clear TroubleCode	Read DataStream
Other Vehicle		A30645 - A99999	PHM - Passenger's head restraint module	●	●	●	●
Other Vehicle		A30645 - A99999	PSM - Passenger's seat module	●	●	●	●
Other Vehicle		A30645 - A99999	SLM - Security locking module.	●	●	●	●
Other Vehicle		A30645 - A99999	TCM - Transmission control module	●	●	●	●
Other Vehicle		F00001 - F20644	ABS - Anti-lock braking system	●	●	●	●
Other Vehicle		F00001 - F20644	ACM - Restraints control module	●	●	●	●
Other Vehicle		F00001 - F20644	ADS - Adaptive damping system.	●	●	●	●
Other Vehicle		F00001 - F20644	BPM - Body processor module	●	○	●	●
Other Vehicle		F00001 - F20644	CCM - Climate control module	●	●	●	●
Other Vehicle		F00001 - F20644	DDM - Driver's door module	●	○	●	●
Other Vehicle		F00001 - F20644	DRDM - Driver's (side) rear door module.	●	○	●	●
Other Vehicle		F00001 - F20644	DSM - Driver's seat module	●	○	●	●
Other Vehicle		F00001 - F20644	ECM - Engine control module	●	●	●	●
Other Vehicle		F00001 - F20644	IPK - Instrument pack	●	●	●	●
Other Vehicle		F00001 - F20644	PDM - Passenger's door module	●	○	●	●
Other Vehicle		F00001 - F20644	PRDM - Passenger's (side) rear door module.	●	○	●	●
Other Vehicle		F00001 - F20644	PSM - Passenger's seat module	●	○	●	●
Other Vehicle		F00001 - F20644	SLM - Security locking module.	●	○	●	●
Other Vehicle		F00001 - F20644	TCM - Transmission control module	●	○	●	●
Other Vehicle		F20645 - F99999	ABS - Anti-lock braking system	●	●	●	●
Other Vehicle		F20645 - F99999	ACM - Restraints control module	●	●	●	●
Other Vehicle		F20645 - F99999	ADS - Adaptive damping system.	●	●	●	●
Other Vehicle		F20645 - F99999	BPM - Body processor module	●	○	●	●
Other Vehicle		F20645 - F99999	CCM - Climate control module	●	●	●	●
Other Vehicle		F20645 - F99999	DDM - Driver's door module	●	○	●	●
Other Vehicle		F20645 - F99999	DRDM - Driver's (side) rear door module.	●	○	●	●
Other Vehicle		F20645 - F99999	DSM - Driver's seat module	●	○	●	●
Other Vehicle		F20645 - F99999	ECM - Engine control module	●	●	●	●
Other Vehicle		F20645 - F99999	IPK - Instrument pack	●	●	●	●
Other Vehicle		F20645 - F99999	PDM - Passenger's door module	●	○	●	●
Other Vehicle		F20645 - F99999	PRDM - Passenger's (side) rear door module.	●	○	●	●
Other Vehicle		F20645 - F99999	PSM - Passenger's seat module	●	○	●	●
Other Vehicle		F20645 - F99999	SLM - Security locking module.	●	○	●	●
Other Vehicle		F20645 - F99999	TCM - Transmission control module	●	●	●	●
Other Vehicle		L00001 - L25200	ABS - Anti-lock braking system	●	●	●	●
Other Vehicle		L00001 - L25200	ADS - Adaptive damping system.	●	●	●	●
Other Vehicle		L00001 - L25200	CCM - Climate control module	●	●	●	●
Other Vehicle		L00001 - L25200	CPM - Cellular telephone control module	●	○	●	●
Other Vehicle		L00001 - L25200	DDM - Driver's door module	●	●	●	●
Other Vehicle		L00001 - L25200	DSM - Driver's seat module	●	●	●	●
Other Vehicle		L00001 - L25200	GEM - General electronics control module.	●	●	●	●
Other Vehicle		L00001 - L25200	ICE - Audio unit.	●	●	●	●
Other Vehicle		L00001 - L25200	IPK - Instrument pack	●	●	●	●
Other Vehicle		L00001 - L25200	MCC - Message center control module	●	●	●	●
Other Vehicle		L00001 - L25200	NAV - Navigation control module	●	●	●	○
Other Vehicle		L00001 - L25200	PAM - Parking aid control module.	●	●	●	●
Other Vehicle		L00001 - L25200	PCM - Powertrain control module	●	●	●	●
Other Vehicle		L00001 - L25200	RCM - Restraints control module	●	●	●	●
Other Vehicle		L00001 - L25200	REM - Rear electronic control module.	●	●	●	●
Other Vehicle		L00001 - L25200	RES - Vehicle emergency control module	●	○	●	●
Other Vehicle		L00001 - L25200	SCL - Steering column lock module	●	○	●	○
Other Vehicle		L00001 - L25200	TCU - Throttle control unit.	●	○	●	○
Other Vehicle		L00001 - L25200	VAM - Voice activation control module.	●	○	●	●
Other Vehicle		L25201 - L86901	ABS - Anti-lock braking system	●	●	●	●
Other Vehicle		L25201 - L86901	ADS - Adaptive damping system.	●	●	●	●
Other Vehicle		L25201 - L86901	CCM - Climate control module	●	●	●	●
Other Vehicle		L25201 - L86901	CPM - Cellular telephone control module	●	○	●	●
Other Vehicle		L25201 - L86901	DDM - Driver's door module	●	●	●	●
Other Vehicle		L25201 - L86901	DSM - Driver's seat module	●	●	●	●
Other Vehicle		L25201 - L86901	GEM - General electronics control module.	●	●	●	●
Other Vehicle		L25201 - L86901	ICE - Audio unit.	●	●	●	●
Other Vehicle		L25201 - L86901	IPK - Instrument pack	●	●	●	●
Other Vehicle		L25201 - L86901	MCC - Message center control module	●	●	●	●
Other Vehicle		L25201 - L86901	NAV - Navigation control module	●	●	●	○
Other Vehicle		L25201 - L86901	PAM - Parking aid control module.	●	●	●	●
Other Vehicle		L25201 - L86901	PCM - Powertrain control module	●	●	●	●
Other Vehicle		L25201 - L86901	RCM - Restraints control module	●	●	●	●
Other Vehicle		L25201 - L86901	REM - Rear electronic control module.	●	●	●	●
Other Vehicle		L25201 - L86901	RES - Vehicle emergency control module	●	○	●	●
Other Vehicle		L25201 - L86901	SCL - Steering column lock module	●	○	●	○
Other Vehicle		L25201 - L86901	TCU - Throttle control unit.	●	○	●	○
Other Vehicle		L25201 - L86901	VAM - Voice activation control module.	●	○	●	●
Other Vehicle		L86902 - L99999	ABS - Anti-lock braking system	●	●	●	●
Other Vehicle		L86902 - L99999	ADS - Adaptive damping system.	●	●	●	●
Other Vehicle		L86902 - L99999	CCM - Climate control module	●	●	●	●
Other Vehicle		L86902 - L99999	CPM - Cellular telephone control module	●	○	●	●
Other Vehicle		L86902 - L99999	DDM - Driver's door module	●	●	●	●
Other Vehicle		L86902 - L99999	DSM - Driver's seat module	●	●	●	●
Other Vehicle		L86902 - L99999	GEM - General electronics control module.	●	●	●	●
Other Vehicle		L86902 - L99999	ICE - Audio unit.	●	●	●	●
Other Vehicle		L86902 - L99999	IPK - Instrument pack	●	●	●	●
Other Vehicle		L86902 - L99999	MCC - Message center control module	●	●	●	●
Other Vehicle		L86902 - L99999	NAV - Navigation control module	●	●	●	○
Other Vehicle		L86902 - L99999	PAM - Parking aid control module.	●	●	●	●
Other Vehicle		L86902 - L99999	PCM - Powertrain control module	●	●	●	●
Other Vehicle		L86902 - L99999	RCM - Restraints control module	●	●	●	●
Other Vehicle		L86902 - L99999	REM - Rear electronic control module.	●	●	●	●

Vehicle model	Year	Engine Type/Chassis Number	System Name	Information	Read TroubleCode	Clear TroubleCode	Read DataStream
Other Vehicle		L86902 - L99999	RES - Vehicle emergency control module	●	○	●	●
Other Vehicle		L86902 - L99999	SCL - Steering column lock module	●	○	●	○
Other Vehicle		L86902 - L99999	TCU - Throttle control unit.	●	○	●	○
Other Vehicle		L86902 - L99999	VAM - Voice activation control module.	●	○	●	●
Other Vehicle		M00001 - M44997	ABS - Anti-lock braking system	●	●	●	●
Other Vehicle		M00001 - M44997	ADS - Adaptive damping system.	●	●	●	●
Other Vehicle		M00001 - M44997	CCM - Climate control module	●	●	●	●
Other Vehicle		M00001 - M44997	CPM - Cellular telephone control module	●	○	●	●
Other Vehicle		M00001 - M44997	DDM - Driver's door module	●	●	●	●
Other Vehicle		M00001 - M44997	DSM - Driver's seat module	●	●	●	●
Other Vehicle		M00001 - M44997	GEM - General electronics control module.	●	●	●	●
Other Vehicle		M00001 - M44997	ICE - Audio unit.	●	●	●	●
Other Vehicle		M00001 - M44997	IPK - Instrument pack	●	●	●	●
Other Vehicle		M00001 - M44997	MCC - Message center control module	●	●	●	●
Other Vehicle		M00001 - M44997	NAV - Navigation control module	●	●	●	○
Other Vehicle		M00001 - M44997	PAM - Parking aid control module.	●	●	●	●
Other Vehicle		M00001 - M44997	PCM - Powertrain control module	●	●	●	●
Other Vehicle		M00001 - M44997	RCM - Restraints control module	●	●	●	●
Other Vehicle		M00001 - M44997	REM - Rear electronic control module.	●	●	●	●
Other Vehicle		M00001 - M44997	RES - Vehicle emergency control module	●	○	●	●
Other Vehicle		M00001 - M44997	SCL - Steering column lock module	●	○	●	○
Other Vehicle		M00001 - M44997	TCU - Throttle control unit.	●	○	●	○
Other Vehicle		M00001 - M44997	VAM - Voice activation control module.	●	○	●	●
Other Vehicle		M44998 - M99999	ABS - Anti-lock braking system	●	●	●	●
Other Vehicle		M44998 - M99999	ACC - Adaptive speed control control module.	●	●	●	●
Other Vehicle		M44998 - M99999	ADHLS - Headlamp levelling system.	○	●	●	●
Other Vehicle		M44998 - M99999	ADRC - Adaptive damping ride control.	○	●	●	●
Other Vehicle		M44998 - M99999	AMP - Amplifier	●	●	●	●
Other Vehicle		M44998 - M99999	ARM - Restraints control module	●	●	●	●
Other Vehicle		M44998 - M99999	ATC - Climate control module	●	●	●	●
Other Vehicle		M44998 - M99999	CPM - Cellular telephone control module	●	●	●	●
Other Vehicle		M44998 - M99999	DDM - Driver's door module	●	●	●	●
Other Vehicle		M44998 - M99999	DSM - Driver's seat module	●	●	●	●
Other Vehicle		M44998 - M99999	ECM - Engine control module	●	●	●	●
Other Vehicle		M44998 - M99999	EPB - Electronic parking brake	●	●	●	●
Other Vehicle		M44998 - M99999	FETM - Audio unit.	●	●	●	●
Other Vehicle		M44998 - M99999	GEM - General electronics control module.	●	●	●	●
Other Vehicle		M44998 - M99999	IP - Instrument pack	●	●	●	●
Other Vehicle		M44998 - M99999	ISM - Intrusion sensor module	●	●	●	●
Other Vehicle		M44998 - M99999	NAV - Navigation control module	●	●	●	●
Other Vehicle		M44998 - M99999	PAM - Parking aid control module.	●	●	●	●
Other Vehicle		M44998 - M99999	REM - Rear electronic control module.	●	●	●	●
Other Vehicle		M44998 - M99999	SCLM - Steering column lock module	●	●	●	●
Other Vehicle		M44998 - M99999	TCM - Transmission control module	●	●	●	●
Other Vehicle		M44998 - M99999	VACM - Voice activation control module.	●	●	●	●
Other Vehicle		N00001 - N13088	ABS - Anti-lock braking system	●	●	●	●
Other Vehicle		N00001 - N13088	ACC - Adaptive speed control control module.	●	●	●	●
Other Vehicle		N00001 - N13088	ADHLS - Headlamp levelling system.	○	●	●	●
Other Vehicle		N00001 - N13088	ADRC - Adaptive damping ride control.	○	●	●	●
Other Vehicle		N00001 - N13088	AMP - Amplifier	●	●	●	●
Other Vehicle		N00001 - N13088	ARM - Restraints control module	●	●	●	●
Other Vehicle		N00001 - N13088	ATC - Climate control module	●	●	●	●
Other Vehicle		N00001 - N13088	CPM - Cellular telephone control module	●	●	●	●
Other Vehicle		N00001 - N13088	DDM - Driver's door module	●	●	●	●
Other Vehicle		N00001 - N13088	DSM - Driver's seat module	●	●	●	●
Other Vehicle		N00001 - N13088	ECM - Engine control module	●	●	●	●
Other Vehicle		N00001 - N13088	EPB - Electronic parking brake	●	●	●	●
Other Vehicle		N00001 - N13088	FETM - Audio unit.	●	●	●	●
Other Vehicle		N00001 - N13088	GEM - General electronics control module.	●	●	●	●
Other Vehicle		N00001 - N13088	IP - Instrument pack	●	●	●	●
Other Vehicle		N00001 - N13088	ISM - Intrusion sensor module	●	●	●	●
Other Vehicle		N00001 - N13088	NAV - Navigation control module	●	●	●	●
Other Vehicle		N00001 - N13088	PAM - Parking aid control module.	●	●	●	●
Other Vehicle		N00001 - N13088	REM - Rear electronic control module.	●	●	●	●
Other Vehicle		N00001 - N13088	SCLM - Steering column lock module	●	●	●	●
Other Vehicle		N00001 - N13088	TCM - Transmission control module	●	●	●	●
Other Vehicle		N00001 - N13088	VACM - Voice activation control module.	●	●	●	●
S-Type	2004-2005	AJ61 2.5L engine	ABS - Anti-lock braking system	●	●	●	●
S-Type	2004-2005	AJ61 2.5L engine	ACC - Adaptive speed control control module.	●	●	●	●
S-Type	2004-2005	AJ61 2.5L engine	ADHLS - Headlamp levelling system.	○	●	●	●
S-Type	2004-2005	AJ61 2.5L engine	ADRC - Adaptive damping ride control.	○	●	●	●
S-Type	2004-2005	AJ61 2.5L engine	AMP - Amplifier	●	●	●	●
S-Type	2004-2005	AJ61 2.5L engine	ARM - Restraints control module	●	●	●	●
S-Type	2004-2005	AJ61 2.5L engine	ATC - Climate control module	●	●	●	●
S-Type	2004-2005	AJ61 2.5L engine	CPM - Cellular telephone control module	●	●	●	●
S-Type	2004-2005	AJ61 2.5L engine	DDM - Driver's door module	●	●	●	●
S-Type	2004-2005	AJ61 2.5L engine	DSM - Driver's seat module	●	●	●	●
S-Type	2004-2005	AJ61 2.5L engine	ECM - Engine control module	●	●	●	●
S-Type	2004-2005	AJ61 2.5L engine	FETM - Audio unit.	●	●	●	●
S-Type	2004-2005	AJ61 2.5L engine	GEM - General electronics control module.	●	●	●	●
S-Type	2004-2005	AJ61 2.5L engine	IP - Instrument pack	●	●	●	●
S-Type	2004-2005	AJ61 2.5L engine	ISM - Intrusion sensor module	●	●	●	●
S-Type	2004-2005	AJ61 2.5L engine	NAV - Navigation control module	●	●	●	●
S-Type	2004-2005	AJ61 2.5L engine	PAM - Parking aid control module.	●	●	●	●
S-Type	2004-2005	AJ61 2.5L engine	PBM - Parking brake control module	●	●	●	●
S-Type	2004-2005	AJ61 2.5L engine	REM - Rear electronic control module.	●	●	●	●
S-Type	2004-2005	AJ61 2.5L engine	SCLM - Steering column lock module	●	●	●	●

Vevhicle model	Year	Engine Type/Chassis Number	System Name	Information	Read TroubleCode	Clear TroubleCode	Read DataStream
S-Type	2004-2005	AJ61 2.5L engine	TCM - Transmission control module	●	●	●	●
S-Type	2004-2005	AJ61 2.5L engine	VACM - Voice activation control module.	●	●	●	●
S-Type	2004-2005	AJ61 3.0L engine	ABS - Anti-lock braking system	●	●	●	●
S-Type	2004-2005	AJ61 3.0L engine	ACC - Adaptive speed control control module.	●	●	●	●
S-Type	2004-2005	AJ61 3.0L engine	ADHLS - Headlamp levelling system.	○	●	●	●
S-Type	2004-2005	AJ61 3.0L engine	ADRC - Adaptive damping ride control.	○	●	●	●
S-Type	2004-2005	AJ61 3.0L engine	AMP - Amplifier	●	●	●	●
S-Type	2004-2005	AJ61 3.0L engine	ARM - Restraints control module	●	●	●	●
S-Type	2004-2005	AJ61 3.0L engine	ATC - Climate control module	●	●	●	●
S-Type	2004-2005	AJ61 3.0L engine	CPM - Cellular telephone control module	●	●	●	●
S-Type	2004-2005	AJ61 3.0L engine	DDM - Driver's door module	●	●	●	●
S-Type	2004-2005	AJ61 3.0L engine	DSM - Driver's seat module	●	●	●	●
S-Type	2004-2005	AJ61 3.0L engine	ECM - Engine control module	●	●	●	●
S-Type	2004-2005	AJ61 3.0L engine	FETM - Audio unit.	●	●	●	●
S-Type	2004-2005	AJ61 3.0L engine	GEM - General electronics control module.	●	●	●	●
S-Type	2004-2005	AJ61 3.0L engine	IP - Instrument pack	●	●	●	●
S-Type	2004-2005	AJ61 3.0L engine	ISM - Intrusion sensor module	●	●	●	●
S-Type	2004-2005	AJ61 3.0L engine	NAV - Navigation control module	●	●	●	●
S-Type	2004-2005	AJ61 3.0L engine	PAM - Parking aid control module.	●	●	●	●
S-Type	2004-2005	AJ61 3.0L engine	PBM - Parking brake control module	●	●	●	●
S-Type	2004-2005	AJ61 3.0L engine	REM - Rear electronic control module.	●	●	●	●
S-Type	2004-2005	AJ61 3.0L engine	SCLM - Steering column lock module	●	●	●	●
S-Type	2004-2005	AJ61 3.0L engine	TCM - Transmission control module	●	●	●	●
S-Type	2004-2005	AJ61 3.0L engine	VACM - Voice activation control module.	●	●	●	●
S-Type	2004-2005	AJ61 4.2L engine	ABS - Anti-lock braking system	●	●	●	●
S-Type	2004-2005	AJ61 4.2L engine	ACC - Adaptive speed control control module.	●	●	●	●
S-Type	2004-2005	AJ61 4.2L engine	ADHLS - Headlamp levelling system.	○	●	●	●
S-Type	2004-2005	AJ61 4.2L engine	ADRC - Adaptive damping ride control.	○	●	●	●
S-Type	2004-2005	AJ61 4.2L engine	AMP - Amplifier	●	●	●	●
S-Type	2004-2005	AJ61 4.2L engine	ARM - Restraints control module	●	●	●	●
S-Type	2004-2005	AJ61 4.2L engine	ATC - Climate control module	●	●	●	●
S-Type	2004-2005	AJ61 4.2L engine	CPM - Cellular telephone control module	●	●	●	●
S-Type	2004-2005	AJ61 4.2L engine	DDM - Driver's door module	●	●	●	●
S-Type	2004-2005	AJ61 4.2L engine	DSM - Driver's seat module	●	●	●	●
S-Type	2004-2005	AJ61 4.2L engine	ECM - Engine control module	●	●	●	●
S-Type	2004-2005	AJ61 4.2L engine	FETM - Audio unit.	●	●	●	●
S-Type	2004-2005	AJ61 4.2L engine	GEM - General electronics control module.	●	●	●	●
S-Type	2004-2005	AJ61 4.2L engine	IP - Instrument pack	●	●	●	●
S-Type	2004-2005	AJ61 4.2L engine	ISM - Intrusion sensor module	●	●	●	●
S-Type	2004-2005	AJ61 4.2L engine	NAV - Navigation control module	●	●	●	●
S-Type	2004-2005	AJ61 4.2L engine	PAM - Parking aid control module.	●	●	●	●
S-Type	2004-2005	AJ61 4.2L engine	PBM - Parking brake control module	●	●	●	●
S-Type	2004-2005	AJ61 4.2L engine	REM - Rear electronic control module.	●	●	●	●
S-Type	2004-2005	AJ61 4.2L engine	SCLM - Steering column lock module	●	●	●	●
S-Type	2004-2005	AJ61 4.2L engine	TCM - Transmission control module	●	●	●	●
S-Type	2004-2005	AJ61 4.2L engine	VACM - Voice activation control module.	●	●	●	●
S-Type	2004-2005	Diesel V6	ABS - Anti-lock braking system	●	●	●	●
S-Type	2004-2005	Diesel V6	ACC - Adaptive speed control control module.	●	●	●	●
S-Type	2004-2005	Diesel V6	ADHLS - Headlamp levelling system.	○	●	●	●
S-Type	2004-2005	Diesel V6	ADRC - Adaptive damping ride control.	○	●	●	●
S-Type	2004-2005	Diesel V6	AHCM - Auxiliary heater control module	●	●	●	●
S-Type	2004-2005	Diesel V6	AMP - Amplifier	●	●	●	●
S-Type	2004-2005	Diesel V6	ARM - Restraints control module	●	●	●	●
S-Type	2004-2005	Diesel V6	ATC - Climate control module	●	●	●	●
S-Type	2004-2005	Diesel V6	CPM - Cellular telephone control module	●	●	●	●
S-Type	2004-2005	Diesel V6	DDM - Driver's door module	●	●	●	●
S-Type	2004-2005	Diesel V6	DSM - Driver's seat module	●	●	●	●
S-Type	2004-2005	Diesel V6	FETM - Audio unit.	●	●	●	●
S-Type	2004-2005	Diesel V6	GEM - General electronics control module.	●	●	●	●
S-Type	2004-2005	Diesel V6	IP - Instrument pack	●	●	●	●
S-Type	2004-2005	Diesel V6	ISM - Intrusion sensor module	●	●	●	●
S-Type	2004-2005	Diesel V6	NAV - Navigation control module	●	●	●	●
S-Type	2004-2005	Diesel V6	PAM - Parking aid control module.	●	●	●	●
S-Type	2004-2005	Diesel V6	PBM - Parking brake control module	●	●	●	●
S-Type	2004-2005	Diesel V6	PCM - Powertrain control module	●	●	●	●
S-Type	2004-2005	Diesel V6	REM - Rear electronic control module.	●	●	●	●
S-Type	2004-2005	Diesel V6	SCLM - Steering column lock module	●	●	●	●
S-Type	2004-2005	Diesel V6	TCM - Transmission control module	●	●	●	●
S-Type	2004-2005	Diesel V6	VACM - Voice activation control module.	●	●	●	●
S-Type	2006-2008	Diesel V6	ABS - Anti-lock braking system	●	●	●	●
S-Type	2006-2008	Diesel V6	ACC - Adaptive speed control control module.	○	●	●	●
S-Type	2006-2008	Diesel V6	ADHLS - Headlamp levelling system.	○	●	●	●
S-Type	2006-2008	Diesel V6	ADRC - Adaptive damping ride control.	○	●	●	●
S-Type	2006-2008	Diesel V6	AHCM - Auxiliary heater control module	●	●	●	●
S-Type	2006-2008	Diesel V6	AMP - Amplifier	○	●	●	●
S-Type	2006-2008	Diesel V6	ARM - Restraints control module	○	●	●	●
S-Type	2006-2008	Diesel V6	ATC - Climate control module	○	●	●	●
S-Type	2006-2008	Diesel V6	CPM - Cellular telephone control module	○	●	●	●
S-Type	2006-2008	Diesel V6	DDM - Driver's door module	○	●	●	●
S-Type	2006-2008	Diesel V6	DSM - Driver's seat module	○	●	●	●
S-Type	2006-2008	Diesel V6	FETM - Audio unit.	○	●	●	●
S-Type	2006-2008	Diesel V6	GEM - General electronics control module.	○	●	●	●
S-Type	2006-2008	Diesel V6	IP - Instrument pack	●	●	●	●
S-Type	2006-2008	Diesel V6	ISM - Intrusion sensor module	○	●	●	●
S-Type	2006-2008	Diesel V6	NAV - Navigation control module	○	●	●	●
S-Type	2006-2008	Diesel V6	PAM - Parking aid control module.	○	●	●	●
S-Type	2006-2008	Diesel V6	PBM - Parking brake control module	●	●	●	●



Vehchile model	Year	Engine Type/Chassis Number	System Name	Information	Read TroubleCode	Clear TroubleCode	Read DataStream
S-Type	2006-2008	Diesel V6	PCM - Powertrain control module	●	●	●	●
S-Type	2006-2008	Diesel V6	REM - Rear electronic control module.	○	●	●	●
S-Type	2006-2008	Diesel V6	SCLM - Steering column lock module	○	●	●	●
S-Type	2006-2008	Diesel V6	TCM - Transmission control module	○	●	●	●
S-Type	2006-2008	Diesel V6	TPM - Tire pressure monitor module	●	●	●	●
S-Type	2006-2008	Diesel V6	VACM - Voice activation control module.	○	●	●	●
S-Type	2006-2008	Normally aspirated V6 2.5L engine	ABS - Anti-lock braking system	●	●	●	●
S-Type	2006-2008	Normally aspirated V6 2.5L engine	ACC - Adaptive speed control control module.	○	●	●	●
S-Type	2006-2008	Normally aspirated V6 2.5L engine	ADHLS - Headlamp levelling system.	○	●	●	●
S-Type	2006-2008	Normally aspirated V6 2.5L engine	ADRC - Adaptive damping ride control.	○	●	●	●
S-Type	2006-2008	Normally aspirated V6 2.5L engine	AMP - Amplifier	○	●	●	●
S-Type	2006-2008	Normally aspirated V6 2.5L engine	ARM - Restraints control module	○	●	●	●
S-Type	2006-2008	Normally aspirated V6 2.5L engine	ATC - Climate control module	○	●	●	●
S-Type	2006-2008	Normally aspirated V6 2.5L engine	CPM - Cellular telephone control module	○	●	●	●
S-Type	2006-2008	Normally aspirated V6 2.5L engine	DDM - Driver's door module	○	●	●	●
S-Type	2006-2008	Normally aspirated V6 2.5L engine	DSM - Driver's seat module	○	●	●	●
S-Type	2006-2008	Normally aspirated V6 2.5L engine	FETM - Audio unit.	○	●	●	●
S-Type	2006-2008	Normally aspirated V6 2.5L engine	GEM - General electronics control module.	○	●	●	●
S-Type	2006-2008	Normally aspirated V6 2.5L engine	IP - Instrument pack	●	●	●	●
S-Type	2006-2008	Normally aspirated V6 2.5L engine	ISM - Intrusion sensor module	○	●	●	●
S-Type	2006-2008	Normally aspirated V6 2.5L engine	NAV - Navigation control module	○	●	●	●
S-Type	2006-2008	Normally aspirated V6 2.5L engine	PAM - Parking aid control module.	○	●	●	●
S-Type	2006-2008	Normally aspirated V6 2.5L engine	PBM - Parking brake control module	●	●	●	●
S-Type	2006-2008	Normally aspirated V6 2.5L engine	PCM - Powertrain control module	●	●	●	●
S-Type	2006-2008	Normally aspirated V6 2.5L engine	REM - Rear electronic control module.	○	●	●	●
S-Type	2006-2008	Normally aspirated V6 2.5L engine	SCLM - Steering column lock module	○	●	●	●
S-Type	2006-2008	Normally aspirated V6 2.5L engine	TCM - Transmission control module	○	●	●	●
S-Type	2006-2008	Normally aspirated V6 2.5L engine	TPM - Tire pressure monitor module	●	●	●	●
S-Type	2006-2008	Normally aspirated V6 2.5L engine	VACM - Voice activation control module.	○	●	●	●
S-Type	2006-2008	Normally aspirated V6 3.0L engine	ABS - Anti-lock braking system	●	●	●	●
S-Type	2006-2008	Normally aspirated V6 3.0L engine	ACC - Adaptive speed control control module.	○	●	●	●
S-Type	2006-2008	Normally aspirated V6 3.0L engine	ADHLS - Headlamp levelling system.	○	●	●	●
S-Type	2006-2008	Normally aspirated V6 3.0L engine	ADRC - Adaptive damping ride control.	○	●	●	●
S-Type	2006-2008	Normally aspirated V6 3.0L engine	AMP - Amplifier	○	●	●	●
S-Type	2006-2008	Normally aspirated V6 3.0L engine	ARM - Restraints control module	○	●	●	●
S-Type	2006-2008	Normally aspirated V6 3.0L engine	ATC - Climate control module	○	●	●	●
S-Type	2006-2008	Normally aspirated V6 3.0L engine	CPM - Cellular telephone control module	○	●	●	●
S-Type	2006-2008	Normally aspirated V6 3.0L engine	DDM - Driver's door module	○	●	●	●
S-Type	2006-2008	Normally aspirated V6 3.0L engine	DSM - Driver's seat module	○	●	●	●
S-Type	2006-2008	Normally aspirated V6 3.0L engine	FETM - Audio unit.	○	●	●	●
S-Type	2006-2008	Normally aspirated V6 3.0L engine	GEM - General electronics control module.	○	●	●	●
S-Type	2006-2008	Normally aspirated V6 3.0L engine	IP - Instrument pack	●	●	●	●
S-Type	2006-2008	Normally aspirated V6 3.0L engine	ISM - Intrusion sensor module	○	●	●	●
S-Type	2006-2008	Normally aspirated V6 3.0L engine	NAV - Navigation control module	○	●	●	●
S-Type	2006-2008	Normally aspirated V6 3.0L engine	PAM - Parking aid control module.	○	●	●	●
S-Type	2006-2008	Normally aspirated V6 3.0L engine	PBM - Parking brake control module	●	●	●	●
S-Type	2006-2008	Normally aspirated V6 3.0L engine	PCM - Powertrain control module	●	●	●	●
S-Type	2006-2008	Normally aspirated V6 3.0L engine	REM - Rear electronic control module.	○	●	●	●
S-Type	2006-2008	Normally aspirated V6 3.0L engine	SCLM - Steering column lock module	○	●	●	●
S-Type	2006-2008	Normally aspirated V6 3.0L engine	TCM - Transmission control module	○	●	●	●
S-Type	2006-2008	Normally aspirated V6 3.0L engine	TPM - Tire pressure monitor module	●	●	●	●
S-Type	2006-2008	Normally aspirated V6 3.0L engine	VACM - Voice activation control module.	○	●	●	●
S-Type	2006-2008	Normally aspirated V8	ABS - Anti-lock braking system	●	●	●	●
S-Type	2006-2008	Normally aspirated V8	ACC - Adaptive speed control control module.	○	●	●	●
S-Type	2006-2008	Normally aspirated V8	ADHLS - Headlamp levelling system.	○	●	●	●
S-Type	2006-2008	Normally aspirated V8	ADRC - Adaptive damping ride control.	○	●	●	●
S-Type	2006-2008	Normally aspirated V8	AMP - Amplifier	○	●	●	●
S-Type	2006-2008	Normally aspirated V8	ARM - Restraints control module	○	●	●	●
S-Type	2006-2008	Normally aspirated V8	ATC - Climate control module	○	●	●	●
S-Type	2006-2008	Normally aspirated V8	CPM - Cellular telephone control module	○	●	●	●
S-Type	2006-2008	Normally aspirated V8	DDM - Driver's door module	○	●	●	●
S-Type	2006-2008	Normally aspirated V8	DSM - Driver's seat module	○	●	●	●
S-Type	2006-2008	Normally aspirated V8	FETM - Audio unit.	○	●	●	●
S-Type	2006-2008	Normally aspirated V8	GEM - General electronics control module.	○	●	●	●
S-Type	2006-2008	Normally aspirated V8	IP - Instrument pack	●	●	●	●
S-Type	2006-2008	Normally aspirated V8	ISM - Intrusion sensor module	○	●	●	●
S-Type	2006-2008	Normally aspirated V8	NAV - Navigation control module	○	●	●	●
S-Type	2006-2008	Normally aspirated V8	PAM - Parking aid control module.	○	●	●	●
S-Type	2006-2008	Normally aspirated V8	PBM - Parking brake control module	●	●	●	●
S-Type	2006-2008	Normally aspirated V8	PCM - Powertrain control module	●	●	●	●
S-Type	2006-2008	Normally aspirated V8	REM - Rear electronic control module.	○	●	●	●
S-Type	2006-2008	Normally aspirated V8	SCLM - Steering column lock module	○	●	●	●
S-Type	2006-2008	Normally aspirated V8	TCM - Transmission control module	○	●	●	●
S-Type	2006-2008	Normally aspirated V8	TPM - Tire pressure monitor module	●	●	●	●
S-Type	2006-2008	Normally aspirated V8	VACM - Voice activation control module.	○	●	●	●
S-Type	2006-2008	Supercharged V8	ABS - Anti-lock braking system	●	●	●	●
S-Type	2006-2008	Supercharged V8	ACC - Adaptive speed control control module.	○	●	●	●
S-Type	2006-2008	Supercharged V8	ADHLS - Headlamp levelling system.	○	●	●	●
S-Type	2006-2008	Supercharged V8	ADRC - Adaptive damping ride control.	○	●	●	●
S-Type	2006-2008	Supercharged V8	AMP - Amplifier	○	●	●	●
S-Type	2006-2008	Supercharged V8	ARM - Restraints control module	○	●	●	●
S-Type	2006-2008	Supercharged V8	ATC - Climate control module	○	●	●	●
S-Type	2006-2008	Supercharged V8	CPM - Cellular telephone control module	○	●	●	●
S-Type	2006-2008	Supercharged V8	DDM - Driver's door module	○	●	●	●
S-Type	2006-2008	Supercharged V8	DSM - Driver's seat module	○	●	●	●
S-Type	2006-2008	Supercharged V8	FETM - Audio unit.	○	●	●	●
S-Type	2006-2008	Supercharged V8	GEM - General electronics control module.	○	●	●	●

Vevhicle model	Year	Engine Type/Chassis Number	System Name	Information	Read TroubleCode	Clear TroubleCode	Read DataStream
S-Type	2006-2008	Supercharged V8	IP - Instrument pack	●	●	●	●
S-Type	2006-2008	Supercharged V8	ISM - Intrusion sensor module	○	●	●	●
S-Type	2006-2008	Supercharged V8	NAV - Navigation control module	○	●	●	●
S-Type	2006-2008	Supercharged V8	PAM - Parking aid control module.	○	●	●	●
S-Type	2006-2008	Supercharged V8	PBM - Parking brake control module	●	●	●	●
S-Type	2006-2008	Supercharged V8	PCM - Powertrain control module	●	●	●	●
S-Type	2006-2008	Supercharged V8	REM - Rear electronic control module.	○	●	●	●
S-Type	2006-2008	Supercharged V8	SCLM - Steering column lock module	○	●	●	●
S-Type	2006-2008	Supercharged V8	TCM - Transmission control module	○	●	●	●
S-Type	2006-2008	Supercharged V8	TPM - Tire pressure monitor module	●	●	●	●
S-Type	2006-2008	Supercharged V8	VACM - Voice activation control module.	○	●	●	●
X-Type	2001-2003	AJ61 2.0L engine	ABS - Anti-lock braking system	●	●	●	●
X-Type	2001-2003	AJ61 2.0L engine	ADHLS - Headlamp levelling system.	●	●	●	●
X-Type	2001-2003	AJ61 2.0L engine	ARM - Restraints control module	●	●	●	●
X-Type	2001-2003	AJ61 2.0L engine	ATC - Climate control module	●	●	●	●
X-Type	2001-2003	AJ61 2.0L engine	CPM - Cellular telephone control module	●	●	●	●
X-Type	2001-2003	AJ61 2.0L engine	ECM - Engine control module	●	●	●	●
X-Type	2001-2003	AJ61 2.0L engine	FETM - Audio unit.	●	●	●	●
X-Type	2001-2003	AJ61 2.0L engine	GEM - General electronics control module.	●	●	●	●
X-Type	2001-2003	AJ61 2.0L engine	IP - Instrument pack	●	●	●	●
X-Type	2001-2003	AJ61 2.0L engine	ISM - Intrusion sensor module	●	●	●	○
X-Type	2001-2003	AJ61 2.0L engine	NAV - Navigation control module	●	●	●	●
X-Type	2001-2003	AJ61 2.0L engine	PAM - Parking aid control module.	●	●	●	●
X-Type	2001-2003	AJ61 2.0L engine	TCM - Transmission control module	●	●	●	●
X-Type	2001-2003	AJ61 2.0L engine	VACM - Voice activation control module.	●	●	●	●
X-Type	2001-2003	AJ61 2.5L engine	ABS - Anti-lock braking system	●	●	●	●
X-Type	2001-2003	AJ61 2.5L engine	ADHLS - Headlamp levelling system.	●	●	●	●
X-Type	2001-2003	AJ61 2.5L engine	ARM - Restraints control module	●	●	●	●
X-Type	2001-2003	AJ61 2.5L engine	ATC - Climate control module	●	●	●	●
X-Type	2001-2003	AJ61 2.5L engine	CPM - Cellular telephone control module	●	●	●	●
X-Type	2001-2003	AJ61 2.5L engine	ECM - Engine control module	●	●	●	●
X-Type	2001-2003	AJ61 2.5L engine	FETM - Audio unit.	●	●	●	●
X-Type	2001-2003	AJ61 2.5L engine	GEM - General electronics control module.	●	●	●	●
X-Type	2001-2003	AJ61 2.5L engine	IP - Instrument pack	●	●	●	●
X-Type	2001-2003	AJ61 2.5L engine	ISM - Intrusion sensor module	●	●	●	○
X-Type	2001-2003	AJ61 2.5L engine	NAV - Navigation control module	●	●	●	●
X-Type	2001-2003	AJ61 2.5L engine	PAM - Parking aid control module.	●	●	●	●
X-Type	2001-2003	AJ61 2.5L engine	TCM - Transmission control module	●	●	●	●
X-Type	2001-2003	AJ61 2.5L engine	VACM - Voice activation control module.	●	●	●	●
X-Type	2001-2003	AJ61 3.0L engine	ABS - Anti-lock braking system	●	●	●	●
X-Type	2001-2003	AJ61 3.0L engine	ADHLS - Headlamp levelling system.	●	●	●	●
X-Type	2001-2003	AJ61 3.0L engine	ARM - Restraints control module	●	●	●	●
X-Type	2001-2003	AJ61 3.0L engine	ATC - Climate control module	●	●	●	●
X-Type	2001-2003	AJ61 3.0L engine	CPM - Cellular telephone control module	●	●	●	●
X-Type	2001-2003	AJ61 3.0L engine	ECM - Engine control module	●	●	●	●
X-Type	2001-2003	AJ61 3.0L engine	FETM - Audio unit.	●	●	●	●
X-Type	2001-2003	AJ61 3.0L engine	GEM - General electronics control module.	●	●	●	●
X-Type	2001-2003	AJ61 3.0L engine	IP - Instrument pack	●	●	●	●
X-Type	2001-2003	AJ61 3.0L engine	ISM - Intrusion sensor module	●	●	●	○
X-Type	2001-2003	AJ61 3.0L engine	NAV - Navigation control module	●	●	●	●
X-Type	2001-2003	AJ61 3.0L engine	PAM - Parking aid control module.	●	●	●	●
X-Type	2001-2003	AJ61 3.0L engine	TCM - Transmission control module	●	●	●	●
X-Type	2001-2003	AJ61 3.0L engine	VACM - Voice activation control module.	●	●	●	●
X-Type	2004-	AJ61 2.0L engine	ADHLS - Headlamp levelling system.	○	●	●	●
X-Type	2004-	AJ61 2.0L engine	AMP - Amplifier	○	●	●	●
X-Type	2004-	AJ61 2.0L engine	ARM - Restraints control module	○	●	●	●
X-Type	2004-	AJ61 2.0L engine	CPM - Cellular telephone control module	○	●	●	●
X-Type	2004-	AJ61 2.0L engine	FFH - Fuel fired heater module	○	●	●	○
X-Type	2004-	AJ61 2.0L engine	ISM - Intrusion sensor module	○	●	●	●
X-Type	2004-	AJ61 2.0L engine	PAM - Parking aid control module.	○	●	●	●
X-Type	2004-	AJ61 2.0L engine	VACM - Voice activation control module.	○	●	●	●
X-Type	2004-	AJ61 2.5L engine	ADHLS - Headlamp levelling system.	○	●	●	●
X-Type	2004-	AJ61 2.5L engine	AMP - Amplifier	○	●	●	●
X-Type	2004-	AJ61 2.5L engine	ARM - Restraints control module	○	●	●	●
X-Type	2004-	AJ61 2.5L engine	CPM - Cellular telephone control module	○	●	●	●
X-Type	2004-	AJ61 2.5L engine	FFH - Fuel fired heater module	○	●	●	○
X-Type	2004-	AJ61 2.5L engine	ISM - Intrusion sensor module	○	●	●	●
X-Type	2004-	AJ61 2.5L engine	PAM - Parking aid control module.	○	●	●	●
X-Type	2004-	AJ61 2.5L engine	VACM - Voice activation control module.	○	●	●	●
X-Type	2004-	AJ61 3.0L engine	ADHLS - Headlamp levelling system.	○	●	●	●
X-Type	2004-	AJ61 3.0L engine	AMP - Amplifier	○	●	●	●
X-Type	2004-	AJ61 3.0L engine	ARM - Restraints control module	○	●	●	●
X-Type	2004-	AJ61 3.0L engine	CPM - Cellular telephone control module	○	●	●	●
X-Type	2004-	AJ61 3.0L engine	FFH - Fuel fired heater module	○	●	●	○
X-Type	2004-	AJ61 3.0L engine	ISM - Intrusion sensor module	○	●	●	●
X-Type	2004-	AJ61 3.0L engine	PAM - Parking aid control module.	○	●	●	●
X-Type	2004-	AJ61 3.0L engine	VACM - Voice activation control module.	○	●	●	●
X-Type	2004-	TDCi 2.0L engine	ADHLS - Headlamp levelling system.	○	●	●	●
X-Type	2004-	TDCi 2.0L engine	AMP - Amplifier	○	●	●	●
X-Type	2004-	TDCi 2.0L engine	ARM - Restraints control module	○	●	●	●
X-Type	2004-	TDCi 2.0L engine	CPM - Cellular telephone control module	○	●	●	●
X-Type	2004-	TDCi 2.0L engine	FFH - Fuel fired heater module	○	●	●	●
X-Type	2004-	TDCi 2.0L engine	ISM - Intrusion sensor module	○	●	●	●
X-Type	2004-	TDCi 2.0L engine	PAM - Parking aid control module.	○	●	●	●
X-Type	2004-	TDCi 2.0L engine	VACM - Voice activation control module.	○	●	●	●
X-Type	2004-	TDCi 2.2L engine	ADHLS - Headlamp levelling system.	○	●	●	●
X-Type	2004-	TDCi 2.2L engine	AMP - Amplifier	○	●	●	●

Vehcile model	Year	Engine Type/Chassis Number	System Name	Information	Read TroubleCode	Clear TroubleCode	Read DataStream
X-Type	2004-	TDCi 2.2L engine	ARM - Restraints control module	○	●	●	●
X-Type	2004-	TDCi 2.2L engine	CPM - Cellular telephone control module	○	●	●	●
X-Type	2004-	TDCi 2.2L engine	FFH - Fuel fired heater module	○	●	●	●
X-Type	2004-	TDCi 2.2L engine	ISM - Intrusion sensor module	○	●	●	●
X-Type	2004-	TDCi 2.2L engine	PAM - Parking aid control module.	○	●	●	●
X-Type	2004-	TDCi 2.2L engine	VACM - Voice activation control module.	○	●	●	●
XE	2016 -	Diesel I4 2.0L engine	AAM - Audio amplifier module	●	●	●	●
XE	2016 -	Diesel I4 2.0L engine	ABS - ABS control module	●	●	●	●
XE	2016 -	Diesel I4 2.0L engine	ACM - Audio front control module	●	●	●	●
XE	2016 -	Diesel I4 2.0L engine	AHU - InControl Touch audio head unit	●	●	●	○
XE	2016 -	Diesel I4 2.0L engine	ATCM - All terrain control module	●	●	●	●
XE	2016 -	Diesel I4 2.0L engine	AUCM - Head-up display cooling fan module	●	●	●	●
XE	2016 -	Diesel I4 2.0L engine	BCM - Body control module	●	●	●	●
XE	2016 -	Diesel I4 2.0L engine	CAV - Connect and view module	●	●	●	●
XE	2016 -	Diesel I4 2.0L engine	CCM - Speed control module	●	●	●	●
XE	2016 -	Diesel I4 2.0L engine	CHCM - Chassis control module	●	●	●	●
XE	2016 -	Diesel I4 2.0L engine	DABM - Digital audio broadcast module	●	●	●	●
XE	2016 -	Diesel I4 2.0L engine	DDM - Driver's door module	●	●	●	●
XE	2016 -	Diesel I4 2.0L engine	DRDM - Driver's (side) rear door module.	●	●	●	●
XE	2016 -	Diesel I4 2.0L engine	DSM - Driver's seat module	●	●	●	●
XE	2016 -	Diesel I4 2.0L engine	front)	●	●	●	●
XE	2016 -	Diesel I4 2.0L engine	FCIM - Integrated control panel	●	●	●	●
XE	2016 -	Diesel I4 2.0L engine	GSM - Gear shift module	●	●	●	●
XE	2016 -	Diesel I4 2.0L engine	GWM - Gateway module	●	●	●	●
XE	2016 -	Diesel I4 2.0L engine	HUD - Head up display	●	●	●	○
XE	2016 -	Diesel I4 2.0L engine	HVAC - Heating ventilation and air conditioning control module	●	●	●	●
XE	2016 -	Diesel I4 2.0L engine	IPC - Instrument cluster control module.	●	●	●	●
XE	2016 -	Diesel I4 2.0L engine	IPMA - Image processing control module A	●	●	●	●
XE	2016 -	Diesel I4 2.0L engine	IPMB - Image processing module B	●	●	●	●
XE	2016 -	Diesel I4 2.0L engine	NAV - Navigation control module	●	●	●	○
XE	2016 -	Diesel I4 2.0L engine	NCM - Navigation control module	●	●	●	●
XE	2016 -	Diesel I4 2.0L engine	OCS - Restraints occupant classification system module	●	●	●	●
XE	2016 -	Diesel I4 2.0L engine	PAM - Parking assist control module	●	●	●	●
XE	2016 -	Diesel I4 2.0L engine	PCM - Powertrain control module	●	●	●	●
XE	2016 -	Diesel I4 2.0L engine	PDM - Passenger's door module	●	●	●	●
XE	2016 -	Diesel I4 2.0L engine	PRDM - Passenger's (side) rear door module.	●	●	●	●
XE	2016 -	Diesel I4 2.0L engine	PSCM - Power steering control module	●	●	●	●
XE	2016 -	Diesel I4 2.0L engine	RCM - Restraints control module	●	●	●	●
XE	2016 -	Diesel I4 2.0L engine	RFA - Keyless vehicle module	●	●	●	●
XE	2016 -	Diesel I4 2.0L engine	RGTM - Rear gate / trunk module	●	●	●	●
XE	2016 -	Diesel I4 2.0L engine	SASM - Steering angle sensor module	●	●	●	●
XE	2016 -	Diesel I4 2.0L engine	SODL - Side object detection control module - Left	●	●	●	●
XE	2016 -	Diesel I4 2.0L engine	SODR - Side object detection control module - Right	●	●	●	●
XE	2016 -	Diesel I4 2.0L engine	SRM - Satellite audio unit module.	●	●	●	●
XE	2016 -	Diesel I4 2.0L engine	TBM - Deployable towbar control module	●	●	●	●
XE	2016 -	Diesel I4 2.0L engine	TCM - Transmission control module	●	●	●	●
XE	2016 -	Diesel I4 2.0L engine	TCU - Telematic control unit module	●	●	●	●
XE	2016 -	Diesel I4 2.0L engine	TPM - Tire pressure monitor module	●	●	●	●
XE	2016 -	Diesel I4 2.0L engine	TVM - Television module	●	●	●	●
XE	2016 -	Diesel I4 2.0L engine	VIM - Vehicle immobilizer control module	●	●	●	●
XE	2016 -	GTDI 2.0L engine	AAM - Audio amplifier module	●	●	●	●
XE	2016 -	GTDI 2.0L engine	ABS - ABS control module	●	●	●	●
XE	2016 -	GTDI 2.0L engine	ACM - Audio front control module	●	●	●	●
XE	2016 -	GTDI 2.0L engine	AHU - InControl Touch audio head unit	●	●	●	○
XE	2016 -	GTDI 2.0L engine	ATCM - All terrain control module	●	●	●	●
XE	2016 -	GTDI 2.0L engine	AUCM - Head-up display cooling fan module	●	●	●	●
XE	2016 -	GTDI 2.0L engine	BCM - Body control module	●	●	●	●
XE	2016 -	GTDI 2.0L engine	CAV - Connect and view module	●	●	●	●
XE	2016 -	GTDI 2.0L engine	CCM - Speed control module	●	●	●	●
XE	2016 -	GTDI 2.0L engine	CHCM - Chassis control module	●	●	●	●
XE	2016 -	GTDI 2.0L engine	DABM - Digital audio broadcast module	●	●	●	●
XE	2016 -	GTDI 2.0L engine	DDM - Driver's door module	●	●	●	●
XE	2016 -	GTDI 2.0L engine	DRDM - Driver's (side) rear door module.	●	●	●	●
XE	2016 -	GTDI 2.0L engine	DSM - Driver's seat module	●	●	●	●
XE	2016 -	GTDI 2.0L engine	front)	●	●	●	●
XE	2016 -	GTDI 2.0L engine	FCIM - Integrated control panel	●	●	●	●
XE	2016 -	GTDI 2.0L engine	GSM - Gear shift module	●	●	●	●
XE	2016 -	GTDI 2.0L engine	GWM - Gateway module	●	●	●	●
XE	2016 -	GTDI 2.0L engine	HUD - Head up display	●	●	●	○
XE	2016 -	GTDI 2.0L engine	HVAC - Heating ventilation and air conditioning control module	●	●	●	●
XE	2016 -	GTDI 2.0L engine	IPC - Instrument cluster control module.	●	●	●	●
XE	2016 -	GTDI 2.0L engine	IPMA - Image processing control module A	●	●	●	●
XE	2016 -	GTDI 2.0L engine	IPMB - Image processing module B	●	●	●	●
XE	2016 -	GTDI 2.0L engine	NAV - Navigation control module	●	●	●	○
XE	2016 -	GTDI 2.0L engine	NCM - Navigation control module	●	●	●	●
XE	2016 -	GTDI 2.0L engine	OCS - Restraints occupant classification system module	●	●	●	●
XE	2016 -	GTDI 2.0L engine	PAM - Parking assist control module	●	●	●	●
XE	2016 -	GTDI 2.0L engine	PCM - Powertrain control module	●	●	●	●
XE	2016 -	GTDI 2.0L engine	PDM - Passenger's door module	●	●	●	●
XE	2016 -	GTDI 2.0L engine	PRDM - Passenger's (side) rear door module.	●	●	●	●
XE	2016 -	GTDI 2.0L engine	PSCM - Power steering control module	●	●	●	●
XE	2016 -	GTDI 2.0L engine	RCM - Restraints control module	●	●	●	●
XE	2016 -	GTDI 2.0L engine	RFA - Keyless vehicle module	●	●	●	●
XE	2016 -	GTDI 2.0L engine	RGTM - Rear gate / trunk module	●	●	●	●
XE	2016 -	GTDI 2.0L engine	SASM - Steering angle sensor module	●	●	●	●
XE	2016 -	GTDI 2.0L engine	SODL - Side object detection control module - Left	●	●	●	●
XE	2016 -	GTDI 2.0L engine	SODR - Side object detection control module - Right	●	●	●	●

Vehicle model	Year	Engine Type/Chassis Number	System Name	Information	Read TroubleCode	Clear TroubleCode	Read DataStream
XE	2016 -	GTDI 2.0L engine	SRM - Satellite audio unit module.	●	●	●	●
XE	2016 -	GTDI 2.0L engine	TBM - Deployable towbar control module	●	●	●	●
XE	2016 -	GTDI 2.0L engine	TCM - Transmission control module	●	●	●	●
XE	2016 -	GTDI 2.0L engine	TCU - Telematic control unit module	●	●	●	●
XE	2016 -	GTDI 2.0L engine	TPM - Tire pressure monitor module	●	●	●	●
XE	2016 -	GTDI 2.0L engine	TVM - Television module	●	●	●	●
XE	2016 -	GTDI 2.0L engine	VIM - Vehicle immobilizer control module	●	●	●	●
XE	2016 -	Supercharged V6 3.0L engine	AAM - Audio amplifier module	●	●	●	●
XE	2016 -	Supercharged V6 3.0L engine	ABS - ABS control module	●	●	●	●
XE	2016 -	Supercharged V6 3.0L engine	ACM - Audio front control module	●	●	●	●
XE	2016 -	Supercharged V6 3.0L engine	AHU - InControl Touch audio head unit	●	●	●	○
XE	2016 -	Supercharged V6 3.0L engine	ATCM - All terrain control module	●	●	●	●
XE	2016 -	Supercharged V6 3.0L engine	AUCM - Head-up display cooling fan module	●	●	●	●
XE	2016 -	Supercharged V6 3.0L engine	BCM - Body control module	●	●	●	●
XE	2016 -	Supercharged V6 3.0L engine	CAV - Connect and view module	●	●	●	●
XE	2016 -	Supercharged V6 3.0L engine	CCM - Speed control module	●	●	●	●
XE	2016 -	Supercharged V6 3.0L engine	CHCM - Chassis control module	●	●	●	●
XE	2016 -	Supercharged V6 3.0L engine	DABM - Digital audio broadcast module	●	●	●	●
XE	2016 -	Supercharged V6 3.0L engine	DDM - Driver's door module	●	●	●	●
XE	2016 -	Supercharged V6 3.0L engine	DRDM - Driver's (side) rear door module.	●	●	●	●
XE	2016 -	Supercharged V6 3.0L engine	DSM - Driver's seat module	●	●	●	●
XE	2016 -	Supercharged V6 3.0L engine	front)	●	●	●	●
XE	2016 -	Supercharged V6 3.0L engine	FCIM - Integrated control panel	●	●	●	●
XE	2016 -	Supercharged V6 3.0L engine	GSM - Gear shift module	●	●	●	●
XE	2016 -	Supercharged V6 3.0L engine	GWM - Gateway module	●	●	●	●
XE	2016 -	Supercharged V6 3.0L engine	HUD - Head up display	●	●	●	○
XE	2016 -	Supercharged V6 3.0L engine	HVAC - Heating ventilation and air conditioning control module	●	●	●	●
XE	2016 -	Supercharged V6 3.0L engine	IPC - Instrument cluster control module.	●	●	●	●
XE	2016 -	Supercharged V6 3.0L engine	IPMA - Image processing control module A	●	●	●	●
XE	2016 -	Supercharged V6 3.0L engine	IPMB - Image processing module B	●	●	●	●
XE	2016 -	Supercharged V6 3.0L engine	NAV - Navigation control module	●	●	●	○
XE	2016 -	Supercharged V6 3.0L engine	NCM - Navigation control module	●	●	●	●
XE	2016 -	Supercharged V6 3.0L engine	OCS - Restraints occupant classification system module	●	●	●	●
XE	2016 -	Supercharged V6 3.0L engine	PAM - Parking assist control module	●	●	●	●
XE	2016 -	Supercharged V6 3.0L engine	PCM - Powertrain control module	●	●	●	●
XE	2016 -	Supercharged V6 3.0L engine	PDM - Passenger's door module	●	●	●	●
XE	2016 -	Supercharged V6 3.0L engine	PRDM - Passenger's (side) rear door module.	●	●	●	●
XE	2016 -	Supercharged V6 3.0L engine	PSCM - Power steering control module	●	●	●	●
XE	2016 -	Supercharged V6 3.0L engine	RCM - Restraints control module	●	●	●	●
XE	2016 -	Supercharged V6 3.0L engine	RFA - Keyless vehicle module	●	●	●	●
XE	2016 -	Supercharged V6 3.0L engine	RGTM - Rear gate / trunk module	●	●	●	●
XE	2016 -	Supercharged V6 3.0L engine	SASM - Steering angle sensor module	●	●	●	●
XE	2016 -	Supercharged V6 3.0L engine	SODL - Side object detection control module - Left	●	●	●	●
XE	2016 -	Supercharged V6 3.0L engine	SODR - Side object detection control module - Right	●	●	●	●
XE	2016 -	Supercharged V6 3.0L engine	SRM - Satellite audio unit module.	●	●	●	●
XE	2016 -	Supercharged V6 3.0L engine	TBM - Deployable towbar control module	●	●	●	●
XE	2016 -	Supercharged V6 3.0L engine	TCM - Transmission control module	●	●	●	●
XE	2016 -	Supercharged V6 3.0L engine	TCU - Telematic control unit module	●	●	●	●
XE	2016 -	Supercharged V6 3.0L engine	TPM - Tire pressure monitor module	●	●	●	●
XE	2016 -	Supercharged V6 3.0L engine	TVM - Television module	●	●	●	●
XE	2016 -	Supercharged V6 3.0L engine	VIM - Vehicle immobilizer control module	●	●	●	●
XJ range	2002-2005	Normally aspirated V6	ABS - Anti-lock braking system	●	●	●	●
XJ range	2002-2005	Normally aspirated V6	ACC - Adaptive speed control control module.	●	●	●	●
XJ range	2002-2005	Normally aspirated V6	ADHLS - Left lighting control module	●	●	●	●
XJ range	2002-2005	Normally aspirated V6	ADHLS - Right lighting control module	●	●	●	●
XJ range	2002-2005	Normally aspirated V6	AMP - Amplifier	●	●	●	●
XJ range	2002-2005	Normally aspirated V6	ARM - Restraints control module	●	●	●	●
XJ range	2002-2005	Normally aspirated V6	ASU - Air suspension module	●	●	●	●
XJ range	2002-2005	Normally aspirated V6	ATC - Climate control module	●	●	●	●
XJ range	2002-2005	Normally aspirated V6	CPM - Cellular telephone control module	●	●	●	●
XJ range	2002-2005	Normally aspirated V6	DDM - Driver's door module	●	●	●	●
XJ range	2002-2005	Normally aspirated V6	DSM - Driver's seat module	●	●	●	●
XJ range	2002-2005	Normally aspirated V6	ECM - Engine control module	●	●	●	●
XJ range	2002-2005	Normally aspirated V6	EPB - Electronic parking brake	●	●	●	●
XJ range	2002-2005	Normally aspirated V6	FETM - Audio unit.	●	●	●	●
XJ range	2002-2005	Normally aspirated V6	GEM - General electronics control module.	●	●	●	●
XJ range	2002-2005	Normally aspirated V6	IP - Instrument pack	●	●	●	●
XJ range	2002-2005	Normally aspirated V6	ISM - Intrusion sensor module	●	●	●	●
XJ range	2002-2005	Normally aspirated V6	NAV - Navigation control module	●	●	●	●
XJ range	2002-2005	Normally aspirated V6	PAM - Parking aid control module.	●	●	●	●
XJ range	2002-2005	Normally aspirated V6	RATC - Rear climate control module	●	●	●	●
XJ range	2002-2005	Normally aspirated V6	REM - Rear electronic control module.	●	●	●	●
XJ range	2002-2005	Normally aspirated V6	RETM - Rear entertainment control module	●	●	●	●
XJ range	2002-2005	Normally aspirated V6	RSM - Rear seat control module.	●	●	●	●
XJ range	2002-2005	Normally aspirated V6	SCLM - Steering column lock module	●	●	●	●
XJ range	2002-2005	Normally aspirated V6	TCM - Transmission control module	●	●	●	●
XJ range	2002-2005	Normally aspirated V6	VACM - Voice activation control module.	●	●	●	●
XJ range	2002-2005	Normally aspirated V8 3.5L engine	ABS - Anti-lock braking system	●	●	●	●
XJ range	2002-2005	Normally aspirated V8 3.5L engine	ACC - Adaptive speed control control module.	●	●	●	●
XJ range	2002-2005	Normally aspirated V8 3.5L engine	ADHLS - Left lighting control module	●	●	●	●
XJ range	2002-2005	Normally aspirated V8 3.5L engine	ADHLS - Right lighting control module	●	●	●	●
XJ range	2002-2005	Normally aspirated V8 3.5L engine	AMP - Amplifier	●	●	●	●
XJ range	2002-2005	Normally aspirated V8 3.5L engine	ARM - Restraints control module	●	●	●	●
XJ range	2002-2005	Normally aspirated V8 3.5L engine	ASU - Air suspension module	●	●	●	●
XJ range	2002-2005	Normally aspirated V8 3.5L engine	ATC - Climate control module	●	●	●	●
XJ range	2002-2005	Normally aspirated V8 3.5L engine	CPM - Cellular telephone control module	●	●	●	●
XJ range	2002-2005	Normally aspirated V8 3.5L engine	DDM - Driver's door module	●	●	●	●

Vevhicle model	Year	Engine Type/Chassis Number	System Name	Information	Read TroubleCode	Clear TroubleCode	Read DataStream
XJ range	2002-2005	Normally aspirated V8 3.5L engine	DSM - Driver's seat module	●	●	●	●
XJ range	2002-2005	Normally aspirated V8 3.5L engine	ECM - Engine control module	●	●	●	●
XJ range	2002-2005	Normally aspirated V8 3.5L engine	EPB - Electronic parking brake	●	●	●	●
XJ range	2002-2005	Normally aspirated V8 3.5L engine	FETM - Audio unit.	●	●	●	●
XJ range	2002-2005	Normally aspirated V8 3.5L engine	GEM - General electronics control module.	●	●	●	●
XJ range	2002-2005	Normally aspirated V8 3.5L engine	IP - Instrument pack	●	●	●	●
XJ range	2002-2005	Normally aspirated V8 3.5L engine	ISM - Intrusion sensor module	●	●	●	●
XJ range	2002-2005	Normally aspirated V8 3.5L engine	NAV - Navigation control module	●	●	●	●
XJ range	2002-2005	Normally aspirated V8 3.5L engine	PAM - Parking aid control module.	●	●	●	●
XJ range	2002-2005	Normally aspirated V8 3.5L engine	RATC - Rear climate control module	●	●	●	●
XJ range	2002-2005	Normally aspirated V8 3.5L engine	REM - Rear electronic control module.	●	●	●	●
XJ range	2002-2005	Normally aspirated V8 3.5L engine	RETM - Rear entertainment control module	●	●	●	●
XJ range	2002-2005	Normally aspirated V8 3.5L engine	RSM - Rear seat control module.	●	●	●	●
XJ range	2002-2005	Normally aspirated V8 3.5L engine	SCLM - Steering column lock module	●	●	●	●
XJ range	2002-2005	Normally aspirated V8 3.5L engine	TCM - Transmission control module	●	●	●	●
XJ range	2002-2005	Normally aspirated V8 3.5L engine	VACM - Voice activation control module.	●	●	●	●
XJ range	2002-2005	Normally aspirated V8 4.2L engine	ABS - Anti-lock braking system	●	●	●	●
XJ range	2002-2005	Normally aspirated V8 4.2L engine	ACC - Adaptive speed control control module.	●	●	●	●
XJ range	2002-2005	Normally aspirated V8 4.2L engine	ADHLS - Left lighting control module	●	●	●	●
XJ range	2002-2005	Normally aspirated V8 4.2L engine	ADHLS - Right lighting control module	●	●	●	●
XJ range	2002-2005	Normally aspirated V8 4.2L engine	AMP - Amplifier	●	●	●	●
XJ range	2002-2005	Normally aspirated V8 4.2L engine	ARM - Restraints control module	●	●	●	●
XJ range	2002-2005	Normally aspirated V8 4.2L engine	ASU - Air suspension module	●	●	●	●
XJ range	2002-2005	Normally aspirated V8 4.2L engine	ATC - Climate control module	●	●	●	●
XJ range	2002-2005	Normally aspirated V8 4.2L engine	CPM - Cellular telephone control module	●	●	●	●
XJ range	2002-2005	Normally aspirated V8 4.2L engine	DDM - Driver's door module	●	●	●	●
XJ range	2002-2005	Normally aspirated V8 4.2L engine	DSM - Driver's seat module	●	●	●	●
XJ range	2002-2005	Normally aspirated V8 4.2L engine	ECM - Engine control module	●	●	●	●
XJ range	2002-2005	Normally aspirated V8 4.2L engine	EPB - Electronic parking brake	●	●	●	●
XJ range	2002-2005	Normally aspirated V8 4.2L engine	FETM - Audio unit.	●	●	●	●
XJ range	2002-2005	Normally aspirated V8 4.2L engine	GEM - General electronics control module.	●	●	●	●
XJ range	2002-2005	Normally aspirated V8 4.2L engine	IP - Instrument pack	●	●	●	●
XJ range	2002-2005	Normally aspirated V8 4.2L engine	ISM - Intrusion sensor module	●	●	●	●
XJ range	2002-2005	Normally aspirated V8 4.2L engine	NAV - Navigation control module	●	●	●	●
XJ range	2002-2005	Normally aspirated V8 4.2L engine	PAM - Parking aid control module.	●	●	●	●
XJ range	2002-2005	Normally aspirated V8 4.2L engine	RATC - Rear climate control module	●	●	●	●
XJ range	2002-2005	Normally aspirated V8 4.2L engine	REM - Rear electronic control module.	●	●	●	●
XJ range	2002-2005	Normally aspirated V8 4.2L engine	RETM - Rear entertainment control module	●	●	●	●
XJ range	2002-2005	Normally aspirated V8 4.2L engine	RSM - Rear seat control module.	●	●	●	●
XJ range	2002-2005	Normally aspirated V8 4.2L engine	SCLM - Steering column lock module	●	●	●	●
XJ range	2002-2005	Normally aspirated V8 4.2L engine	TCM - Transmission control module	●	●	●	●
XJ range	2002-2005	Normally aspirated V8 4.2L engine	VACM - Voice activation control module.	●	●	●	●
XJ range	2002-2005	Supercharged V8	ABS - Anti-lock braking system	●	●	●	●
XJ range	2002-2005	Supercharged V8	ACC - Adaptive speed control control module.	●	●	●	●
XJ range	2002-2005	Supercharged V8	ADHLS - Left lighting control module	●	●	●	●
XJ range	2002-2005	Supercharged V8	ADHLS - Right lighting control module	●	●	●	●
XJ range	2002-2005	Supercharged V8	AMP - Amplifier	●	●	●	●
XJ range	2002-2005	Supercharged V8	ARM - Restraints control module	●	●	●	●
XJ range	2002-2005	Supercharged V8	ASU - Air suspension module	●	●	●	●
XJ range	2002-2005	Supercharged V8	ATC - Climate control module	●	●	●	●
XJ range	2002-2005	Supercharged V8	CPM - Cellular telephone control module	●	●	●	●
XJ range	2002-2005	Supercharged V8	DDM - Driver's door module	●	●	●	●
XJ range	2002-2005	Supercharged V8	DSM - Driver's seat module	●	●	●	●
XJ range	2002-2005	Supercharged V8	ECM - Engine control module	●	●	●	●
XJ range	2002-2005	Supercharged V8	EPB - Electronic parking brake	●	●	●	●
XJ range	2002-2005	Supercharged V8	FETM - Audio unit.	●	●	●	●
XJ range	2002-2005	Supercharged V8	GEM - General electronics control module.	●	●	●	●
XJ range	2002-2005	Supercharged V8	IP - Instrument pack	●	●	●	●
XJ range	2002-2005	Supercharged V8	ISM - Intrusion sensor module	●	●	●	●
XJ range	2002-2005	Supercharged V8	NAV - Navigation control module	●	●	●	●
XJ range	2002-2005	Supercharged V8	PAM - Parking aid control module.	●	●	●	●
XJ range	2002-2005	Supercharged V8	RATC - Rear climate control module	●	●	●	●
XJ range	2002-2005	Supercharged V8	REM - Rear electronic control module.	●	●	●	●
XJ range	2002-2005	Supercharged V8	RETM - Rear entertainment control module	●	●	●	●
XJ range	2002-2005	Supercharged V8	RSM - Rear seat control module.	●	●	●	●
XJ range	2002-2005	Supercharged V8	SCLM - Steering column lock module	●	●	●	●
XJ range	2002-2005	Supercharged V8	TCM - Transmission control module	●	●	●	●
XJ range	2002-2005	Supercharged V8	VACM - Voice activation control module.	●	●	●	●
XJ range	2006-2007	Diesel V6	ABS - Anti-lock braking system	●	●	●	●
XJ range	2006-2007	Diesel V6	ACC - Adaptive speed control control module.	○	●	●	●
XJ range	2006-2007	Diesel V6	ADHLS - Left lighting control module	○	○	●	○
XJ range	2006-2007	Diesel V6	ADHLS - Right lighting control module	○	○	●	○
XJ range	2006-2007	Diesel V6	AHCM - Auxiliary heater control module	●	●	●	●
XJ range	2006-2007	Diesel V6	AMP - Amplifier	○	●	●	●
XJ range	2006-2007	Diesel V6	ARM - Restraints control module	○	●	●	●
XJ range	2006-2007	Diesel V6	ASU - Air suspension module	○	●	●	●
XJ range	2006-2007	Diesel V6	ATC - Climate control module	○	●	●	●
XJ range	2006-2007	Diesel V6	CPM - Cellular telephone control module	○	●	●	●
XJ range	2006-2007	Diesel V6	DDM - Driver's door module	○	●	●	●
XJ range	2006-2007	Diesel V6	DSM - Driver's seat module	○	●	●	●
XJ range	2006-2007	Diesel V6	FETM - Audio unit.	○	●	●	●
XJ range	2006-2007	Diesel V6	GEM - General electronics control module.	○	●	●	●
XJ range	2006-2007	Diesel V6	IP - Instrument pack	●	●	●	●
XJ range	2006-2007	Diesel V6	ISM - Intrusion sensor module	○	●	●	●
XJ range	2006-2007	Diesel V6	NAV - Navigation control module	○	●	●	●
XJ range	2006-2007	Diesel V6	PAM - Parking aid control module.	○	●	●	●
XJ range	2006-2007	Diesel V6	PBM - Parking brake control module	●	●	●	●



Vevhicle model	Year	Engine Type/Chassis Number	System Name	Information	Read TroubleCode	Clear TroubleCode	Read DataStream
XJ range	2006-2007	Diesel V6	PCM - Powertrain control module	●	●	●	●
XJ range	2006-2007	Diesel V6	RATC - Rear climate control module	○	●	●	●
XJ range	2006-2007	Diesel V6	REM - Rear electronic control module.	○	●	●	●
XJ range	2006-2007	Diesel V6	RETM - Rear entertainment control module	○	●	●	●
XJ range	2006-2007	Diesel V6	RSM - Rear seat control module.	○	●	●	●
XJ range	2006-2007	Diesel V6	SCLM - Steering column lock module	○	●	●	●
XJ range	2006-2007	Diesel V6	TCM - Transmission control module	○	●	●	●
XJ range	2006-2007	Diesel V6	TPM - Tire pressure monitor module	●	●	●	●
XJ range	2006-2007	Diesel V6	VACM - Voice activation control module.	○	●	●	●
XJ range	2006-2007	Normally aspirated V6	ABS - Anti-lock braking system	●	●	●	●
XJ range	2006-2007	Normally aspirated V6	ACC - Adaptive speed control control module.	○	●	●	●
XJ range	2006-2007	Normally aspirated V6	ADHLS - Left lighting control module	○	○	●	○
XJ range	2006-2007	Normally aspirated V6	ADHLS - Right lighting control module	○	○	●	○
XJ range	2006-2007	Normally aspirated V6	AHCM - Auxiliary heater control module	●	●	●	●
XJ range	2006-2007	Normally aspirated V6	AMP - Amplifier	○	●	●	●
XJ range	2006-2007	Normally aspirated V6	ARM - Restraints control module	○	●	●	●
XJ range	2006-2007	Normally aspirated V6	ASU - Air suspension module	○	●	●	●
XJ range	2006-2007	Normally aspirated V6	ATC - Climate control module	○	●	●	●
XJ range	2006-2007	Normally aspirated V6	CPM - Cellular telephone control module	○	●	●	●
XJ range	2006-2007	Normally aspirated V6	DDM - Driver's door module	○	●	●	●
XJ range	2006-2007	Normally aspirated V6	DSM - Driver's seat module	○	●	●	●
XJ range	2006-2007	Normally aspirated V6	FETM - Audio unit.	○	●	●	●
XJ range	2006-2007	Normally aspirated V6	GEM - General electronics control module.	○	●	●	●
XJ range	2006-2007	Normally aspirated V6	IP - Instrument pack	●	●	●	●
XJ range	2006-2007	Normally aspirated V6	ISM - Intrusion sensor module	○	●	●	●
XJ range	2006-2007	Normally aspirated V6	NAV - Navigation control module	○	●	●	●
XJ range	2006-2007	Normally aspirated V6	PAM - Parking aid control module.	○	●	●	●
XJ range	2006-2007	Normally aspirated V6	PBM - Parking brake control module	●	●	●	●
XJ range	2006-2007	Normally aspirated V6	PCM - Powertrain control module	●	●	●	●
XJ range	2006-2007	Normally aspirated V6	RATC - Rear climate control module	○	●	●	●
XJ range	2006-2007	Normally aspirated V6	REM - Rear electronic control module.	○	●	●	●
XJ range	2006-2007	Normally aspirated V6	RETM - Rear entertainment control module	○	●	●	●
XJ range	2006-2007	Normally aspirated V6	RSM - Rear seat control module.	○	●	●	●
XJ range	2006-2007	Normally aspirated V6	SCLM - Steering column lock module	○	●	●	●
XJ range	2006-2007	Normally aspirated V6	TCM - Transmission control module	○	●	●	●
XJ range	2006-2007	Normally aspirated V6	TPM - Tire pressure monitor module	●	●	●	●
XJ range	2006-2007	Normally aspirated V6	VACM - Voice activation control module.	○	●	●	●
XJ range	2006-2007	Normally aspirated V8 3.5L engine	ABS - Anti-lock braking system	●	●	●	●
XJ range	2006-2007	Normally aspirated V8 3.5L engine	ACC - Adaptive speed control control module.	○	●	●	●
XJ range	2006-2007	Normally aspirated V8 3.5L engine	ADHLS - Left lighting control module	○	○	●	○
XJ range	2006-2007	Normally aspirated V8 3.5L engine	ADHLS - Right lighting control module	○	○	●	○
XJ range	2006-2007	Normally aspirated V8 3.5L engine	AHCM - Auxiliary heater control module	●	●	●	●
XJ range	2006-2007	Normally aspirated V8 3.5L engine	AMP - Amplifier	○	●	●	●
XJ range	2006-2007	Normally aspirated V8 3.5L engine	ARM - Restraints control module	○	●	●	●
XJ range	2006-2007	Normally aspirated V8 3.5L engine	ASU - Air suspension module	○	●	●	●
XJ range	2006-2007	Normally aspirated V8 3.5L engine	ATC - Climate control module	○	●	●	●
XJ range	2006-2007	Normally aspirated V8 3.5L engine	CPM - Cellular telephone control module	○	●	●	●
XJ range	2006-2007	Normally aspirated V8 3.5L engine	DDM - Driver's door module	○	●	●	●
XJ range	2006-2007	Normally aspirated V8 3.5L engine	DSM - Driver's seat module	○	●	●	●
XJ range	2006-2007	Normally aspirated V8 3.5L engine	FETM - Audio unit.	○	●	●	●
XJ range	2006-2007	Normally aspirated V8 3.5L engine	GEM - General electronics control module.	○	●	●	●
XJ range	2006-2007	Normally aspirated V8 3.5L engine	IP - Instrument pack	●	●	●	●
XJ range	2006-2007	Normally aspirated V8 3.5L engine	ISM - Intrusion sensor module	○	●	●	●
XJ range	2006-2007	Normally aspirated V8 3.5L engine	NAV - Navigation control module	○	●	●	●
XJ range	2006-2007	Normally aspirated V8 3.5L engine	PAM - Parking aid control module.	○	●	●	●
XJ range	2006-2007	Normally aspirated V8 3.5L engine	PBM - Parking brake control module	●	●	●	●
XJ range	2006-2007	Normally aspirated V8 3.5L engine	PCM - Powertrain control module	●	●	●	●
XJ range	2006-2007	Normally aspirated V8 3.5L engine	RATC - Rear climate control module	○	●	●	●
XJ range	2006-2007	Normally aspirated V8 3.5L engine	REM - Rear electronic control module.	○	●	●	●
XJ range	2006-2007	Normally aspirated V8 3.5L engine	RETM - Rear entertainment control module	○	●	●	●
XJ range	2006-2007	Normally aspirated V8 3.5L engine	RSM - Rear seat control module.	○	●	●	●
XJ range	2006-2007	Normally aspirated V8 3.5L engine	SCLM - Steering column lock module	○	●	●	●
XJ range	2006-2007	Normally aspirated V8 3.5L engine	TCM - Transmission control module	○	●	●	●
XJ range	2006-2007	Normally aspirated V8 3.5L engine	TPM - Tire pressure monitor module	●	●	●	●
XJ range	2006-2007	Normally aspirated V8 3.5L engine	VACM - Voice activation control module.	○	●	●	●
XJ range	2006-2007	Normally aspirated V8 4.2L engine	ABS - Anti-lock braking system	●	●	●	●
XJ range	2006-2007	Normally aspirated V8 4.2L engine	ACC - Adaptive speed control control module.	○	●	●	●
XJ range	2006-2007	Normally aspirated V8 4.2L engine	ADHLS - Left lighting control module	○	○	●	○
XJ range	2006-2007	Normally aspirated V8 4.2L engine	ADHLS - Right lighting control module	○	○	●	○
XJ range	2006-2007	Normally aspirated V8 4.2L engine	AHCM - Auxiliary heater control module	●	●	●	●
XJ range	2006-2007	Normally aspirated V8 4.2L engine	AMP - Amplifier	○	●	●	●
XJ range	2006-2007	Normally aspirated V8 4.2L engine	ARM - Restraints control module	○	●	●	●
XJ range	2006-2007	Normally aspirated V8 4.2L engine	ASU - Air suspension module	○	●	●	●
XJ range	2006-2007	Normally aspirated V8 4.2L engine	ATC - Climate control module	○	●	●	●
XJ range	2006-2007	Normally aspirated V8 4.2L engine	CPM - Cellular telephone control module	○	●	●	●
XJ range	2006-2007	Normally aspirated V8 4.2L engine	DDM - Driver's door module	○	●	●	●
XJ range	2006-2007	Normally aspirated V8 4.2L engine	DSM - Driver's seat module	○	●	●	●
XJ range	2006-2007	Normally aspirated V8 4.2L engine	FETM - Audio unit.	○	●	●	●
XJ range	2006-2007	Normally aspirated V8 4.2L engine	GEM - General electronics control module.	○	●	●	●
XJ range	2006-2007	Normally aspirated V8 4.2L engine	IP - Instrument pack	●	●	●	●
XJ range	2006-2007	Normally aspirated V8 4.2L engine	ISM - Intrusion sensor module	○	●	●	●
XJ range	2006-2007	Normally aspirated V8 4.2L engine	NAV - Navigation control module	○	●	●	●
XJ range	2006-2007	Normally aspirated V8 4.2L engine	PAM - Parking aid control module.	○	●	●	●
XJ range	2006-2007	Normally aspirated V8 4.2L engine	PBM - Parking brake control module	●	●	●	●
XJ range	2006-2007	Normally aspirated V8 4.2L engine	PCM - Powertrain control module	●	●	●	●
XJ range	2006-2007	Normally aspirated V8 4.2L engine	RATC - Rear climate control module	○	●	●	●
XJ range	2006-2007	Normally aspirated V8 4.2L engine	REM - Rear electronic control module.	○	●	●	●

Vevhicle model	Year	Engine Type/Chassis Number	System Name	Information	Read TroubleCode	Clear TroubleCode	Read DataStream
XJ range	2006-2007	Normally aspirated V8 4.2L engine	RETM - Rear entertainment control module	○	●	●	●
XJ range	2006-2007	Normally aspirated V8 4.2L engine	RSM - Rear seat control module.	○	●	●	●
XJ range	2006-2007	Normally aspirated V8 4.2L engine	SCLM - Steering column lock module	○	●	●	●
XJ range	2006-2007	Normally aspirated V8 4.2L engine	TCM - Transmission control module	○	●	●	●
XJ range	2006-2007	Normally aspirated V8 4.2L engine	TPM - Tire pressure monitor module	●	●	●	●
XJ range	2006-2007	Normally aspirated V8 4.2L engine	VACM - Voice activation control module.	○	●	●	●
XJ range	2006-2007	Supercharged V8	ABS - Anti-lock braking system	●	●	●	●
XJ range	2006-2007	Supercharged V8	ACC - Adaptive speed control control module.	○	●	●	●
XJ range	2006-2007	Supercharged V8	ADHLS - Left lighting control module	○	○	●	○
XJ range	2006-2007	Supercharged V8	ADHLS - Right lighting control module	○	○	●	○
XJ range	2006-2007	Supercharged V8	AHCM - Auxiliary heater control module	●	●	●	●
XJ range	2006-2007	Supercharged V8	AMP - Amplifier	○	●	●	●
XJ range	2006-2007	Supercharged V8	ARM - Restraints control module	○	●	●	●
XJ range	2006-2007	Supercharged V8	ASU - Air suspension module	○	●	●	●
XJ range	2006-2007	Supercharged V8	ATC - Climate control module	○	●	●	●
XJ range	2006-2007	Supercharged V8	CPM - Cellular telephone control module	○	●	●	●
XJ range	2006-2007	Supercharged V8	DDM - Driver's door module	○	●	●	●
XJ range	2006-2007	Supercharged V8	DSM - Driver's seat module	○	●	●	●
XJ range	2006-2007	Supercharged V8	FETM - Audio unit.	○	●	●	●
XJ range	2006-2007	Supercharged V8	GEM - General electronics control module.	○	●	●	●
XJ range	2006-2007	Supercharged V8	IP - Instrument pack	●	●	●	●
XJ range	2006-2007	Supercharged V8	ISM - Intrusion sensor module	○	●	●	●
XJ range	2006-2007	Supercharged V8	NAV - Navigation control module	○	●	●	●
XJ range	2006-2007	Supercharged V8	PAM - Parking aid control module.	○	●	●	●
XJ range	2006-2007	Supercharged V8	PBM - Parking brake control module	●	●	●	●
XJ range	2006-2007	Supercharged V8	PCM - Powertrain control module	●	●	●	●
XJ range	2006-2007	Supercharged V8	RATC - Rear climate control module	○	●	●	●
XJ range	2006-2007	Supercharged V8	REM - Rear electronic control module.	○	●	●	●
XJ range	2006-2007	Supercharged V8	RETM - Rear entertainment control module	○	●	●	●
XJ range	2006-2007	Supercharged V8	RSM - Rear seat control module.	○	●	●	●
XJ range	2006-2007	Supercharged V8	SCLM - Steering column lock module	○	●	●	●
XJ range	2006-2007	Supercharged V8	TCM - Transmission control module	○	●	●	●
XJ range	2006-2007	Supercharged V8	TPM - Tire pressure monitor module	●	●	●	●
XJ range	2006-2007	Supercharged V8	VACM - Voice activation control module.	○	●	●	●
XJ range	2008-2009	Diesel V6	ABS - Anti-lock braking system	●	●	●	●
XJ range	2008-2009	Diesel V6	ACC - Adaptive speed control control module.	○	●	●	●
XJ range	2008-2009	Diesel V6	ADHLS - Left lighting control module	○	○	●	○
XJ range	2008-2009	Diesel V6	ADHLS - Right lighting control module	○	○	●	○
XJ range	2008-2009	Diesel V6	AHCM - Auxiliary heater control module	●	●	●	●
XJ range	2008-2009	Diesel V6	AMP - Amplifier	○	●	●	●
XJ range	2008-2009	Diesel V6	ARM - Restraints control module	○	●	●	●
XJ range	2008-2009	Diesel V6	ASU - Air suspension module	○	●	●	●
XJ range	2008-2009	Diesel V6	ATC - Climate control module	○	●	●	●
XJ range	2008-2009	Diesel V6	CPM - Cellular telephone control module	○	●	●	●
XJ range	2008-2009	Diesel V6	DCSM - Driver's climate seat module	●	●	●	●
XJ range	2008-2009	Diesel V6	DDM - Driver's door module	○	●	●	●
XJ range	2008-2009	Diesel V6	DSM - Driver's seat module	○	●	●	●
XJ range	2008-2009	Diesel V6	FETM - Audio unit.	○	●	●	●
XJ range	2008-2009	Diesel V6	GEM - General electronics control module.	○	●	●	●
XJ range	2008-2009	Diesel V6	GWM - Gateway module	○	●	●	●
XJ range	2008-2009	Diesel V6	IP - Instrument pack	●	●	●	●
XJ range	2008-2009	Diesel V6	ISM - Intrusion sensor module	○	●	●	●
XJ range	2008-2009	Diesel V6	NAV - Navigation control module	○	●	●	●
XJ range	2008-2009	Diesel V6	PAM - Parking aid control module.	○	●	●	●
XJ range	2008-2009	Diesel V6	PBM - Parking brake control module	●	●	●	●
XJ range	2008-2009	Diesel V6	PCM - Powertrain control module	●	●	●	●
XJ range	2008-2009	Diesel V6	RATC - Rear climate control module	○	●	●	●
XJ range	2008-2009	Diesel V6	REM - Rear electronic control module.	○	●	●	●
XJ range	2008-2009	Diesel V6	RETM - Rear entertainment control module	○	●	●	●
XJ range	2008-2009	Diesel V6	RSM - Rear seat control module.	○	●	●	●
XJ range	2008-2009	Diesel V6	SCLM - Steering column lock module	○	●	●	●
XJ range	2008-2009	Diesel V6	TCM - Transmission control module	○	●	●	●
XJ range	2008-2009	Diesel V6	TPM - Tire pressure monitor module	●	●	●	●
XJ range	2008-2009	Diesel V6	VACM - Voice activation control module.	○	●	●	●
XJ range	2008-2009	Normally aspirated V6	ABS - Anti-lock braking system	●	●	●	●
XJ range	2008-2009	Normally aspirated V6	ACC - Adaptive speed control control module.	○	●	●	●
XJ range	2008-2009	Normally aspirated V6	ADHLS - Left lighting control module	○	○	●	○
XJ range	2008-2009	Normally aspirated V6	ADHLS - Right lighting control module	○	○	●	○
XJ range	2008-2009	Normally aspirated V6	AMP - Amplifier	○	●	●	●
XJ range	2008-2009	Normally aspirated V6	ARM - Restraints control module	○	●	●	●
XJ range	2008-2009	Normally aspirated V6	ASU - Air suspension module	○	●	●	●
XJ range	2008-2009	Normally aspirated V6	ATC - Climate control module	○	●	●	●
XJ range	2008-2009	Normally aspirated V6	CPM - Cellular telephone control module	○	●	●	●
XJ range	2008-2009	Normally aspirated V6	DCSM - Driver's climate seat module	●	●	●	●
XJ range	2008-2009	Normally aspirated V6	DDM - Driver's door module	○	●	●	●
XJ range	2008-2009	Normally aspirated V6	DSM - Driver's seat module	○	●	●	●
XJ range	2008-2009	Normally aspirated V6	FETM - Audio unit.	○	●	●	●
XJ range	2008-2009	Normally aspirated V6	GEM - General electronics control module.	○	●	●	●
XJ range	2008-2009	Normally aspirated V6	GWM - Gateway module	○	●	●	●
XJ range	2008-2009	Normally aspirated V6	IP - Instrument pack	●	●	●	●
XJ range	2008-2009	Normally aspirated V6	ISM - Intrusion sensor module	○	●	●	●
XJ range	2008-2009	Normally aspirated V6	NAV - Navigation control module	○	●	●	●
XJ range	2008-2009	Normally aspirated V6	PAM - Parking aid control module.	○	●	●	●
XJ range	2008-2009	Normally aspirated V6	PBM - Parking brake control module	●	●	●	●
XJ range	2008-2009	Normally aspirated V6	PCM - Powertrain control module	●	●	●	●
XJ range	2008-2009	Normally aspirated V6	RATC - Rear climate control module	○	●	●	●
XJ range	2008-2009	Normally aspirated V6	REM - Rear electronic control module.	○	●	●	●

Vevhicle model	Year	Engine Type/Chassis Number	System Name	Information	Read TroubleCode	Clear TroubleCode	Read DataStream
XJ range	2008-2009	Normally aspirated V6	RETM - Rear entertainment control module	○	●	●	●
XJ range	2008-2009	Normally aspirated V6	RSM - Rear seat control module.	○	●	●	●
XJ range	2008-2009	Normally aspirated V6	SCLM - Steering column lock module	○	●	●	●
XJ range	2008-2009	Normally aspirated V6	TCM - Transmission control module	○	●	●	●
XJ range	2008-2009	Normally aspirated V6	TPM - Tire pressure monitor module	●	●	●	●
XJ range	2008-2009	Normally aspirated V6	VACM - Voice activation control module.	○	●	●	●
XJ range	2008-2009	Normally aspirated V8 3.5L engine	ABS - Anti-lock braking system	●	●	●	●
XJ range	2008-2009	Normally aspirated V8 3.5L engine	ACC - Adaptive speed control control module.	○	●	●	●
XJ range	2008-2009	Normally aspirated V8 3.5L engine	ADHLS - Left lighting control module	○	○	●	○
XJ range	2008-2009	Normally aspirated V8 3.5L engine	ADHLS - Right lighting control module	○	○	●	○
XJ range	2008-2009	Normally aspirated V8 3.5L engine	AMP - Amplifier	○	●	●	●
XJ range	2008-2009	Normally aspirated V8 3.5L engine	ARM - Restraints control module	○	●	●	●
XJ range	2008-2009	Normally aspirated V8 3.5L engine	ASU - Air suspension module	○	●	●	●
XJ range	2008-2009	Normally aspirated V8 3.5L engine	ATC - Climate control module	○	●	●	●
XJ range	2008-2009	Normally aspirated V8 3.5L engine	CPM - Cellular telephone control module	○	●	●	●
XJ range	2008-2009	Normally aspirated V8 3.5L engine	DCSM - Driver's climate seat module	●	●	●	●
XJ range	2008-2009	Normally aspirated V8 3.5L engine	DDM - Driver's door module	○	●	●	●
XJ range	2008-2009	Normally aspirated V8 3.5L engine	DSM - Driver's seat module	○	●	●	●
XJ range	2008-2009	Normally aspirated V8 3.5L engine	FETM - Audio unit.	○	●	●	●
XJ range	2008-2009	Normally aspirated V8 3.5L engine	GEM - General electronics control module.	○	●	●	●
XJ range	2008-2009	Normally aspirated V8 3.5L engine	GWM - Gateway module	○	●	●	●
XJ range	2008-2009	Normally aspirated V8 3.5L engine	IP - Instrument pack	●	●	●	●
XJ range	2008-2009	Normally aspirated V8 3.5L engine	ISM - Intrusion sensor module	○	●	●	●
XJ range	2008-2009	Normally aspirated V8 3.5L engine	NAV - Navigation control module	○	●	●	●
XJ range	2008-2009	Normally aspirated V8 3.5L engine	PAM - Parking aid control module.	○	●	●	●
XJ range	2008-2009	Normally aspirated V8 3.5L engine	PBM - Parking brake control module	●	●	●	●
XJ range	2008-2009	Normally aspirated V8 3.5L engine	PCM - Powertrain control module	●	●	●	●
XJ range	2008-2009	Normally aspirated V8 3.5L engine	RATC - Rear climate control module	○	●	●	●
XJ range	2008-2009	Normally aspirated V8 3.5L engine	REM - Rear electronic control module.	○	●	●	●
XJ range	2008-2009	Normally aspirated V8 3.5L engine	RETM - Rear entertainment control module	○	●	●	●
XJ range	2008-2009	Normally aspirated V8 3.5L engine	RSM - Rear seat control module.	○	●	●	●
XJ range	2008-2009	Normally aspirated V8 3.5L engine	SCLM - Steering column lock module	○	●	●	●
XJ range	2008-2009	Normally aspirated V8 3.5L engine	TCM - Transmission control module	○	●	●	●
XJ range	2008-2009	Normally aspirated V8 3.5L engine	TPM - Tire pressure monitor module	●	●	●	●
XJ range	2008-2009	Normally aspirated V8 3.5L engine	VACM - Voice activation control module.	○	●	●	●
XJ range	2008-2009	Normally aspirated V8 4.2L engine	ABS - Anti-lock braking system	●	●	●	●
XJ range	2008-2009	Normally aspirated V8 4.2L engine	ACC - Adaptive speed control control module.	○	●	●	●
XJ range	2008-2009	Normally aspirated V8 4.2L engine	ADHLS - Left lighting control module	○	○	●	○
XJ range	2008-2009	Normally aspirated V8 4.2L engine	ADHLS - Right lighting control module	○	○	●	○
XJ range	2008-2009	Normally aspirated V8 4.2L engine	AMP - Amplifier	○	●	●	●
XJ range	2008-2009	Normally aspirated V8 4.2L engine	ARM - Restraints control module	○	●	●	●
XJ range	2008-2009	Normally aspirated V8 4.2L engine	ASU - Air suspension module	○	●	●	●
XJ range	2008-2009	Normally aspirated V8 4.2L engine	ATC - Climate control module	○	●	●	●
XJ range	2008-2009	Normally aspirated V8 4.2L engine	CPM - Cellular telephone control module	○	●	●	●
XJ range	2008-2009	Normally aspirated V8 4.2L engine	DCSM - Driver's climate seat module	●	●	●	●
XJ range	2008-2009	Normally aspirated V8 4.2L engine	DDM - Driver's door module	○	●	●	●
XJ range	2008-2009	Normally aspirated V8 4.2L engine	DSM - Driver's seat module	○	●	●	●
XJ range	2008-2009	Normally aspirated V8 4.2L engine	FETM - Audio unit.	○	●	●	●
XJ range	2008-2009	Normally aspirated V8 4.2L engine	GEM - General electronics control module.	○	●	●	●
XJ range	2008-2009	Normally aspirated V8 4.2L engine	GWM - Gateway module	○	●	●	●
XJ range	2008-2009	Normally aspirated V8 4.2L engine	IP - Instrument pack	●	●	●	●
XJ range	2008-2009	Normally aspirated V8 4.2L engine	ISM - Intrusion sensor module	○	●	●	●
XJ range	2008-2009	Normally aspirated V8 4.2L engine	NAV - Navigation control module	○	●	●	●
XJ range	2008-2009	Normally aspirated V8 4.2L engine	PAM - Parking aid control module.	○	●	●	●
XJ range	2008-2009	Normally aspirated V8 4.2L engine	PBM - Parking brake control module	●	●	●	●
XJ range	2008-2009	Normally aspirated V8 4.2L engine	PCM - Powertrain control module	●	●	●	●
XJ range	2008-2009	Normally aspirated V8 4.2L engine	RATC - Rear climate control module	○	●	●	●
XJ range	2008-2009	Normally aspirated V8 4.2L engine	REM - Rear electronic control module.	○	●	●	●
XJ range	2008-2009	Normally aspirated V8 4.2L engine	RETM - Rear entertainment control module	○	●	●	●
XJ range	2008-2009	Normally aspirated V8 4.2L engine	RSM - Rear seat control module.	○	●	●	●
XJ range	2008-2009	Normally aspirated V8 4.2L engine	SCLM - Steering column lock module	○	●	●	●
XJ range	2008-2009	Normally aspirated V8 4.2L engine	TCM - Transmission control module	○	●	●	●
XJ range	2008-2009	Normally aspirated V8 4.2L engine	TPM - Tire pressure monitor module	●	●	●	●
XJ range	2008-2009	Normally aspirated V8 4.2L engine	VACM - Voice activation control module.	○	●	●	●
XJ range	2008-2009	Supercharged V8	ABS - Anti-lock braking system	●	●	●	●
XJ range	2008-2009	Supercharged V8	ACC - Adaptive speed control control module.	○	●	●	●
XJ range	2008-2009	Supercharged V8	ADHLS - Left lighting control module	○	○	●	○
XJ range	2008-2009	Supercharged V8	ADHLS - Right lighting control module	○	○	●	○
XJ range	2008-2009	Supercharged V8	AMP - Amplifier	○	●	●	●
XJ range	2008-2009	Supercharged V8	ARM - Restraints control module	○	●	●	●
XJ range	2008-2009	Supercharged V8	ASU - Air suspension module	○	●	●	●
XJ range	2008-2009	Supercharged V8	ATC - Climate control module	○	●	●	●
XJ range	2008-2009	Supercharged V8	CPM - Cellular telephone control module	○	●	●	●
XJ range	2008-2009	Supercharged V8	DCSM - Driver's climate seat module	●	●	●	●
XJ range	2008-2009	Supercharged V8	DDM - Driver's door module	○	●	●	●
XJ range	2008-2009	Supercharged V8	DSM - Driver's seat module	○	●	●	●
XJ range	2008-2009	Supercharged V8	FETM - Audio unit.	○	●	●	●
XJ range	2008-2009	Supercharged V8	GEM - General electronics control module.	○	●	●	●
XJ range	2008-2009	Supercharged V8	GWM - Gateway module	○	●	●	●
XJ range	2008-2009	Supercharged V8	IP - Instrument pack	●	●	●	●
XJ range	2008-2009	Supercharged V8	ISM - Intrusion sensor module	○	●	●	●
XJ range	2008-2009	Supercharged V8	NAV - Navigation control module	○	●	●	●
XJ range	2008-2009	Supercharged V8	PAM - Parking aid control module.	○	●	●	●
XJ range	2008-2009	Supercharged V8	PBM - Parking brake control module	●	●	●	●
XJ range	2008-2009	Supercharged V8	PCM - Powertrain control module	●	●	●	●
XJ range	2008-2009	Supercharged V8	RATC - Rear climate control module	○	●	●	●
XJ range	2008-2009	Supercharged V8	REM - Rear electronic control module.	○	●	●	●

Vevhicle model	Year	Engine Type/Chassis Number	System Name	Information	Read TroubleCode	Clear TroubleCode	Read DataStream
XJ range	2008-2009	Supercharged V8	RETM - Rear entertainment control module	○	●	●	●
XJ range	2008-2009	Supercharged V8	RSM - Rear seat control module.	○	●	●	●
XJ range	2008-2009	Supercharged V8	SCLM - Steering column lock module	○	●	●	●
XJ range	2008-2009	Supercharged V8	TCM - Transmission control module	○	●	●	●
XJ range	2008-2009	Supercharged V8	TPM - Tire pressure monitor module	●	●	●	●
XJ range	2008-2009	Supercharged V8	VACM - Voice activation control module.	○	●	●	●
XJ range	2010-2012	Diesel V6	AAM - Audio amplifier module	●	●	●	●
XJ range	2010-2012	Diesel V6	ABS - ABS control module	●	●	●	●
XJ range	2010-2012	Diesel V6	ACM - Audio front control module	●	●	●	●
XJ range	2010-2012	Diesel V6	ADCM - Adaptive damping control module	●	●	●	●
XJ range	2010-2012	Diesel V6	BCM - Body control module	●	●	●	●
XJ range	2010-2012	Diesel V6	CCM - Speed control module	●	●	●	●
XJ range	2010-2012	Diesel V6	DABM - Digital audio broadcast module	●	●	●	●
XJ range	2010-2012	Diesel V6	DCSM - Driver's climate seat module	●	●	●	●
XJ range	2010-2012	Diesel V6	DDM - Driver's door module	●	●	●	●
XJ range	2010-2012	Diesel V6	DSM - Driver's seat module	●	●	●	●
XJ range	2010-2012	Diesel V6	front)	●	●	●	●
XJ range	2010-2012	Diesel V6	panel)	●	●	●	●
XJ range	2010-2012	Diesel V6	GSM - Gear shift module	●	●	●	●
XJ range	2010-2012	Diesel V6	HCM - Headlamp control module	●	●	●	●
XJ range	2010-2012	Diesel V6	HCMB - Headlamp control module 'B'	●	●	●	●
XJ range	2010-2012	Diesel V6	HVAC - Heating ventilation and air conditioning control module	●	●	●	●
XJ range	2010-2012	Diesel V6	IPC - Instrument cluster control module.	●	●	●	●
XJ range	2010-2012	Diesel V6	KVM - Keyless vehicle module	●	●	●	●
XJ range	2010-2012	Diesel V6	OCS - Restraints occupant classification system module	●	●	●	●
XJ range	2010-2012	Diesel V6	PAM - Parking assist control module	●	●	●	●
XJ range	2010-2012	Diesel V6	PBM - Parking brake control module	●	●	●	●
XJ range	2010-2012	Diesel V6	PCM - Powertrain control module	●	●	●	●
XJ range	2010-2012	Diesel V6	PDM - Passenger's door module	●	●	●	●
XJ range	2010-2012	Diesel V6	PSM - Passenger's seat module	●	●	●	●
XJ range	2010-2012	Diesel V6	RCM - Restraints control module	●	●	●	●
XJ range	2010-2012	Diesel V6	RDCM - Rear differential control module	●	●	●	●
XJ range	2010-2012	Diesel V6	RDCSM - Rear climate seat module	●	●	●	●
XJ range	2010-2012	Diesel V6	REM - Rear entertainment control module	●	●	●	●
XJ range	2010-2012	Diesel V6	RGTM - Rear gate / trunk module	●	●	●	●
XJ range	2010-2012	Diesel V6	module	●	●	●	●
XJ range	2010-2012	Diesel V6	RLM - Ride level control module	●	●	●	●
XJ range	2010-2012	Diesel V6	SODL - Side object detection control module - Left	●	●	●	●
XJ range	2010-2012	Diesel V6	SODR - Side object detection control module - Right	●	●	●	●
XJ range	2010-2012	Diesel V6	SPMA - Safety belt pretensioner control module A - drivers side	●	●	●	●
XJ range	2010-2012	Diesel V6	SPMB - Safety belt pretensioner control module B - passengers side	●	●	●	●
XJ range	2010-2012	Diesel V6	SRM - Satellite audio unit module.	●	●	●	●
XJ range	2010-2012	Diesel V6	TCM - Transmission control module	●	●	●	●
XJ range	2010-2012	Diesel V6	TVM - Television module	●	●	●	●
XJ range	2010-2012	Diesel V6	VIM - Vehicle immobilizer control module	●	●	●	●
XJ range	2010-2012	Normally aspirated V6 3.0L engine	AAM - Audio amplifier module	●	●	●	●
XJ range	2010-2012	Normally aspirated V6 3.0L engine	ABS - ABS control module	●	●	●	●
XJ range	2010-2012	Normally aspirated V6 3.0L engine	ACM - Audio front control module	●	●	●	●
XJ range	2010-2012	Normally aspirated V6 3.0L engine	ADCM - Adaptive damping control module	●	●	●	●
XJ range	2010-2012	Normally aspirated V6 3.0L engine	BCM - Body control module	●	●	●	●
XJ range	2010-2012	Normally aspirated V6 3.0L engine	CCM - Speed control module	●	●	●	●
XJ range	2010-2012	Normally aspirated V6 3.0L engine	DABM - Digital audio broadcast module	●	●	●	●
XJ range	2010-2012	Normally aspirated V6 3.0L engine	DCSM - Driver's climate seat module	●	●	●	●
XJ range	2010-2012	Normally aspirated V6 3.0L engine	DDM - Driver's door module	●	●	●	●
XJ range	2010-2012	Normally aspirated V6 3.0L engine	DSM - Driver's seat module	●	●	●	●
XJ range	2010-2012	Normally aspirated V6 3.0L engine	front)	●	●	●	●
XJ range	2010-2012	Normally aspirated V6 3.0L engine	panel)	●	●	●	●
XJ range	2010-2012	Normally aspirated V6 3.0L engine	GSM - Gear shift module	●	●	●	●
XJ range	2010-2012	Normally aspirated V6 3.0L engine	HCM - Headlamp control module	●	●	●	●
XJ range	2010-2012	Normally aspirated V6 3.0L engine	HCMB - Headlamp control module 'B'	●	●	●	●
XJ range	2010-2012	Normally aspirated V6 3.0L engine	HVAC - Heating ventilation and air conditioning control module	●	●	●	●
XJ range	2010-2012	Normally aspirated V6 3.0L engine	IPC - Instrument cluster control module.	●	●	●	●
XJ range	2010-2012	Normally aspirated V6 3.0L engine	KVM - Keyless vehicle module	●	●	●	●
XJ range	2010-2012	Normally aspirated V6 3.0L engine	OCS - Restraints occupant classification system module	●	●	●	●
XJ range	2010-2012	Normally aspirated V6 3.0L engine	PAM - Parking assist control module	●	●	●	●
XJ range	2010-2012	Normally aspirated V6 3.0L engine	PBM - Parking brake control module	●	●	●	●
XJ range	2010-2012	Normally aspirated V6 3.0L engine	PCM - Powertrain control module	●	●	●	●
XJ range	2010-2012	Normally aspirated V6 3.0L engine	PDM - Passenger's door module	●	●	●	●
XJ range	2010-2012	Normally aspirated V6 3.0L engine	PSM - Passenger's seat module	●	●	●	●
XJ range	2010-2012	Normally aspirated V6 3.0L engine	RCM - Restraints control module	●	●	●	●
XJ range	2010-2012	Normally aspirated V6 3.0L engine	RDCM - Rear differential control module	●	●	●	●
XJ range	2010-2012	Normally aspirated V6 3.0L engine	RDCSM - Rear climate seat module	●	●	●	●
XJ range	2010-2012	Normally aspirated V6 3.0L engine	REM - Rear entertainment control module	●	●	●	●
XJ range	2010-2012	Normally aspirated V6 3.0L engine	RGTM - Rear gate / trunk module	●	●	●	●
XJ range	2010-2012	Normally aspirated V6 3.0L engine	module	●	●	●	●
XJ range	2010-2012	Normally aspirated V6 3.0L engine	RLM - Ride level control module	●	●	●	●
XJ range	2010-2012	Normally aspirated V6 3.0L engine	SODL - Side object detection control module - Left	●	●	●	●
XJ range	2010-2012	Normally aspirated V6 3.0L engine	SODR - Side object detection control module - Right	●	●	●	●
XJ range	2010-2012	Normally aspirated V6 3.0L engine	SPMA - Safety belt pretensioner control module A - drivers side	●	●	●	●
XJ range	2010-2012	Normally aspirated V6 3.0L engine	SPMB - Safety belt pretensioner control module B - passengers side	●	●	●	●
XJ range	2010-2012	Normally aspirated V6 3.0L engine	SRM - Satellite audio unit module.	●	●	●	●
XJ range	2010-2012	Normally aspirated V6 3.0L engine	TCM - Transmission control module	●	●	●	●
XJ range	2010-2012	Normally aspirated V6 3.0L engine	TVM - Television module	●	●	●	●
XJ range	2010-2012	Normally aspirated V6 3.0L engine	VIM - Vehicle immobilizer control module	●	●	●	●
XJ range	2010-2012	Normally aspirated V8 5.0L engine	AAM - Audio amplifier module	●	●	●	●
XJ range	2010-2012	Normally aspirated V8 5.0L engine	ABS - ABS control module	●	●	●	●
XJ range	2010-2012	Normally aspirated V8 5.0L engine	ACM - Audio front control module	●	●	●	●

Vevhicle model	Year	Engine Type/Chassis Number	System Name	Information	Read TroubleCode	Clear TroubleCode	Read DataStream
XJ range	2010-2012	Normally aspirated V8 5.0L engine	ADCM - Adaptive damping control module	●	●	●	●
XJ range	2010-2012	Normally aspirated V8 5.0L engine	BCM - Body control module	●	●	●	●
XJ range	2010-2012	Normally aspirated V8 5.0L engine	CCM - Speed control module	●	●	●	●
XJ range	2010-2012	Normally aspirated V8 5.0L engine	DABM - Digital audio broadcast module	●	●	●	●
XJ range	2010-2012	Normally aspirated V8 5.0L engine	DSCSM - Driver's climate seat module	●	●	●	●
XJ range	2010-2012	Normally aspirated V8 5.0L engine	DDM - Driver's door module	●	●	●	●
XJ range	2010-2012	Normally aspirated V8 5.0L engine	DSM - Driver's seat module	●	●	●	●
XJ range	2010-2012	Normally aspirated V8 5.0L engine	front)	●	●	●	●
XJ range	2010-2012	Normally aspirated V8 5.0L engine	panel)	●	●	●	●
XJ range	2010-2012	Normally aspirated V8 5.0L engine	GSM - Gear shift module	●	●	●	●
XJ range	2010-2012	Normally aspirated V8 5.0L engine	HCM - Headlamp control module	●	●	●	●
XJ range	2010-2012	Normally aspirated V8 5.0L engine	HCMB - Headlamp control module 'B'	●	●	●	●
XJ range	2010-2012	Normally aspirated V8 5.0L engine	HVAC - Heating ventilation and air conditioning control module	●	●	●	●
XJ range	2010-2012	Normally aspirated V8 5.0L engine	IPC - Instrument cluster control module.	●	●	●	●
XJ range	2010-2012	Normally aspirated V8 5.0L engine	KVM - Keyless vehicle module	●	●	●	●
XJ range	2010-2012	Normally aspirated V8 5.0L engine	OCS - Restraints occupant classification system module	●	●	●	●
XJ range	2010-2012	Normally aspirated V8 5.0L engine	PAM - Parking assist control module	●	●	●	●
XJ range	2010-2012	Normally aspirated V8 5.0L engine	PBM - Parking brake control module	●	●	●	●
XJ range	2010-2012	Normally aspirated V8 5.0L engine	PCM - Powertrain control module	●	●	●	●
XJ range	2010-2012	Normally aspirated V8 5.0L engine	PDM - Passenger's door module	●	●	●	●
XJ range	2010-2012	Normally aspirated V8 5.0L engine	PSM - Passenger's seat module	●	●	●	●
XJ range	2010-2012	Normally aspirated V8 5.0L engine	RCM - Restraints control module	●	●	●	●
XJ range	2010-2012	Normally aspirated V8 5.0L engine	RDCM - Rear differential control module	●	●	●	●
XJ range	2010-2012	Normally aspirated V8 5.0L engine	RDCSM - Rear climate seat module	●	●	●	●
XJ range	2010-2012	Normally aspirated V8 5.0L engine	REM - Rear entertainment control module	●	●	●	●
XJ range	2010-2012	Normally aspirated V8 5.0L engine	RGTM - Rear gate / trunk module	●	●	●	●
XJ range	2010-2012	Normally aspirated V8 5.0L engine	module	●	●	●	●
XJ range	2010-2012	Normally aspirated V8 5.0L engine	RLM - Ride level control module	●	●	●	●
XJ range	2010-2012	Normally aspirated V8 5.0L engine	SODL - Side object detection control module - Left	●	●	●	●
XJ range	2010-2012	Normally aspirated V8 5.0L engine	SODR - Side object detection control module - Right	●	●	●	●
XJ range	2010-2012	Normally aspirated V8 5.0L engine	SPMA - Safety belt pretensioner control module A - drivers side	●	●	●	●
XJ range	2010-2012	Normally aspirated V8 5.0L engine	SPMB - Safety belt pretensioner control module B - passengers side	●	●	●	●
XJ range	2010-2012	Normally aspirated V8 5.0L engine	SRM - Satellite audio unit module.	●	●	●	●
XJ range	2010-2012	Normally aspirated V8 5.0L engine	TCM - Transmission control module	●	●	●	●
XJ range	2010-2012	Normally aspirated V8 5.0L engine	TVM - Television module	●	●	●	●
XJ range	2010-2012	Normally aspirated V8 5.0L engine	VIM - Vehicle immobilizer control module	●	●	●	●
XJ range	2010-2012	Supercharged V8. 5.0L engine	AAM - Audio amplifier module	●	●	●	●
XJ range	2010-2012	Supercharged V8. 5.0L engine	ABS - ABS control module	●	●	●	●
XJ range	2010-2012	Supercharged V8. 5.0L engine	ACM - Audio front control module	●	●	●	●
XJ range	2010-2012	Supercharged V8. 5.0L engine	ADCM - Adaptive damping control module	●	●	●	●
XJ range	2010-2012	Supercharged V8. 5.0L engine	BCM - Body control module	●	●	●	●
XJ range	2010-2012	Supercharged V8. 5.0L engine	CCM - Speed control module	●	●	●	●
XJ range	2010-2012	Supercharged V8. 5.0L engine	DABM - Digital audio broadcast module	●	●	●	●
XJ range	2010-2012	Supercharged V8. 5.0L engine	DSCSM - Driver's climate seat module	●	●	●	●
XJ range	2010-2012	Supercharged V8. 5.0L engine	DDM - Driver's door module	●	●	●	●
XJ range	2010-2012	Supercharged V8. 5.0L engine	DSM - Driver's seat module	●	●	●	●
XJ range	2010-2012	Supercharged V8. 5.0L engine	front)	●	●	●	●
XJ range	2010-2012	Supercharged V8. 5.0L engine	panel)	●	●	●	●
XJ range	2010-2012	Supercharged V8. 5.0L engine	GSM - Gear shift module	●	●	●	●
XJ range	2010-2012	Supercharged V8. 5.0L engine	HCM - Headlamp control module	●	●	●	●
XJ range	2010-2012	Supercharged V8. 5.0L engine	HCMB - Headlamp control module 'B'	●	●	●	●
XJ range	2010-2012	Supercharged V8. 5.0L engine	HVAC - Heating ventilation and air conditioning control module	●	●	●	●
XJ range	2010-2012	Supercharged V8. 5.0L engine	IPC - Instrument cluster control module.	●	●	●	●
XJ range	2010-2012	Supercharged V8. 5.0L engine	KVM - Keyless vehicle module	●	●	●	●
XJ range	2010-2012	Supercharged V8. 5.0L engine	OCS - Restraints occupant classification system module	●	●	●	●
XJ range	2010-2012	Supercharged V8. 5.0L engine	PAM - Parking assist control module	●	●	●	●
XJ range	2010-2012	Supercharged V8. 5.0L engine	PBM - Parking brake control module	●	●	●	●
XJ range	2010-2012	Supercharged V8. 5.0L engine	PCM - Powertrain control module	●	●	●	●
XJ range	2010-2012	Supercharged V8. 5.0L engine	PDM - Passenger's door module	●	●	●	●
XJ range	2010-2012	Supercharged V8. 5.0L engine	PSM - Passenger's seat module	●	●	●	●
XJ range	2010-2012	Supercharged V8. 5.0L engine	RCM - Restraints control module	●	●	●	●
XJ range	2010-2012	Supercharged V8. 5.0L engine	RDCM - Rear differential control module	●	●	●	●
XJ range	2010-2012	Supercharged V8. 5.0L engine	RDCSM - Rear climate seat module	●	●	●	●
XJ range	2010-2012	Supercharged V8. 5.0L engine	REM - Rear entertainment control module	●	●	●	●
XJ range	2010-2012	Supercharged V8. 5.0L engine	RGTM - Rear gate / trunk module	●	●	●	●
XJ range	2010-2012	Supercharged V8. 5.0L engine	module	●	●	●	●
XJ range	2010-2012	Supercharged V8. 5.0L engine	RLM - Ride level control module	●	●	●	●
XJ range	2010-2012	Supercharged V8. 5.0L engine	SODL - Side object detection control module - Left	●	●	●	●
XJ range	2010-2012	Supercharged V8. 5.0L engine	SODR - Side object detection control module - Right	●	●	●	●
XJ range	2010-2012	Supercharged V8. 5.0L engine	SPMA - Safety belt pretensioner control module A - drivers side	●	●	●	●
XJ range	2010-2012	Supercharged V8. 5.0L engine	SPMB - Safety belt pretensioner control module B - passengers side	●	●	●	●
XJ range	2010-2012	Supercharged V8. 5.0L engine	SRM - Satellite audio unit module.	●	●	●	●
XJ range	2010-2012	Supercharged V8. 5.0L engine	TCM - Transmission control module	●	●	●	●
XJ range	2010-2012	Supercharged V8. 5.0L engine	TVM - Television module	●	●	●	●
XJ range	2010-2012	Supercharged V8. 5.0L engine	VIM - Vehicle immobilizer control module	●	●	●	●
XJ range	2013-2015	Diesel V6	AAM - Audio amplifier module	●	●	●	●
XJ range	2013-2015	Diesel V6	ABS - ABS control module	●	●	●	●
XJ range	2013-2015	Diesel V6	ACM - Audio front control module	●	●	●	●
XJ range	2013-2015	Diesel V6	BCM - Body control module	●	●	●	●
XJ range	2013-2015	Diesel V6	CCM - Speed control module	●	●	●	●
XJ range	2013-2015	Diesel V6	CHCM - Chassis control module	●	●	●	●
XJ range	2013-2015	Diesel V6	DABM - Digital audio broadcast module	●	●	●	●
XJ range	2013-2015	Diesel V6	DDM - Driver's door module	●	●	●	●
XJ range	2013-2015	Diesel V6	DSM - Driver's seat module	●	●	●	●
XJ range	2013-2015	Diesel V6	front)	●	●	●	●
XJ range	2013-2015	Diesel V6	panel)	●	●	●	●
XJ range	2013-2015	Diesel V6	GSM - Gear shift module	●	●	●	●

Vevhicle model	Year	Engine Type/Chassis Number	System Name	Information	Read TroubleCode	Clear TroubleCode	Read DataStream
XJ range	2013-2015	Diesel V6	GWM - Gateway module	●	●	●	●
XJ range	2013-2015	Diesel V6	HCM - Headlamp control module	●	●	●	●
XJ range	2013-2015	Diesel V6	HCMB - Headlamp control module B	●	●	●	●
XJ range	2013-2015	Diesel V6	HVAC - Heating ventilation and air conditioning control module	●	●	●	●
XJ range	2013-2015	Diesel V6	IPC - Instrument cluster control module.	●	●	●	●
XJ range	2013-2015	Diesel V6	NCM - Navigation control module	●	●	●	●
XJ range	2013-2015	Diesel V6	OCS - Restraints occupant classification system module	●	●	●	●
XJ range	2013-2015	Diesel V6	PAM - Parking assist control module	●	●	●	●
XJ range	2013-2015	Diesel V6	PBM - Parking brake control module	●	●	●	●
XJ range	2013-2015	Diesel V6	PCM - Powertrain control module	●	●	●	●
XJ range	2013-2015	Diesel V6	PDM - Passenger's door module	●	●	●	●
XJ range	2013-2015	Diesel V6	PSM - Passenger's seat module	●	●	●	●
XJ range	2013-2015	Diesel V6	RCM - Restraints control module	●	●	●	●
XJ range	2013-2015	Diesel V6	RDCM - Rear differential control module	●	●	●	●
XJ range	2013-2015	Diesel V6	REM - Rear entertainment control module	●	●	●	●
XJ range	2013-2015	Diesel V6	RFA - Keyless vehicle module	●	●	●	●
XJ range	2013-2015	Diesel V6	RGTM - Rear gate / trunk module	●	●	●	●
XJ range	2013-2015	Diesel V6	module	●	●	●	●
XJ range	2013-2015	Diesel V6	RLSM - Rear seat - Control module - Left	●	●	●	●
XJ range	2013-2015	Diesel V6	RRSM - Rear seat - Control module - Right	●	●	●	●
XJ range	2013-2015	Diesel V6	SCME - Driver's climate seat module	●	●	●	●
XJ range	2013-2015	Diesel V6	SCMF - Rear climate seat module	●	●	●	●
XJ range	2013-2015	Diesel V6	SODL - Side object detection control module - Left	●	●	●	●
XJ range	2013-2015	Diesel V6	SODR - Side object detection control module - Right	●	●	●	●
XJ range	2013-2015	Diesel V6	SPMA - Safety belt pretensioner control module A - drivers side	●	●	●	●
XJ range	2013-2015	Diesel V6	SPMB - Safety belt pretensioner control module B - passengers side	●	●	●	●
XJ range	2013-2015	Diesel V6	SRM - Satellite audio unit module.	●	●	●	●
XJ range	2013-2015	Diesel V6	TCCM - Transfer case control module	●	●	●	●
XJ range	2013-2015	Diesel V6	TCM - Transmission control module	●	●	●	●
XJ range	2013-2015	Diesel V6	TVM - Television module	●	●	●	●
XJ range	2013-2015	Diesel V6	VIM - Vehicle immobilizer control module	●	●	●	●
XJ range	2013-2015	GTDI 2.0L engine	AAM - Audio amplifier module	●	●	●	●
XJ range	2013-2015	GTDI 2.0L engine	ABS - ABS control module	●	●	●	●
XJ range	2013-2015	GTDI 2.0L engine	ACM - Audio front control module	●	●	●	●
XJ range	2013-2015	GTDI 2.0L engine	BCM - Body control module	●	●	●	●
XJ range	2013-2015	GTDI 2.0L engine	CCM - Speed control module	●	●	●	●
XJ range	2013-2015	GTDI 2.0L engine	CHCM - Chassis control module	●	●	●	●
XJ range	2013-2015	GTDI 2.0L engine	DABM - Digital audio broadcast module	●	●	●	●
XJ range	2013-2015	GTDI 2.0L engine	DDM - Driver's door module	●	●	●	●
XJ range	2013-2015	GTDI 2.0L engine	DSM - Driver's seat module	●	●	●	●
XJ range	2013-2015	GTDI 2.0L engine	front)	●	●	●	●
XJ range	2013-2015	GTDI 2.0L engine	panel)	●	●	●	●
XJ range	2013-2015	GTDI 2.0L engine	GSM - Gear shift module	●	●	●	●
XJ range	2013-2015	GTDI 2.0L engine	GWM - Gateway module	●	●	●	●
XJ range	2013-2015	GTDI 2.0L engine	HCM - Headlamp control module	●	●	●	●
XJ range	2013-2015	GTDI 2.0L engine	HCMB - Headlamp control module B	●	●	●	●
XJ range	2013-2015	GTDI 2.0L engine	HVAC - Heating ventilation and air conditioning control module	●	●	●	●
XJ range	2013-2015	GTDI 2.0L engine	IPC - Instrument cluster control module.	●	●	●	●
XJ range	2013-2015	GTDI 2.0L engine	NCM - Navigation control module	●	●	●	●
XJ range	2013-2015	GTDI 2.0L engine	OCS - Restraints occupant classification system module	●	●	●	●
XJ range	2013-2015	GTDI 2.0L engine	PAM - Parking assist control module	●	●	●	●
XJ range	2013-2015	GTDI 2.0L engine	PBM - Parking brake control module	●	●	●	●
XJ range	2013-2015	GTDI 2.0L engine	PCM - Powertrain control module	●	●	●	●
XJ range	2013-2015	GTDI 2.0L engine	PDM - Passenger's door module	●	●	●	●
XJ range	2013-2015	GTDI 2.0L engine	PSM - Passenger's seat module	●	●	●	●
XJ range	2013-2015	GTDI 2.0L engine	RCM - Restraints control module	●	●	●	●
XJ range	2013-2015	GTDI 2.0L engine	RDCM - Rear differential control module	●	●	●	●
XJ range	2013-2015	GTDI 2.0L engine	REM - Rear entertainment control module	●	●	●	●
XJ range	2013-2015	GTDI 2.0L engine	RFA - Keyless vehicle module	●	●	●	●
XJ range	2013-2015	GTDI 2.0L engine	RGTM - Rear gate / trunk module	●	●	●	●
XJ range	2013-2015	GTDI 2.0L engine	module	●	●	●	●
XJ range	2013-2015	GTDI 2.0L engine	RLSM - Rear seat - Control module - Left	●	●	●	●
XJ range	2013-2015	GTDI 2.0L engine	RRSM - Rear seat - Control module - Right	●	●	●	●
XJ range	2013-2015	GTDI 2.0L engine	SCME - Driver's climate seat module	●	●	●	●
XJ range	2013-2015	GTDI 2.0L engine	SCMF - Rear climate seat module	●	●	●	●
XJ range	2013-2015	GTDI 2.0L engine	SODL - Side object detection control module - Left	●	●	●	●
XJ range	2013-2015	GTDI 2.0L engine	SODR - Side object detection control module - Right	●	●	●	●
XJ range	2013-2015	GTDI 2.0L engine	SPMA - Safety belt pretensioner control module A - drivers side	●	●	●	●
XJ range	2013-2015	GTDI 2.0L engine	SPMB - Safety belt pretensioner control module B - passengers side	●	●	●	●
XJ range	2013-2015	GTDI 2.0L engine	SRM - Satellite audio unit module.	●	●	●	●
XJ range	2013-2015	GTDI 2.0L engine	TCCM - Transfer case control module	●	●	●	●
XJ range	2013-2015	GTDI 2.0L engine	TCM - Transmission control module	●	●	●	●
XJ range	2013-2015	GTDI 2.0L engine	TVM - Television module	●	●	●	●
XJ range	2013-2015	GTDI 2.0L engine	VIM - Vehicle immobilizer control module	●	●	●	●
XJ range	2013-2015	Normally aspirated V8 5.0L engine	AAM - Audio amplifier module	●	●	●	●
XJ range	2013-2015	Normally aspirated V8 5.0L engine	ABS - ABS control module	●	●	●	●
XJ range	2013-2015	Normally aspirated V8 5.0L engine	ACM - Audio front control module	●	●	●	●
XJ range	2013-2015	Normally aspirated V8 5.0L engine	BCM - Body control module	●	●	●	●
XJ range	2013-2015	Normally aspirated V8 5.0L engine	CCM - Speed control module	●	●	●	●
XJ range	2013-2015	Normally aspirated V8 5.0L engine	CHCM - Chassis control module	●	●	●	●
XJ range	2013-2015	Normally aspirated V8 5.0L engine	DABM - Digital audio broadcast module	●	●	●	●
XJ range	2013-2015	Normally aspirated V8 5.0L engine	DDM - Driver's door module	●	●	●	●
XJ range	2013-2015	Normally aspirated V8 5.0L engine	DSM - Driver's seat module	●	●	●	●
XJ range	2013-2015	Normally aspirated V8 5.0L engine	front)	●	●	●	●
XJ range	2013-2015	Normally aspirated V8 5.0L engine	panel)	●	●	●	●
XJ range	2013-2015	Normally aspirated V8 5.0L engine	GSM - Gear shift module	●	●	●	●
XJ range	2013-2015	Normally aspirated V8 5.0L engine	GWM - Gateway module	●	●	●	●



Vevhicle model	Year	Engine Type/Chassis Number	System Name	Information	Read TroubleCode	Clear TroubleCode	Read DataStream
XJ range	2013-2015	Normally aspirated V8 5.0L engine	HCM - Headlamp control module	●	●	●	●
XJ range	2013-2015	Normally aspirated V8 5.0L engine	HCMB - Headlamp control module B	●	●	●	●
XJ range	2013-2015	Normally aspirated V8 5.0L engine	HVAC - Heating ventilation and air conditioning control module	●	●	●	●
XJ range	2013-2015	Normally aspirated V8 5.0L engine	IPC - Instrument cluster control module.	●	●	●	●
XJ range	2013-2015	Normally aspirated V8 5.0L engine	NCM - Navigation control module	●	●	●	●
XJ range	2013-2015	Normally aspirated V8 5.0L engine	OCS - Restraints occupant classification system module	●	●	●	●
XJ range	2013-2015	Normally aspirated V8 5.0L engine	PAM - Parking assist control module	●	●	●	●
XJ range	2013-2015	Normally aspirated V8 5.0L engine	PBM - Parking brake control module	●	●	●	●
XJ range	2013-2015	Normally aspirated V8 5.0L engine	PCM - Powertrain control module	●	●	●	●
XJ range	2013-2015	Normally aspirated V8 5.0L engine	PDM - Passenger's door module	●	●	●	●
XJ range	2013-2015	Normally aspirated V8 5.0L engine	PSM - Passenger's seat module	●	●	●	●
XJ range	2013-2015	Normally aspirated V8 5.0L engine	RCM - Restraints control module	●	●	●	●
XJ range	2013-2015	Normally aspirated V8 5.0L engine	RDCM - Rear differential control module	●	●	●	●
XJ range	2013-2015	Normally aspirated V8 5.0L engine	REM - Rear entertainment control module	●	●	●	●
XJ range	2013-2015	Normally aspirated V8 5.0L engine	RFA - Keyless vehicle module	●	●	●	●
XJ range	2013-2015	Normally aspirated V8 5.0L engine	RGTM - Rear gate / trunk module	●	●	●	●
XJ range	2013-2015	Normally aspirated V8 5.0L engine	module	●	●	●	●
XJ range	2013-2015	Normally aspirated V8 5.0L engine	RLSM - Rear seat - Control module - Left	●	●	●	●
XJ range	2013-2015	Normally aspirated V8 5.0L engine	RRSM - Rear seat - Control module - Right	●	●	●	●
XJ range	2013-2015	Normally aspirated V8 5.0L engine	SCME - Driver's climate seat module	●	●	●	●
XJ range	2013-2015	Normally aspirated V8 5.0L engine	SCMF - Rear climate seat module	●	●	●	●
XJ range	2013-2015	Normally aspirated V8 5.0L engine	SODL - Side object detection control module - Left	●	●	●	●
XJ range	2013-2015	Normally aspirated V8 5.0L engine	SODR - Side object detection control module - Right	●	●	●	●
XJ range	2013-2015	Normally aspirated V8 5.0L engine	SPMA - Safety belt pretensioner control module A - drivers side	●	●	●	●
XJ range	2013-2015	Normally aspirated V8 5.0L engine	SPMB - Safety belt pretensioner control module B - passengers side	●	●	●	●
XJ range	2013-2015	Normally aspirated V8 5.0L engine	SRM - Satellite audio unit module.	●	●	●	●
XJ range	2013-2015	Normally aspirated V8 5.0L engine	TCCM - Transfer case control module	●	●	●	●
XJ range	2013-2015	Normally aspirated V8 5.0L engine	TCM - Transmission control module	●	●	●	●
XJ range	2013-2015	Normally aspirated V8 5.0L engine	TVM - Television module	●	●	●	●
XJ range	2013-2015	Normally aspirated V8 5.0L engine	VIM - Vehicle immobilizer control module	●	●	●	●
XJ range	2013-2015	Supercharged V6	AAM - Audio amplifier module	●	●	●	●
XJ range	2013-2015	Supercharged V6	ABS - ABS control module	●	●	●	●
XJ range	2013-2015	Supercharged V6	ACM - Audio front control module	●	●	●	●
XJ range	2013-2015	Supercharged V6	BCM - Body control module	●	●	●	●
XJ range	2013-2015	Supercharged V6	CCM - Speed control module	●	●	●	●
XJ range	2013-2015	Supercharged V6	CHCM - Chassis control module	●	●	●	●
XJ range	2013-2015	Supercharged V6	DABM - Digital audio broadcast module	●	●	●	●
XJ range	2013-2015	Supercharged V6	DDM - Driver's door module	●	●	●	●
XJ range	2013-2015	Supercharged V6	DSM - Driver's seat module	●	●	●	●
XJ range	2013-2015	Supercharged V6	front)	●	●	●	●
XJ range	2013-2015	Supercharged V6	panel)	●	●	●	●
XJ range	2013-2015	Supercharged V6	GSM - Gear shift module	●	●	●	●
XJ range	2013-2015	Supercharged V6	GWM - Gateway module	●	●	●	●
XJ range	2013-2015	Supercharged V6	HCM - Headlamp control module	●	●	●	●
XJ range	2013-2015	Supercharged V6	HCMB - Headlamp control module B	●	●	●	●
XJ range	2013-2015	Supercharged V6	HVAC - Heating ventilation and air conditioning control module	●	●	●	●
XJ range	2013-2015	Supercharged V6	IPC - Instrument cluster control module.	●	●	●	●
XJ range	2013-2015	Supercharged V6	NCM - Navigation control module	●	●	●	●
XJ range	2013-2015	Supercharged V6	OCS - Restraints occupant classification system module	●	●	●	●
XJ range	2013-2015	Supercharged V6	PAM - Parking assist control module	●	●	●	●
XJ range	2013-2015	Supercharged V6	PBM - Parking brake control module	●	●	●	●
XJ range	2013-2015	Supercharged V6	PCM - Powertrain control module	●	●	●	●
XJ range	2013-2015	Supercharged V6	PDM - Passenger's door module	●	●	●	●
XJ range	2013-2015	Supercharged V6	PSM - Passenger's seat module	●	●	●	●
XJ range	2013-2015	Supercharged V6	RCM - Restraints control module	●	●	●	●
XJ range	2013-2015	Supercharged V6	RDCM - Rear differential control module	●	●	●	●
XJ range	2013-2015	Supercharged V6	REM - Rear entertainment control module	●	●	●	●
XJ range	2013-2015	Supercharged V6	RFA - Keyless vehicle module	●	●	●	●
XJ range	2013-2015	Supercharged V6	RGTM - Rear gate / trunk module	●	●	●	●
XJ range	2013-2015	Supercharged V6	module	●	●	●	●
XJ range	2013-2015	Supercharged V6	RLSM - Rear seat - Control module - Left	●	●	●	●
XJ range	2013-2015	Supercharged V6	RRSM - Rear seat - Control module - Right	●	●	●	●
XJ range	2013-2015	Supercharged V6	SCME - Driver's climate seat module	●	●	●	●
XJ range	2013-2015	Supercharged V6	SCMF - Rear climate seat module	●	●	●	●
XJ range	2013-2015	Supercharged V6	SODL - Side object detection control module - Left	●	●	●	●
XJ range	2013-2015	Supercharged V6	SODR - Side object detection control module - Right	●	●	●	●
XJ range	2013-2015	Supercharged V6	SPMA - Safety belt pretensioner control module A - drivers side	●	●	●	●
XJ range	2013-2015	Supercharged V6	SPMB - Safety belt pretensioner control module B - passengers side	●	●	●	●
XJ range	2013-2015	Supercharged V6	SRM - Satellite audio unit module.	●	●	●	●
XJ range	2013-2015	Supercharged V6	TCCM - Transfer case control module	●	●	●	●
XJ range	2013-2015	Supercharged V6	TCM - Transmission control module	●	●	●	●
XJ range	2013-2015	Supercharged V6	TVM - Television module	●	●	●	●
XJ range	2013-2015	Supercharged V6	VIM - Vehicle immobilizer control module	●	●	●	●
XJ range	2013-2015	Supercharged V8. 5.0L engine	AAM - Audio amplifier module	●	●	●	●
XJ range	2013-2015	Supercharged V8. 5.0L engine	ABS - ABS control module	●	●	●	●
XJ range	2013-2015	Supercharged V8. 5.0L engine	ACM - Audio front control module	●	●	●	●
XJ range	2013-2015	Supercharged V8. 5.0L engine	BCM - Body control module	●	●	●	●
XJ range	2013-2015	Supercharged V8. 5.0L engine	CCM - Speed control module	●	●	●	●
XJ range	2013-2015	Supercharged V8. 5.0L engine	CHCM - Chassis control module	●	●	●	●
XJ range	2013-2015	Supercharged V8. 5.0L engine	DABM - Digital audio broadcast module	●	●	●	●
XJ range	2013-2015	Supercharged V8. 5.0L engine	DDM - Driver's door module	●	●	●	●
XJ range	2013-2015	Supercharged V8. 5.0L engine	DSM - Driver's seat module	●	●	●	●
XJ range	2013-2015	Supercharged V8. 5.0L engine	front)	●	●	●	●
XJ range	2013-2015	Supercharged V8. 5.0L engine	panel)	●	●	●	●
XJ range	2013-2015	Supercharged V8. 5.0L engine	GSM - Gear shift module	●	●	●	●
XJ range	2013-2015	Supercharged V8. 5.0L engine	GWM - Gateway module	●	●	●	●
XJ range	2013-2015	Supercharged V8. 5.0L engine	HCM - Headlamp control module	●	●	●	●

Vevhicle model	Year	Engine Type/Chassis Number	System Name	Information	Read TroubleCode	Clear TroubleCode	Read DataStream
XJ range	2013-2015	Supercharged V8. 5.0L engine	HCMB - Headlamp control module B	●	●	●	●
XJ range	2013-2015	Supercharged V8. 5.0L engine	HVAC - Heating ventilation and air conditioning control module	●	●	●	●
XJ range	2013-2015	Supercharged V8. 5.0L engine	IPC - Instrument cluster control module.	●	●	●	●
XJ range	2013-2015	Supercharged V8. 5.0L engine	NCM - Navigation control module	●	●	●	●
XJ range	2013-2015	Supercharged V8. 5.0L engine	OCS - Restraints occupant classification system module	●	●	●	●
XJ range	2013-2015	Supercharged V8. 5.0L engine	PAM - Parking assist control module	●	●	●	●
XJ range	2013-2015	Supercharged V8. 5.0L engine	PBM - Parking brake control module	●	●	●	●
XJ range	2013-2015	Supercharged V8. 5.0L engine	PCM - Powertrain control module	●	●	●	●
XJ range	2013-2015	Supercharged V8. 5.0L engine	PDM - Passenger's door module	●	●	●	●
XJ range	2013-2015	Supercharged V8. 5.0L engine	PSM - Passenger's seat module	●	●	●	●
XJ range	2013-2015	Supercharged V8. 5.0L engine	RCM - Restraints control module	●	●	●	●
XJ range	2013-2015	Supercharged V8. 5.0L engine	RDCM - Rear differential control module	●	●	●	●
XJ range	2013-2015	Supercharged V8. 5.0L engine	REM - Rear entertainment control module	●	●	●	●
XJ range	2013-2015	Supercharged V8. 5.0L engine	RFA - Keyless vehicle module	●	●	●	●
XJ range	2013-2015	Supercharged V8. 5.0L engine	RGTM - Rear gate / trunk module	●	●	●	●
XJ range	2013-2015	Supercharged V8. 5.0L engine	module	●	●	●	●
XJ range	2013-2015	Supercharged V8. 5.0L engine	RLSM - Rear seat - Control module - Left	●	●	●	●
XJ range	2013-2015	Supercharged V8. 5.0L engine	RRSM - Rear seat - Control module - Right	●	●	●	●
XJ range	2013-2015	Supercharged V8. 5.0L engine	SCME - Driver's climate seat module	●	●	●	●
XJ range	2013-2015	Supercharged V8. 5.0L engine	SCMF - Rear climate seat module	●	●	●	●
XJ range	2013-2015	Supercharged V8. 5.0L engine	SODL - Side object detection control module - Left	●	●	●	●
XJ range	2013-2015	Supercharged V8. 5.0L engine	SODR - Side object detection control module - Right	●	●	●	●
XJ range	2013-2015	Supercharged V8. 5.0L engine	SPMA - Safety belt pretensioner control module A - drivers side	●	●	●	●
XJ range	2013-2015	Supercharged V8. 5.0L engine	SPMB - Safety belt pretensioner control module B - passengers side	●	●	●	●
XJ range	2013-2015	Supercharged V8. 5.0L engine	SRM - Satellite audio unit module.	●	●	●	●
XJ range	2013-2015	Supercharged V8. 5.0L engine	TCCM - Transfer case control module	●	●	●	●
XJ range	2013-2015	Supercharged V8. 5.0L engine	TCM - Transmission control module	●	●	●	●
XJ range	2013-2015	Supercharged V8. 5.0L engine	TVM - Television module	●	●	●	●
XJ range	2013-2015	Supercharged V8. 5.0L engine	VIM - Vehicle immobilizer control module	●	●	●	●
XJ range	2016 -	Diesel V6	AAM - InControl Touch Pro audio amplifier module	●	●	●	●
XJ range	2016 -	Diesel V6	ABS - ABS control module	●	●	●	●
XJ range	2016 -	Diesel V6	BCM - Body control module	●	●	●	●
XJ range	2016 -	Diesel V6	CCM - Speed control module	●	●	●	●
XJ range	2016 -	Diesel V6	CHCM - Chassis control module	●	●	●	●
XJ range	2016 -	Diesel V6	DDM - Driver's door module	●	●	●	●
XJ range	2016 -	Diesel V6	DSM - Driver's seat module	●	●	●	●
XJ range	2016 -	Diesel V6	FCIM - Integrated control panel	●	●	●	●
XJ range	2016 -	Diesel V6	GSM - Gear shift module	●	●	●	●
XJ range	2016 -	Diesel V6	GWM - Gateway module	●	●	●	●
XJ range	2016 -	Diesel V6	HCM - Headlamp control module	●	●	●	●
XJ range	2016 -	Diesel V6	HVAC - Heating ventilation and air conditioning control module	●	●	●	●
XJ range	2016 -	Diesel V6	IMC - InControl Touch Pro infotainment master controller	●	●	●	●
XJ range	2016 -	Diesel V6	IPC - Instrument cluster control module.	●	●	●	●
XJ range	2016 -	Diesel V6	IPMA - Image processing control module A	●	●	●	●
XJ range	2016 -	Diesel V6	IPMB - Image processing module B	●	●	●	●
XJ range	2016 -	Diesel V6	ISC - InControl Touch Pro infotainment slave controller	●	●	●	●
XJ range	2016 -	Diesel V6	OCS - Restraints occupant classification system module	●	●	●	●
XJ range	2016 -	Diesel V6	PAM - Parking assist control module	●	●	●	●
XJ range	2016 -	Diesel V6	PBM - Parking brake control module	●	●	●	●
XJ range	2016 -	Diesel V6	PCM - Powertrain control module	●	●	●	●
XJ range	2016 -	Diesel V6	PDM - Passenger's door module	●	●	●	●
XJ range	2016 -	Diesel V6	PSCM - Power steering control module	●	●	●	●
XJ range	2016 -	Diesel V6	PSM - Passenger's seat module	●	●	●	●
XJ range	2016 -	Diesel V6	RCM - Restraints control module	●	●	●	●
XJ range	2016 -	Diesel V6	RDCM - Rear differential control module	●	●	●	●
XJ range	2016 -	Diesel V6	RFA - Keyless vehicle module	●	●	●	●
XJ range	2016 -	Diesel V6	RGTM - Rear gate / trunk module	●	●	●	●
XJ range	2016 -	Diesel V6	module	●	●	●	●
XJ range	2016 -	Diesel V6	RLSM - Rear seat - Control module - Left	●	●	●	●
XJ range	2016 -	Diesel V6	RRSM - Rear seat - Control module - Right	●	●	●	●
XJ range	2016 -	Diesel V6	SASM - Steering angle sensor module	●	●	●	●
XJ range	2016 -	Diesel V6	SODL - Side object detection control module - Left	●	●	●	●
XJ range	2016 -	Diesel V6	SODR - Side object detection control module - Right	●	●	●	●
XJ range	2016 -	Diesel V6	TCCM - Transfer case control module	●	●	●	●
XJ range	2016 -	Diesel V6	TCM - Transmission control module	●	●	●	●
XJ range	2016 -	Diesel V6	TCU - Telematic control unit module	●	●	●	●
XJ range	2016 -	Diesel V6	TPM - Tire pressure monitor module	●	●	●	●
XJ range	2016 -	Diesel V6	VDM - Vehicle dynamics control module	●	●	●	●
XJ range	2016 -	Diesel V6	VIM - Vehicle immobilizer control module	●	●	●	●
XJ range	2016 -	GTDI 2.0L engine	AAM - InControl Touch Pro audio amplifier module	●	●	●	●
XJ range	2016 -	GTDI 2.0L engine	ABS - ABS control module	●	●	●	●
XJ range	2016 -	GTDI 2.0L engine	BCM - Body control module	●	●	●	●
XJ range	2016 -	GTDI 2.0L engine	CCM - Speed control module	●	●	●	●
XJ range	2016 -	GTDI 2.0L engine	CHCM - Chassis control module	●	●	●	●
XJ range	2016 -	GTDI 2.0L engine	DDM - Driver's door module	●	●	●	●
XJ range	2016 -	GTDI 2.0L engine	DSM - Driver's seat module	●	●	●	●
XJ range	2016 -	GTDI 2.0L engine	FCIM - Integrated control panel	●	●	●	●
XJ range	2016 -	GTDI 2.0L engine	GSM - Gear shift module	●	●	●	●
XJ range	2016 -	GTDI 2.0L engine	GWM - Gateway module	●	●	●	●
XJ range	2016 -	GTDI 2.0L engine	HCM - Headlamp control module	●	●	●	●
XJ range	2016 -	GTDI 2.0L engine	HVAC - Heating ventilation and air conditioning control module	●	●	●	●
XJ range	2016 -	GTDI 2.0L engine	IMC - InControl Touch Pro infotainment master controller	●	●	●	●
XJ range	2016 -	GTDI 2.0L engine	IPC - Instrument cluster control module.	●	●	●	●
XJ range	2016 -	GTDI 2.0L engine	IPMA - Image processing control module A	●	●	●	●
XJ range	2016 -	GTDI 2.0L engine	IPMB - Image processing module B	●	●	●	●
XJ range	2016 -	GTDI 2.0L engine	ISC - InControl Touch Pro infotainment slave controller	●	●	●	●
XJ range	2016 -	GTDI 2.0L engine	OCS - Restraints occupant classification system module	●	●	●	●

Vevhicle model	Year	Engine Type/Chassis Number	System Name	Information	Read TroubleCode	Clear TroubleCode	Read DataStream
XJ range	2016 -	GTDI 2.0L engine	PAM - Parking assist control module	●	●	●	●
XJ range	2016 -	GTDI 2.0L engine	PBM - Parking brake control module	●	●	●	●
XJ range	2016 -	GTDI 2.0L engine	PCM - Powertrain control module	●	●	●	●
XJ range	2016 -	GTDI 2.0L engine	PDM - Passenger's door module	●	●	●	●
XJ range	2016 -	GTDI 2.0L engine	PSCM - Power steering control module	●	●	●	●
XJ range	2016 -	GTDI 2.0L engine	PSM - Passenger's seat module	●	●	●	●
XJ range	2016 -	GTDI 2.0L engine	RCM - Restraints control module	●	●	●	●
XJ range	2016 -	GTDI 2.0L engine	RDCM - Rear differential control module	●	●	●	●
XJ range	2016 -	GTDI 2.0L engine	RFA - Keyless vehicle module	●	●	●	●
XJ range	2016 -	GTDI 2.0L engine	RGTM - Rear gate / trunk module	●	●	●	●
XJ range	2016 -	GTDI 2.0L engine	module	●	●	●	●
XJ range	2016 -	GTDI 2.0L engine	RLSM - Rear seat - Control module - Left	●	●	●	●
XJ range	2016 -	GTDI 2.0L engine	RRSM - Rear seat - Control module - Right	●	●	●	●
XJ range	2016 -	GTDI 2.0L engine	SASM - Steering angle sensor module	●	●	●	●
XJ range	2016 -	GTDI 2.0L engine	SODL - Side object detection control module - Left	●	●	●	●
XJ range	2016 -	GTDI 2.0L engine	SODR - Side object detection control module - Right	●	●	●	●
XJ range	2016 -	GTDI 2.0L engine	TCCM - Transfer case control module	●	●	●	●
XJ range	2016 -	GTDI 2.0L engine	TCM - Transmission control module	●	●	●	●
XJ range	2016 -	GTDI 2.0L engine	TCU - Telematic control unit module	●	●	●	●
XJ range	2016 -	GTDI 2.0L engine	TPM - Tire pressure monitor module	●	●	●	●
XJ range	2016 -	GTDI 2.0L engine	VDM - Vehicle dynamics control module	●	●	●	●
XJ range	2016 -	GTDI 2.0L engine	VIM - Vehicle immobilizer control module	●	●	●	●
XJ range	2016 -	Supercharged V6	AAM - InControl Touch Pro audio amplifier module	●	●	●	●
XJ range	2016 -	Supercharged V6	ABS - ABS control module	●	●	●	●
XJ range	2016 -	Supercharged V6	BCM - Body control module	●	●	●	●
XJ range	2016 -	Supercharged V6	CCM - Speed control module	●	●	●	●
XJ range	2016 -	Supercharged V6	CHCM - Chassis control module	●	●	●	●
XJ range	2016 -	Supercharged V6	DDM - Driver's door module	●	●	●	●
XJ range	2016 -	Supercharged V6	DSM - Driver's seat module	●	●	●	●
XJ range	2016 -	Supercharged V6	FCIM - Integrated control panel	●	●	●	●
XJ range	2016 -	Supercharged V6	GSM - Gear shift module	●	●	●	●
XJ range	2016 -	Supercharged V6	GWM - Gateway module	●	●	●	●
XJ range	2016 -	Supercharged V6	HCM - Headlamp control module	●	●	●	●
XJ range	2016 -	Supercharged V6	HVAC - Heating ventilation and air conditioning control module	●	●	●	●
XJ range	2016 -	Supercharged V6	IMC - InControl Touch Pro infotainment master controller	●	●	●	●
XJ range	2016 -	Supercharged V6	IPC - Instrument cluster control module.	●	●	●	●
XJ range	2016 -	Supercharged V6	IPMA - Image processing control module A	●	●	●	●
XJ range	2016 -	Supercharged V6	IPMB - Image processing module B	●	●	●	●
XJ range	2016 -	Supercharged V6	ISC - InControl Touch Pro infotainment slave controller	●	●	●	●
XJ range	2016 -	Supercharged V6	OCS - Restraints occupant classification system module	●	●	●	●
XJ range	2016 -	Supercharged V6	PAM - Parking assist control module	●	●	●	●
XJ range	2016 -	Supercharged V6	PBM - Parking brake control module	●	●	●	●
XJ range	2016 -	Supercharged V6	PCM - Powertrain control module	●	●	●	●
XJ range	2016 -	Supercharged V6	PDM - Passenger's door module	●	●	●	●
XJ range	2016 -	Supercharged V6	PSCM - Power steering control module	●	●	●	●
XJ range	2016 -	Supercharged V6	PSM - Passenger's seat module	●	●	●	●
XJ range	2016 -	Supercharged V6	RCM - Restraints control module	●	●	●	●
XJ range	2016 -	Supercharged V6	RDCM - Rear differential control module	●	●	●	●
XJ range	2016 -	Supercharged V6	RFA - Keyless vehicle module	●	●	●	●
XJ range	2016 -	Supercharged V6	RGTM - Rear gate / trunk module	●	●	●	●
XJ range	2016 -	Supercharged V6	module	●	●	●	●
XJ range	2016 -	Supercharged V6	RLSM - Rear seat - Control module - Left	●	●	●	●
XJ range	2016 -	Supercharged V6	RRSM - Rear seat - Control module - Right	●	●	●	●
XJ range	2016 -	Supercharged V6	SASM - Steering angle sensor module	●	●	●	●
XJ range	2016 -	Supercharged V6	SODL - Side object detection control module - Left	●	●	●	●
XJ range	2016 -	Supercharged V6	SODR - Side object detection control module - Right	●	●	●	●
XJ range	2016 -	Supercharged V6	TCCM - Transfer case control module	●	●	●	●
XJ range	2016 -	Supercharged V6	TCM - Transmission control module	●	●	●	●
XJ range	2016 -	Supercharged V6	TCU - Telematic control unit module	●	●	●	●
XJ range	2016 -	Supercharged V6	TPM - Tire pressure monitor module	●	●	●	●
XJ range	2016 -	Supercharged V6	VDM - Vehicle dynamics control module	●	●	●	●
XJ range	2016 -	Supercharged V6	VIM - Vehicle immobilizer control module	●	●	●	●
XJ range	2016 -	Supercharged V8. 5.0L engine	AAM - InControl Touch Pro audio amplifier module	●	●	●	●
XJ range	2016 -	Supercharged V8. 5.0L engine	ABS - ABS control module	●	●	●	●
XJ range	2016 -	Supercharged V8. 5.0L engine	BCM - Body control module	●	●	●	●
XJ range	2016 -	Supercharged V8. 5.0L engine	CCM - Speed control module	●	●	●	●
XJ range	2016 -	Supercharged V8. 5.0L engine	CHCM - Chassis control module	●	●	●	●
XJ range	2016 -	Supercharged V8. 5.0L engine	DDM - Driver's door module	●	●	●	●
XJ range	2016 -	Supercharged V8. 5.0L engine	DSM - Driver's seat module	●	●	●	●
XJ range	2016 -	Supercharged V8. 5.0L engine	FCIM - Integrated control panel	●	●	●	●
XJ range	2016 -	Supercharged V8. 5.0L engine	GSM - Gear shift module	●	●	●	●
XJ range	2016 -	Supercharged V8. 5.0L engine	GWM - Gateway module	●	●	●	●
XJ range	2016 -	Supercharged V8. 5.0L engine	HCM - Headlamp control module	●	●	●	●
XJ range	2016 -	Supercharged V8. 5.0L engine	HVAC - Heating ventilation and air conditioning control module	●	●	●	●
XJ range	2016 -	Supercharged V8. 5.0L engine	IMC - InControl Touch Pro infotainment master controller	●	●	●	●
XJ range	2016 -	Supercharged V8. 5.0L engine	IPC - Instrument cluster control module.	●	●	●	●
XJ range	2016 -	Supercharged V8. 5.0L engine	IPMA - Image processing control module A	●	●	●	●
XJ range	2016 -	Supercharged V8. 5.0L engine	IPMB - Image processing module B	●	●	●	●
XJ range	2016 -	Supercharged V8. 5.0L engine	ISC - InControl Touch Pro infotainment slave controller	●	●	●	●
XJ range	2016 -	Supercharged V8. 5.0L engine	OCS - Restraints occupant classification system module	●	●	●	●
XJ range	2016 -	Supercharged V8. 5.0L engine	PAM - Parking assist control module	●	●	●	●
XJ range	2016 -	Supercharged V8. 5.0L engine	PBM - Parking brake control module	●	●	●	●
XJ range	2016 -	Supercharged V8. 5.0L engine	PCM - Powertrain control module	●	●	●	●
XJ range	2016 -	Supercharged V8. 5.0L engine	PDM - Passenger's door module	●	●	●	●
XJ range	2016 -	Supercharged V8. 5.0L engine	PSCM - Power steering control module	●	●	●	●
XJ range	2016 -	Supercharged V8. 5.0L engine	PSM - Passenger's seat module	●	●	●	●
XJ range	2016 -	Supercharged V8. 5.0L engine	RCM - Restraints control module	●	●	●	●

Vevhicle model	Year	Engine Type/Chassis Number	System Name	Information	Read TroubleCode	Clear TroubleCode	Read DataStream
XJ range	2016 -	Supercharged V8. 5.0L engine	RDCM - Rear differential control module	●	●	●	●
XJ range	2016 -	Supercharged V8. 5.0L engine	RFA - Keyless vehicle module	●	●	●	●
XJ range	2016 -	Supercharged V8. 5.0L engine	RGTM - Rear gate / trunk module	●	●	●	●
XJ range	2016 -	Supercharged V8. 5.0L engine	module	●	●	●	●
XJ range	2016 -	Supercharged V8. 5.0L engine	RLSM - Rear seat - Control module - Left	●	●	●	●
XJ range	2016 -	Supercharged V8. 5.0L engine	RRSM - Rear seat - Control module - Right	●	●	●	●
XJ range	2016 -	Supercharged V8. 5.0L engine	SASM - Steering angle sensor module	●	●	●	●
XJ range	2016 -	Supercharged V8. 5.0L engine	SODL - Side object detection control module - Left	●	●	●	●
XJ range	2016 -	Supercharged V8. 5.0L engine	SODR - Side object detection control module - Right	●	●	●	●
XJ range	2016 -	Supercharged V8. 5.0L engine	TCCM - Transfer case control module	●	●	●	●
XJ range	2016 -	Supercharged V8. 5.0L engine	TCM - Transmission control module	●	●	●	●
XJ range	2016 -	Supercharged V8. 5.0L engine	TCU - Telematic control unit module	●	●	●	●
XJ range	2016 -	Supercharged V8. 5.0L engine	TPM - Tire pressure monitor module	●	●	●	●
XJ range	2016 -	Supercharged V8. 5.0L engine	VDM - Vehicle dynamics control module	●	●	●	●
XJ range	2016 -	Supercharged V8. 5.0L engine	VIM - Vehicle immobilizer control module	●	●	●	●
XK	2001-2002		ABS - ABS control module	●	●	●	●
XK	2001-2002		ACC - Adaptive speed control control module.	●	●	●	○
XK	2001-2002		ADS - Adaptive damping system.	●	●	●	●
XK	2001-2002		ARM - Restraints control module	●	●	●	●
XK	2001-2002		BPM - Body processor module	●	○	●	●
XK	2001-2002		CCM - Climate control module	●	●	●	●
XK	2001-2002		DDM - Driver's door module	●	○	●	●
XK	2001-2002		DHM - Driver's head restraint module	●	●	●	●
XK	2001-2002		DSM - Driver's seat module	●	○	●	●
XK	2001-2002		ECM - Engine control module	●	●	●	●
XK	2001-2002		IPK - Instrument pack	●	●	●	●
XK	2001-2002		PDM - Passenger's door module	●	○	●	●
XK	2001-2002		PHM - Passenger's head restraint module	●	●	●	●
XK	2001-2002		PSM - Passenger's seat module	●	○	●	●
XK	2001-2002		SBC - Adaptive speed control booster control module	●	●	●	○
XK	2001-2002		SLM - Security locking module.	●	○	●	●
XK	2001-2002		TCM - Transmission control module	●	●	●	●
XK	2003-2006		ABS - ABS control module	●	●	●	●
XK	2003-2006		ACC - Adaptive speed control control module.	●	●	●	●
XK	2003-2006		ADHLS - Left lighting control module	●	●	●	●
XK	2003-2006		ADHLS - Right lighting control module	●	●	●	●
XK	2003-2006		ADRC - Adaptive damping ride control.	○	●	●	●
XK	2003-2006		ARM - Restraints control module	●	●	●	●
XK	2003-2006		ATC - Climate control module	○	●	●	●
XK	2003-2006		BPM - Body processor module	●	●	●	●
XK	2003-2006		DDM - Driver's door module	●	●	●	●
XK	2003-2006		DHM - Driver's head restraint module	●	●	●	●
XK	2003-2006		DSM - Driver's seat module	●	●	●	●
XK	2003-2006		ECM - Engine control module	●	●	●	●
XK	2003-2006		IP - Instrument pack	●	●	●	●
XK	2003-2006		PAM - Parking aid control module.	●	●	●	●
XK	2003-2006		PDM - Passenger's door module	●	●	●	●
XK	2003-2006		PHM - Passenger's head restraint module	●	●	●	●
XK	2003-2006		PSM - Passenger's seat module	●	●	●	●
XK	2003-2006		SLM - Security locking module.	●	●	●	●
XK	2003-2006		TCM - Transmission control module	●	●	●	●
XK	2006-2009	Normally aspirated V8 3.5L engine	AAM - Audio amplifier module	●	●	●	●
XK	2006-2009	Normally aspirated V8 3.5L engine	ABS - ABS control module	●	●	●	●
XK	2006-2009	Normally aspirated V8 3.5L engine	ACM - Audio front control module	●	●	●	●
XK	2006-2009	Normally aspirated V8 3.5L engine	ADCM - Adaptive damping control module	●	●	●	●
XK	2006-2009	Normally aspirated V8 3.5L engine	module)	●	●	●	●
XK	2006-2009	Normally aspirated V8 3.5L engine	CCM - Speed control module	●	●	●	●
XK	2006-2009	Normally aspirated V8 3.5L engine	DDM - Driver's door module	●	●	●	●
XK	2006-2009	Normally aspirated V8 3.5L engine	DSM - Driver's seat module	●	●	●	●
XK	2006-2009	Normally aspirated V8 3.5L engine	front)	●	●	●	●
XK	2006-2009	Normally aspirated V8 3.5L engine	FLR - Forward looking radar	●	○	●	○
XK	2006-2009	Normally aspirated V8 3.5L engine	FSJB - Central junction box (body control module)	●	●	●	●
XK	2006-2009	Normally aspirated V8 3.5L engine	FTCM - Folding top control module	●	●	●	●
XK	2006-2009	Normally aspirated V8 3.5L engine	HCM - Headlamp control module	●	●	●	●
XK	2006-2009	Normally aspirated V8 3.5L engine	HVAC - Heating ventilation and air conditioning control module	●	●	●	●
XK	2006-2009	Normally aspirated V8 3.5L engine	ICM - Infotainment control module.	●	●	●	●
XK	2006-2009	Normally aspirated V8 3.5L engine	ICP - Integrated control panel	●	●	●	○
XK	2006-2009	Normally aspirated V8 3.5L engine	ICS - Impact classification system	●	●	●	●
XK	2006-2009	Normally aspirated V8 3.5L engine	IPC - Instrument cluster control module.	●	●	●	●
XK	2006-2009	Normally aspirated V8 3.5L engine	KVM - Keyless vehicle module	●	●	●	●
XK	2006-2009	Normally aspirated V8 3.5L engine	NCM - Navigation control module	●	●	●	●
XK	2006-2009	Normally aspirated V8 3.5L engine	PAM - Parking assist control module	●	●	●	●
XK	2006-2009	Normally aspirated V8 3.5L engine	PBM - Parking brake control module	●	●	●	●
XK	2006-2009	Normally aspirated V8 3.5L engine	PCM - Powertrain control module	●	●	●	●
XK	2006-2009	Normally aspirated V8 3.5L engine	PDM - Passenger's door module	●	●	●	●
XK	2006-2009	Normally aspirated V8 3.5L engine	PSM - Passenger's seat module	●	●	●	●
XK	2006-2009	Normally aspirated V8 3.5L engine	RCM - Restraints control module	●	●	●	●
XK	2006-2009	Normally aspirated V8 3.5L engine	RSJB - Auxiliary junction box (body control module B)	●	●	●	●
XK	2006-2009	Normally aspirated V8 3.5L engine	SRM - Satellite audio unit module.	●	●	●	●
XK	2006-2009	Normally aspirated V8 3.5L engine	TCM - Transmission control module	●	●	●	●
XK	2006-2009	Normally aspirated V8 3.5L engine	TPM - Tire pressure monitor module	●	●	●	●
XK	2006-2009	Normally aspirated V8 3.5L engine	VIM - Vehicle immobilizer control module	●	●	●	●
XK	2006-2009	Normally aspirated V8 4.2L engine	AAM - Audio amplifier module	●	●	●	●
XK	2006-2009	Normally aspirated V8 4.2L engine	ABS - ABS control module	●	●	●	●
XK	2006-2009	Normally aspirated V8 4.2L engine	ACM - Audio front control module	●	●	●	●
XK	2006-2009	Normally aspirated V8 4.2L engine	ADCM - Adaptive damping control module	●	●	●	●
XK	2006-2009	Normally aspirated V8 4.2L engine	module)	●	●	●	●

Vehcile model	Year	Engine Type/Chassis Number	System Name	Information	Read TroubleCode	Clear TroubleCode	Read DataStream
XK	2006-2009	Normally aspirated V8 4.2L engine	CCM - Speed control module	●	●	●	●
XK	2006-2009	Normally aspirated V8 4.2L engine	DDM - Driver's door module	●	●	●	●
XK	2006-2009	Normally aspirated V8 4.2L engine	DSM - Driver's seat module	●	●	●	●
XK	2006-2009	Normally aspirated V8 4.2L engine	front)	●	●	●	●
XK	2006-2009	Normally aspirated V8 4.2L engine	FLR - Forward looking radar	●	○	●	○
XK	2006-2009	Normally aspirated V8 4.2L engine	FSJB - Central junction box (body control module)	●	●	●	●
XK	2006-2009	Normally aspirated V8 4.2L engine	FTCM - Folding top control module	●	●	●	●
XK	2006-2009	Normally aspirated V8 4.2L engine	HCM - Headlamp control module	●	●	●	●
XK	2006-2009	Normally aspirated V8 4.2L engine	HVAC - Heating ventilation and air conditioning control module	●	●	●	●
XK	2006-2009	Normally aspirated V8 4.2L engine	ICM - Infotainment control module.	●	●	●	●
XK	2006-2009	Normally aspirated V8 4.2L engine	ICP - Integrated control panel	●	●	●	○
XK	2006-2009	Normally aspirated V8 4.2L engine	ICS - Impact classification system	●	●	●	●
XK	2006-2009	Normally aspirated V8 4.2L engine	IPC - Instrument cluster control module.	●	●	●	●
XK	2006-2009	Normally aspirated V8 4.2L engine	KVM - Keyless vehicle module	●	●	●	●
XK	2006-2009	Normally aspirated V8 4.2L engine	NCM - Navigation control module	●	●	●	●
XK	2006-2009	Normally aspirated V8 4.2L engine	PAM - Parking assist control module	●	●	●	●
XK	2006-2009	Normally aspirated V8 4.2L engine	PBM - Parking brake control module	●	●	●	●
XK	2006-2009	Normally aspirated V8 4.2L engine	PCM - Powertrain control module	●	●	●	●
XK	2006-2009	Normally aspirated V8 4.2L engine	PDM - Passenger's door module	●	●	●	●
XK	2006-2009	Normally aspirated V8 4.2L engine	PSM - Passenger's seat module	●	●	●	●
XK	2006-2009	Normally aspirated V8 4.2L engine	RCM - Restraints control module	●	●	●	●
XK	2006-2009	Normally aspirated V8 4.2L engine	RSJB - Auxiliary junction box (body control module B)	●	●	●	●
XK	2006-2009	Normally aspirated V8 4.2L engine	SRM - Satellite audio unit module.	●	●	●	●
XK	2006-2009	Normally aspirated V8 4.2L engine	TCM - Transmission control module	●	●	●	●
XK	2006-2009	Normally aspirated V8 4.2L engine	TPM - Tire pressure monitor module	●	●	●	●
XK	2006-2009	Normally aspirated V8 4.2L engine	VIM - Vehicle immobilizer control module	●	●	●	●
XK	2006-2009	Supercharged V8	AAM - Audio amplifier module	●	●	●	●
XK	2006-2009	Supercharged V8	ABS - ABS control module	●	●	●	●
XK	2006-2009	Supercharged V8	ACM - Audio front control module	●	●	●	●
XK	2006-2009	Supercharged V8	ADCM - Adaptive damping control module	●	●	●	●
XK	2006-2009	Supercharged V8	module)	●	●	●	●
XK	2006-2009	Supercharged V8	CCM - Speed control module	●	●	●	●
XK	2006-2009	Supercharged V8	DDM - Driver's door module	●	●	●	●
XK	2006-2009	Supercharged V8	DSM - Driver's seat module	●	●	●	●
XK	2006-2009	Supercharged V8	front)	●	●	●	●
XK	2006-2009	Supercharged V8	FLR - Forward looking radar	●	○	●	○
XK	2006-2009	Supercharged V8	FSJB - Central junction box (body control module)	●	●	●	●
XK	2006-2009	Supercharged V8	FTCM - Folding top control module	●	●	●	●
XK	2006-2009	Supercharged V8	HCM - Headlamp control module	●	●	●	●
XK	2006-2009	Supercharged V8	HVAC - Heating ventilation and air conditioning control module	●	●	●	●
XK	2006-2009	Supercharged V8	ICM - Infotainment control module.	●	●	●	●
XK	2006-2009	Supercharged V8	ICP - Integrated control panel	●	●	●	○
XK	2006-2009	Supercharged V8	ICS - Impact classification system	●	●	●	●
XK	2006-2009	Supercharged V8	IPC - Instrument cluster control module.	●	●	●	●
XK	2006-2009	Supercharged V8	KVM - Keyless vehicle module	●	●	●	●
XK	2006-2009	Supercharged V8	NCM - Navigation control module	●	●	●	●
XK	2006-2009	Supercharged V8	PAM - Parking assist control module	●	●	●	●
XK	2006-2009	Supercharged V8	PBM - Parking brake control module	●	●	●	●
XK	2006-2009	Supercharged V8	PCM - Powertrain control module	●	●	●	●
XK	2006-2009	Supercharged V8	PDM - Passenger's door module	●	●	●	●
XK	2006-2009	Supercharged V8	PSM - Passenger's seat module	●	●	●	●
XK	2006-2009	Supercharged V8	RCM - Restraints control module	●	●	●	●
XK	2006-2009	Supercharged V8	RSJB - Auxiliary junction box (body control module B)	●	●	●	●
XK	2006-2009	Supercharged V8	SRM - Satellite audio unit module.	●	●	●	●
XK	2006-2009	Supercharged V8	TCM - Transmission control module	●	●	●	●
XK	2006-2009	Supercharged V8	TPM - Tire pressure monitor module	●	●	●	●
XK	2006-2009	Supercharged V8	VIM - Vehicle immobilizer control module	●	●	●	●
XK	2010-2015	Normally aspirated V8	AAM - Audio amplifier module	●	●	●	●
XK	2010-2015	Normally aspirated V8	ABS - ABS control module	●	●	●	●
XK	2010-2015	Normally aspirated V8	ACM - Audio front control module	●	●	●	●
XK	2010-2015	Normally aspirated V8	ADCM - Adaptive damping control module	●	●	●	●
XK	2010-2015	Normally aspirated V8	APIM - Accessory protocol interface module	●	●	●	●
XK	2010-2015	Normally aspirated V8	CCM - Speed control module	●	●	●	●
XK	2010-2015	Normally aspirated V8	DABM - Digital audio broadcast module	●	●	●	●
XK	2010-2015	Normally aspirated V8	DACMC - Digital audio control module C	●	●	●	●
XK	2010-2015	Normally aspirated V8	DCSM - Driver's climate seat module	●	●	●	●
XK	2010-2015	Normally aspirated V8	DDM - Driver's door module	●	●	●	●
XK	2010-2015	Normally aspirated V8	DSM - Driver's seat module	●	●	●	●
XK	2010-2015	Normally aspirated V8	front)	●	●	●	●
XK	2010-2015	Normally aspirated V8	FLR - Forward looking radar	●	○	●	○
XK	2010-2015	Normally aspirated V8	FSJB - Central junction box (body control module)	●	●	●	●
XK	2010-2015	Normally aspirated V8	FTCM - Folding top control module	●	●	●	●
XK	2010-2015	Normally aspirated V8	GSM - Gear shift module	●	●	●	●
XK	2010-2015	Normally aspirated V8	HCM - Headlamp control module	●	●	●	●
XK	2010-2015	Normally aspirated V8	HVAC - Heating ventilation and air conditioning control module	●	●	●	●
XK	2010-2015	Normally aspirated V8	ICM - Infotainment control module.	●	●	●	●
XK	2010-2015	Normally aspirated V8	ICP - Integrated control panel	●	●	●	○
XK	2010-2015	Normally aspirated V8	ICS - Impact classification system	●	●	●	●
XK	2010-2015	Normally aspirated V8	IPC - Instrument cluster control module.	●	●	●	●
XK	2010-2015	Normally aspirated V8	KVM - Keyless vehicle module	●	●	●	●
XK	2010-2015	Normally aspirated V8	NCM - Navigation control module	●	●	●	●
XK	2010-2015	Normally aspirated V8	OCS - Restraints occupant classification system module	●	●	●	●
XK	2010-2015	Normally aspirated V8	PAM - Parking assist control module	●	●	●	●
XK	2010-2015	Normally aspirated V8	PBM - Parking brake control module	●	●	●	●
XK	2010-2015	Normally aspirated V8	PCM - Powertrain control module	●	●	●	●
XK	2010-2015	Normally aspirated V8	PDM - Passenger's door module	●	●	●	●
XK	2010-2015	Normally aspirated V8	PSM - Passenger's seat module	●	●	●	●

Vevhicle model	Year	Engine Type/Chassis Number	System Name	Information	Read TroubleCode	Clear TroubleCode	Read DataStream
XK	2010-2015	Normally aspirated V8	RCM - Restraints control module	●	●	●	●
XK	2010-2015	Normally aspirated V8	RDCM - Rear differential control module	●	●	●	●
XK	2010-2015	Normally aspirated V8	RSJB - Auxiliary junction box (body control module B)	●	●	●	●
XK	2010-2015	Normally aspirated V8	SRM - Satellite audio unit module.	●	●	●	●
XK	2010-2015	Normally aspirated V8	TCM - Transmission control module	●	●	●	●
XK	2010-2015	Normally aspirated V8	TEL - Cellular telephone control module	●	●	●	●
XK	2010-2015	Normally aspirated V8	TPM - Tire pressure monitor module	●	●	●	●
XK	2010-2015	Normally aspirated V8	VIM - Vehicle immobilizer control module	●	●	●	●
XK	2010-2015	Supercharged V8	AAM - Audio amplifier module	●	●	●	●
XK	2010-2015	Supercharged V8	ABS - ABS control module	●	●	●	●
XK	2010-2015	Supercharged V8	ACM - Audio front control module	●	●	●	●
XK	2010-2015	Supercharged V8	ADCM - Adaptive damping control module	●	●	●	●
XK	2010-2015	Supercharged V8	APIM - Accessory protocol interface module	●	●	●	●
XK	2010-2015	Supercharged V8	CCM - Speed control module	●	●	●	●
XK	2010-2015	Supercharged V8	DABM - Digital audio broadcast module	●	●	●	●
XK	2010-2015	Supercharged V8	DACMC - Digital audio control module C	●	●	●	●
XK	2010-2015	Supercharged V8	DCSM - Driver's climate seat module	●	●	●	●
XK	2010-2015	Supercharged V8	DDM - Driver's door module	●	●	●	●
XK	2010-2015	Supercharged V8	DSM - Driver's seat module	●	●	●	●
XK	2010-2015	Supercharged V8	front)	●	●	●	●
XK	2010-2015	Supercharged V8	FLR - Forward looking radar	●	○	●	○
XK	2010-2015	Supercharged V8	FSJB - Central junction box (body control module)	●	●	●	●
XK	2010-2015	Supercharged V8	FTCM - Folding top control module	●	●	●	●
XK	2010-2015	Supercharged V8	GSM - Gear shift module	●	●	●	●
XK	2010-2015	Supercharged V8	HCM - Headlamp control module	●	●	●	●
XK	2010-2015	Supercharged V8	HVAC - Heating ventilation and air conditioning control module	●	●	●	●
XK	2010-2015	Supercharged V8	ICM - Infotainment control module.	●	●	●	●
XK	2010-2015	Supercharged V8	ICP - Integrated control panel	●	●	●	○
XK	2010-2015	Supercharged V8	ICS - Impact classification system	●	●	●	●
XK	2010-2015	Supercharged V8	IPC - Instrument cluster control module.	●	●	●	●
XK	2010-2015	Supercharged V8	KVM - Keyless vehicle module	●	●	●	●
XK	2010-2015	Supercharged V8	NCM - Navigation control module	●	●	●	●
XK	2010-2015	Supercharged V8	OCS - Restraints occupant classification system module	●	●	●	●
XK	2010-2015	Supercharged V8	PAM - Parking assist control module	●	●	●	●
XK	2010-2015	Supercharged V8	PBM - Parking brake control module	●	●	●	●
XK	2010-2015	Supercharged V8	PCM - Powertrain control module	●	●	●	●
XK	2010-2015	Supercharged V8	PDM - Passenger's door module	●	●	●	●
XK	2010-2015	Supercharged V8	PSM - Passenger's seat module	●	●	●	●
XK	2010-2015	Supercharged V8	RCM - Restraints control module	●	●	●	●
XK	2010-2015	Supercharged V8	RDCM - Rear differential control module	●	●	●	●
XK	2010-2015	Supercharged V8	RSJB - Auxiliary junction box (body control module B)	●	●	●	●
XK	2010-2015	Supercharged V8	SRM - Satellite audio unit module.	●	●	●	●
XK	2010-2015	Supercharged V8	TCM - Transmission control module	●	●	●	●
XK	2010-2015	Supercharged V8	TEL - Cellular telephone control module	●	●	●	●
XK	2010-2015	Supercharged V8	TPM - Tire pressure monitor module	●	●	●	●
XK	2010-2015	Supercharged V8	VIM - Vehicle immobilizer control module	●	●	●	●

Vevhicle mode	Year	Engine Type/Chassis Number	System Name
Other Vehicle	NULL	A30645 - A99999	0041, 0042
Other Vehicle	NULL	N00001 - N13088	0041
Other Vehicle	NULL	M44998 - M99999	0041
XK	2006-2009	Normally aspirated V8 3. 5L eng	0042, 0058, 004D, 0051, 0052, 0055
XK	2006-2009	Normally aspirated V8 4. 2L eng	0042, 0058, 004D, 0051, 0052, 0055
XK	2006-2009	Supercharged V8	0042, 0058, 004D, 0051, 0052, 0055
XK	2010-2015	Normally aspirated V8	0041, 0042, 0058, 0048, 004E, 0051, 0052, 0055
XK	2010-2015	Supercharged V8	0041, 0042, 0058, 0048, 004E, 0051, 0052, 0055
F-Type	2014-2015	Supercharged V8. 5. 0L engine	0041, 0042, 0058, 0048, 004C, 004D, 004E, 0051, 0052
F-Type	2014-2015	Supercharged V6 3. 0L engine	0041, 0042, 0058, 0048, 004C, 004D, 004E, 0051, 0052
F-Type	2016 -	Supercharged V8. 5. 0L engine	0041
F-Type	2016 -	Supercharged V6 3. 0L engine	0041
S-Type	2004-2005	AJ61 2. 5L engine	0041, 0042
S-Type	2004-2005	AJ61 3. 0L engine	0041, 0042
S-Type	2004-2005	AJ61 4. 2L engine	0041, 0042
S-Type	2004-2005	Diesel V6	0041, 0042
S-Type	2006-2008	Normally aspirated V6 3. 0L eng	0041, 0042, 0058, 004D
S-Type	2006-2008	Normally aspirated V6 2. 5L eng	0041, 0042, 0058, 004D
S-Type	2006-2008	Normally aspirated V8	0041, 0042, 0058, 004D
S-Type	2006-2008	Supercharged V8	0041, 0042, 0058, 004D
S-Type	2006-2008	Diesel V6	0041, 0042, 0058, 004D
Jaguar XF	2008-2009	Normally aspirated V8	0041, 0042, 0058, 0048, 004E, 0051, 0052, 0055
Jaguar XF	2008-2009	Supercharged V8	0041, 0042, 0058, 0048, 004E, 0051, 0052, 0055
Jaguar XF	2008-2009	Normally aspirated V6	0041, 0042, 0058, 0048, 004E, 0051, 0052, 0055
Jaguar XF	2008-2009	Diesel V6	0041, 0042, 0058, 0048, 004E, 0051, 0052, 0055
Jaguar XF	2010-2011	Normally aspirated V8 4. 2L eng	0041, 0042, 0058, 0048, 004C, 004E, 004F, 0051, 0052, 0055
Jaguar XF	2010-2011	Normally aspirated V8 5. 0L eng	0041, 0042, 0058, 0048, 004C, 004E, 004F, 0051, 0052, 0055
Jaguar XF	2010-2011	Supercharged V8. 5. 0L engin	0041, 0042, 0058, 0048, 004C, 004E, 004F, 0051, 0052, 0055
Jaguar XF	2010-2011	Normally aspirated V6	0041, 0042, 0058, 0048, 004C, 004E, 004F, 0051, 0052, 0055
Jaguar XF	2010-2011	Diesel V6	0041, 0042, 0058, 0048, 004C, 004E, 004F, 0051, 0052, 0055
Jaguar XF	2012	Normally aspirated V8 5. 0L eng	0041, 0042, 0058, 0048, 004C, 004D, 004E, 0051, 0052, 0055, 0056
Jaguar XF	2012	Supercharged V8. 5. 0L engine	0041, 0042, 0058, 0048, 004C, 004D, 004E, 0051, 0052, 0055, 0056
Jaguar XF	2012	Normally aspirated V6	0041, 0042, 0058, 0048, 004C, 004D, 004E, 0051, 0052, 0055, 0056
Jaguar XF	2012	Diesel V6	0041, 0042, 0058, 0048, 004C, 004D, 004E, 0051, 0052, 0055, 0056
Jaguar XF	2012	Diesel I4 2. 2L engine	0041, 0042, 0058, 0048, 004C, 004D, 004E, 0051, 0052, 0055, 0056
Jaguar XF	2013-2015	Supercharged V8. 5. 0L engine	0041, 0042, 0058, 0048, 004C, 004D, 004E, 004F, 0051, 0052, 0055
Jaguar XF	2013-2015	Supercharged V6	0041, 0042, 0058, 0048, 004C, 004D, 004E, 004F, 0051, 0052, 0055
Jaguar XF	2013-2015	Diesel V6	0041, 0042, 0058, 0048, 004C, 004D, 004E, 004F, 0051, 0052, 0055
Jaguar XF	2013-2015	Diesel I4 2. 2L engine	0041, 0042, 0058, 0048, 004C, 004D, 004E, 004F, 0051, 0052, 0055
Jaguar XF	2013-2015	GTDI 2. 0L engine	0041, 0042, 0058, 0048, 004C, 004D, 004E, 004F, 0051, 0052, 0055
Jaguar XF	2016 -	Supercharged V6 3. 0L engine	0041
Jaguar XF	2016 -	GTDI 2. 0L engine	0041
Jaguar XF	2016 -	Diesel I4 2. 0L engine	0041



Vevhicle model	Year	Engine Type/Chassis Number	System Name	Information	Read TroubleCode	Clear TroubleCode	Read DataStream
Jaguar XF	2016 -	Diesel V6		0041			
XJ RANGE	2002-2005	Normally aspirated V6		0041,0042			
XJ RANGE	2002-2005	Normally aspirated V8 3.5L eng		0041,0042			
XJ RANGE	2002-2005	Normally aspirated V8 4.2L eng		0041,0042			
XJ RANGE	2002-2005	Supercharged V8		0041,0042			
XJ RANGE	2006-2007	Normally aspirated V6		0041,0042,0058			
XJ RANGE	2006-2007	Normally aspirated V8 3.5L eng		0041,0042,0058			
XJ RANGE	2006-2007	Normally aspirated V8 4.2L eng		0041,0042,0058			
XJ RANGE	2006-2007	Supercharged V8		0041,0042,0058			
XJ RANGE	2006-2007	Diesel V6		0041,0042,0058			
XJ RANGE	2008-2009	Normally aspirated V6		0041,0042,0058,004D			
XJ RANGE	2008-2009	Normally aspirated V8 3.5L eng		0041,0042,0058,004D			
XJ RANGE	2008-2009	Normally aspirated V8 4.2L eng		0041,0042,0058,004D			
XJ RANGE	2008-2009	Supercharged V8		0041,0042,0058,004D			
XJ RANGE	2008-2009	Diesel V6		0041,0042,0058,004D			
XJ RANGE	2010-2012	Normally aspirated V6 3.0L eng		0041,0042,0058,0048,004C,004D,004E,004F,0051,0052,0055			
XJ RANGE	2010-2012	Normally aspirated V8 5.0L eng		0041,0042,0058,0048,004C,004D,004E,004F,0051,0052,0055			
XJ RANGE	2010-2012	Supercharged V8. 5.0L engine		0041,0042,0058,0048,004C,004D,004E,004F,0051,0052,0055			
XJ RANGE	2010-2012	Diesel V6		0041,0042,0058,0048,004C,004D,004E,004F,0051,0052,0055			
XJ RANGE	2013-2015	Normally aspirated V8 5.0L eng		0041,0042,0058,0048,004C,004D,004E,004F,0051,0052,0055			
XJ RANGE	2013-2015	Supercharged V8. 5.0L engine		0041,0042,0058,0048,004C,004D,004E,004F,0051,0052,0055			
XJ RANGE	2013-2015	Diesel V6		0041,0042,0058,0048,004C,004D,004E,004F,0051,0052,0055			
XJ RANGE	2013-2015	GTDI 2.0L engine		0041,0042,0058,0048,004C,004D,004E,004F,0051,0052,0055			
XJ RANGE	2013-2015	Supercharged V6		0041,0042,0058,0048,004C,004D,004E,004F,0051,0052,0055			
XJ RANGE	2016 -	Supercharged V8. 5.0L engine		0041			
XJ RANGE	2016 -	Diesel V6		0041			
XJ RANGE	2016 -	GTDI 2.0L engine		0041			
XJ RANGE	2016 -	Supercharged V6		0041			
X-Type	2001-2003	AJ61 3.0L engine		0041			
X-Type	2001-2003	AJ61 2.5L engine		0041			
X-Type	2001-2003	AJ61 2.0L engine		0041			
X-Type	2004-	AJ61 2.0L engine		0041,0058,004C,004D			
X-Type	2004-	AJ61 2.5L engine		0041,0058,004C,004D			
X-Type	2004-	AJ61 3.0L engine		0041,0058,004C,004D			
X-Type	2004-	TDCi 2.0L engine		0041,0058,004C,004D			
X-Type	2004-	TDCi 2.2L engine		0041,0058,004C,004D			
XE	2016 -	Supercharged V6 3.0L engine		0041			
XE	2016 -	GTDI 2.0L engine		0041			
XE	2016 -	Diesel I4 2.0L engine		0041			

### Special functions code instructions

0041	Oil Reset
0042	Electric Parking Brake
0058	TPMS
0048	Battery
004C	Injector
004D	Steering
004E	Suspension
004F	Throttle
0051	Window, door and roof
0052	Seats
0055	Headlamp
0056	Change tire size