

### NOTES:

●: This function is supported  
○: This function is not supported

▲: This function is the new feature in this version  
※: This function may be supported which depends on the actual condition of the vehicle

Model	systematic name	Subsystem name	Read version information	Read TroubleCode	Clear TroubleCode	DataStream	Action
Musso	ECM	ECM(2.3 MSE/RATIO)	●	●	●	●	●
Musso	ECM	ECM(3.2 MSE/RATIO)	●	●	●	●	●
Musso	TCM	TCM(BTRA 4)	●	●	●	●	○
Musso	TCM	TCM(BTR BOSCH)	●	●	●	●	○
Musso	ABS	ABS (ABS 5.0)	○	●	●	●	●
Musso	ABS	ABS (ABS-ABD 5.0)	○	●	●	●	●
Musso	ABS	ABS (ABS-EBD 5.3)	○	●	●	●	●
Musso	ABS	ABS (ABD-EBD 5.3)	○	●	●	●	●
Musso	ABS	ABS (ABS 5.3(running change))	○	●	●	●	●
Musso	ECS	ECS	●	●	●	●	●
Musso	Airbag	Airbag	○	●	●	○	○
Musso	TOD	TOD	○	●	●	○	○
Musso	TCCU (P/T)	TCCU (P/T)	●	○	○	○	○
Musso	Huber EGR	Huber EGR	●	●	●	○	○
Korando	ECM	ECM(2.3 MSE/RATIO)	●	●	●	●	●
Korando	ECM	ECM(3.2 MSE/RATIO)	●	●	●	●	●
Korando	TCM	TCM(BTRA 4)	●	●	●	●	○
Korando	TCM	TCM(BTR BOSCH)	●	●	●	●	○
Korando	ABS	ABS (ABS 5.0)	○	●	●	●	●
Korando	ABS	ABS (ABS-ABD 5.0)	○	●	●	●	●
Korando	ABS	ABS (ABS-EBD 5.3)	○	●	●	●	●
Korando	ABS	ABS (ABD-EBD 5.3)	○	●	●	●	●
Korando	ABS	ABS (ABS 5.3(running change))	○	●	●	●	●
Korando	ECS	ECS	●	●	●	●	●
Korando	Airbag	Airbag	○	●	●	○	○
Korando	TOD	TOD	○	●	●	○	○
Korando	TCCU (P/T)	TCCU (P/T)	●	○	○	○	○
Korando	Huber EGR	Huber EGR	●	●	●	○	○
Istana	ECM	ECM(2.3 MSE/RATIO)	●	●	●	●	●
Istana	ABS	ABS (ABS 5.0 free running)	○	●	●	●	●
Istana	ABS	ABS (ABS (TEVES))	●	●	●	●	●
Chairman	ECM	ECM(3.6 BOSCH)	●	●	●	●	●
Chairman	ECM	ECM(3.2 DOHC BOSCH)	○	●	●	●	○
Chairman	ECM	ECM(2.3 MSE/RATIO)	●	●	●	●	●
Chairman	ECM	ECM(2.8 MSE/RATIO)	●	●	●	●	●
Chairman	ECM	ECM(3.2 MSE/RATIO)	●	●	●	●	●
Chairman	TCM	TCM(BTRA 4)	●	●	●	●	●
Chairman	TCM	TCM(NAG 5 A/T)	○	●	●	○	○
Chairman	TCM	TCM(DC 5 A/T)	●	●	●	●	○
Chairman	ABS	ABS (ABS 5.3(running change))	○	●	●	●	●
Chairman	ABS	ABS (ABD 5.3)	○	●	●	●	●
Chairman	ABS	ABS (ASR 5.3)	○	●	●	●	●
Chairman	ABS	ABS (TEVES (ABS/ESP))	●	●	●	●	●
Chairman	ABS	ABS (TEVES (ABS))	●	●	●	●	●
Chairman	ECS	ECS (VDO)	●	●	●	●	●
Chairman	ECS	ECS (SACHS)	●	●	●	●	●
Chairman	Airbag	Airbag (BOSCH)	○	●	●	○	○
Chairman	Airbag	Airbag (BOSCH)	○	●	●	○	○
Chairman	Airbag	Airbag (SRE-NCS)	○	●	●	○	○
Chairman	Power trunk	Power trunk	●	●	●	●	●
Chairman	TPMS	TPMS	●	●	●	●	●
Chairman	Dual rekes	Dual rekes	●	●	●	●	●
Chairman	Immobilizer	Immobilizer (Gasoline)	○	○	○	○	○
Chairman	Immobilizer	Immobilizer (Diesel)	○	○	○	○	○
Rexton	ECM	ECM(2.3 MSE)	●	●	●	●	●
Rexton	ECM	ECM(2.8 MSE)	●	●	●	●	●
Rexton	ECM	ECM(3.2 MSE)	●	●	●	●	●
Rexton	ECM	ECM(DSL 2.7 (C2I))	●	●	●	●	●
Rexton	ECM	ECM(DSL 2.7 (C3I))	●	●	●	●	●
Rexton	TCM	TCM(BTRA 4)	●	●	●	●	○
Rexton	TCM	TCM(DC 5 A/T)	●	●	●	●	○
Rexton	ABS	ABS (TEVES (ABS/ESP))	●	●	●	●	●
Rexton	ABS	ABS (Bosch)	●	●	●	●	●
Rexton	Airbag	Airbag (SRE-NCS)	○	●	●	○	○
Rexton	Airbag	Airbag (SRE-smart)	●	●	●	○	○
Rexton	TOD	TOD (OLD)	○	●	●	○	○
Rexton	TOD	TOD (NEW)	○	●	●	●	○
Rexton	TCCU	TCCU (OLD)	●	○	○	○	○
Rexton	TCCU	TCCU (NEW)	●	●	●	●	○
Rexton	Huber EGR	Huber EGR (A11)	●	●	●	○	○
Rexton	SSPS	SSPS (A11)	●	●	●	●	○
Rexton	TPMS	TPMS (A11)	●	●	●	●	●
Rexton	TGS lever	TGS lever (A11)	●	●	●	○	○
Rexton	Immobilizer	Immobilizer (Gasoline)	○	○	○	○	○
Rexton	Immobilizer	Immobilizer (Diesel)	○	○	○	○	○
Rodius/Stavic	ECM	ECM(DSL D27DT (C2I))	●	●	●	●	●
Rodius/Stavic	ECM	ECM(DSL D27DT (C2I))	●	●	●	●	●
Rodius/Stavic	ECM	ECM(DSL D27DT (C3I))	●	●	●	●	●
Rodius/Stavic	ECM	ECM(DSL D27DT (C3I))	●	●	●	●	●
Rodius/Stavic	ECM	ECM(3.2 MSE/RATIO)	●	●	●	●	●
Rodius/Stavic	TCM	TCM(DC 5 A/T)	●	●	●	●	○
Rodius/Stavic	ABS	ABS (TEVES (ABS/ESP))	●	●	●	●	●

Model	systematic name	Subsystem name	Read version information	Read TroubleCode	Clear TroubleCode	DataStream	Action
Rodius/Stavic	Airbag	Airbag(SRE-smart)	●	●	●	○	○
Rodius/Stavic	TOD	TOD(NEW)	○	●	●	●	○
Rodius/Stavic	TCCU	TCCU(NEW)	●	●	●	●	○
Rodius/Stavic	TGS lever	TGS lever(A11)	●	●	●	○	○
Rodius/Stavic	Immobilizer	Immobilizer(Gasoline)	○	○	○	○	○
Rodius/Stavic	Immobilizer	Immobilizer(Diesel)	○	○	○	○	○
Kyron	ECM	ECM(2.3 MSE)	●	●	●	●	●
Kyron	ECM	ECM(3.2 MSE)	●	●	●	●	●
Kyron	ECM	ECM(DSL 2.0(C2I))	●	●	●	●	●
Kyron	ECM	ECM(DSL 2.0(C3I))	●	●	●	●	●
Kyron	ECM	ECM(DSL 2.7(C2I))	●	●	●	●	●
Kyron	ECM	ECM(DSL 2.7(C3I))	●	●	●	●	●
Kyron	TCM	TCM(BTRA 4)	●	●	●	●	○
Kyron	TCM	TCM(DC 5 A/T)	●	●	●	●	○
Kyron	ABS	ABS(TEVES(ABS/ESP))	●	●	●	●	●
Kyron	Airbag	Airbag(SRE-smart)	●	●	●	○	○
Kyron	TCCU	TCCU	●	●	●	●	○
Kyron	SSPS	SSPS	●	●	●	●	○
Kyron	TGS lever	TGS lever	●	●	●	○	○
Kyron	Immobilizer	Immobilizer(Gasoline)	○	○	○	○	○
Kyron	Immobilizer	Immobilizer(Diesel)	○	○	○	○	○
Actyon	ECM	ECM(2.3 MSE)	●	●	●	●	●
Actyon	ECM	ECM(DSL 2.0(C2I))	●	●	●	●	●
Actyon	ECM	ECM(DSL 2.0(C3I))	●	●	●	●	●
Actyon	TCM	TCM(BTRA 4)	●	●	●	●	○
Actyon	TCM	TCM(DC 5 A/T)	●	●	●	●	○
Actyon	ABS	ABS(TEVES(ABS/ESP))	●	●	●	●	●
Actyon	Airbag	Airbag(SRE-smart)	●	●	●	○	○
Actyon	TCCU	TCCU	●	●	●	●	○
Actyon	SSPS	SSPS	●	●	●	●	○
Actyon	Immobilizer	Immobilizer(Gasoline)	○	○	○	○	○
Actyon	Immobilizer	Immobilizer(Diesel)	○	○	○	○	○
Korando c	ECM	ECM	●	●	●	●	●
Korando c	TCM	TCM	○	●	●	●	○
Korando c	ABS/ESP	ABS/ESP	●	●	●	●	●
Korando c	E-coupling	E-coupling	●	●	●	●	○
Korando c	EPS	EPS	●	●	●	●	○
Korando c	BCM	BCM	●	●	●	○	●
Korando c	SKM	SKM	●	●	●	○	○
Korando c	Airbag	Airbag	●	●	●	○	○