

NOTES:

- : This function is supported ▲: This function is the new feature in this version
- : This function is not supported ※: This function may be supported which depends on the actual condition of the vehicle

Systems Name	Information	Read TroubleCode	Clear TroubleCode	DataStream	Active
ENGINE	●	●	●	●	●
ABS	●	●	●	●	●
METER/M&A	●	●	●	●	●
BCM	●	●	●	●	●
AIR BAG	●	●	●	●	●
ICC/ADAS	●	●	●	●	●
HVAC	●	●	●	●	●
TRANSMISSION	●	●	●	●	●
MULTI AV	●	●	●	●	●
EHS/PKB	●	●	●	●	●
MOTOR CONTROL	●	●	●	●	○
EPS/DAST 3	●	●	●	●	○
IPDM E/R	●	●	●	●	●
AIR PRESSURE MONITOR	●	●	●	●	●
BAC	●	●	●	●	○
SUB METER	○	●	●	●	○
CONVERTIBLE ROOF	●	●	●	●	●
E-4WD	●	●	●	●	●
LASER/RADAR	●	●	●	●	●
INTELLIGENT KEY	●	●	●	●	●
DIU	○	●	●	●	○
AUTO SLIDE DOOR	●	●	●	●	●
PRECRASH SEATBELT	●	●	●	●	○
AUTO DRIVE POSITION	●	●	●	●	●
ALL MODE AWD/4WD	●	●	●	●	●
DIFFERENCE LOCK	●	●	●	●	○
4WAS(MAIN)/RAS/HICAS	●	●	●	●	●
SONAR	●	●	●	●	●
LANE CAMERA	●	●	●	●	●
ADAPTIVE LIGHT	●	●	●	●	●
AUTO SLIDE DOOR RIGHT	●	●	●	●	●
CAN GATEWAY	●	●	●	●	○
SHIFT	●	●	●	●	○
EV/HEV	●	●	●	●	●
POP UP HOOD	●	●	●	●	○
AUTO BACK DOOR	●	●	●	●	○
DIAG DATA RECORDER	○	○	○	○	○
4WAS(FRONT)	●	●	●	●	●
E-SUS	●	●	●	●	●
ACCELE PEDAL ACT	●	●	●	●	●
HV BATTERY	●	●	●	●	●
BRAKE	●	●	●	●	●
SIDE RADAR LEFT	●	●	●	●	●
VSP	●	●	●	●	●
ANC	●	●	●	●	●
MULTI DISPLAY	○	●	●	●	●
SIDE RADAR RIGHT	●	●	●	●	●
ADCM	●	●	●	●	●
PTC HEATER	●	●	●	●	○
CHARGER/PD MODULE	●	●	●	●	●
TELEMATICS	●	●	●	●	○
HAS	●	●	●	●	●
EMCM	●	●	●	●	●
BSW/BUZZER	●	●	●	●	●
AVM	●	●	●	●	●
CHASSIS CONTROL	●	●	●	●	●
DAST 1	●	●	●	●	○
DAST 2	●	●	●	●	○
CIU	●	●	●	●	●
MM CONN	●	●	●	●	○
CLUSTER	●	●	●	●	●
CHA	●	●	●	●	●
FSCM	●	●	●	●	●
PMAS	●	●	●	●	○
RADIO	●	●	●	●	●
DOOR MODULE FRONT LEFT	●	●	●	●	●
DOOR MODULE FRONT RIGHT	●	●	●	●	●
VEHICLE THEFT ALARM SENSOR MODULE	●	●	●	●	●
INTRUSION SIREN	●	○	○	●	○
SEAT CONTROL MODULE PASSENGER*	●	●	●	●	●
INTELLIGENT BATTERY SENSOR	●	○	○	○	○
UPPER ACCESSORY SWITCH BANK MODULE	●	○	○	○	○

Systems Name	Information	Read TroubleCode	Clear TroubleCode	DataStream	Active
EC MIRROR COMPASS*	●	○	○	○	○
UNIVERSAL GARAGE DOOR OPENER*	●	○	○	●	○
LIGHT/RAIN SENSOR MODULE*	●	○	○	●	○
OVERHEAD CONTROL MODULE	●	○	○	●	○
ELECTRONIC IGNITION SWITCH (WITH CENTRAL GATEWAY)	●	●	●	●	○
TRAILER MODULE*	●	●	●	●	○
OCCUPANT CLASSIFICATION MODULE4	●	○	○	●	○
STANDALONE DISTRONIC SENSOR*	●	●	●	●	○
PARKING ASSIST	●	●	●	●	○
SCCM	●	●	●	●	○
STEERING WHEEL SWITCH PAD	●	○	○	●	○
FORWARD COLLISION WARNING**	●	●	●	●	○
LED CONTROL UNIT FRONT RIGHT	●	○	○	●	○
LED CONTROL UNIT FRONT LEFT	●	○	○	●	○
BLIND SPOT MONITORING - MASTER**	●	●	●	●	○
BLIND SPOT MONITORING - SLAVE**	●	●	●	●	○
MULTI PURPOSE CAMERA	●	●	●	●	○
CPC(CENTRAL POWERTRAIN CONTROLLER)	●	●	●	●	●
HEAD LAMP INTERFACE RIGHT	●	●	●	●	●
HEAD LAMP INTERFACE LEFT	●	●	●	●	●
HANDS FREE MODULE	●	●	●	●	○