

## TabScan - ZOTYE - V2.25 Diagnostic Coverage

This function is supportedThis function is not supported

▲: This function is the new feature in this version

\*: This function may be supported which depends on the actual condition of the vehicle

Vehicle Model	System Name	Information	Read TroubleCode	Clear TroubleCode	Read DataStream	ActiveTest
SR9	1.8T Engine Management System(EMS)	•	•	•	•	•
SR9	1.5T Engine Management System(EMS)	•	•	•	•	•
SR9	2. OT engine system (EMS)	•	•	•	•	•
SR9	AT System(AT)	•	•	•	•	0
SR9 SR9	Transmission system 8AT(TCU)  ABS/Electronic Stability Control System(TRW)				•	•
SR9	SRS System(SRS)	•	•	•	0	
SR9	Instrument Panel System(ICU)	•	•	•	0	•
SR9	Tire Pressure Monitoring System(TPMS)	•	•	•	•	0
SR9	Electronic Power Steering System(EPS)	•	•	•	•	0
SR9	Passive Entry Passive Start (PEPS)	•	•	•	•	•
SR9	Automatic Air-conditioning System	•	•	•	•	0
SR9 SR9	Communication System(TBOX) FBCM	•	•	•	•	<u> </u>
SR9	RBCM				•	•
SR9	Gateway System(GW)	•	•	•	0	0
SR9	Headlamp regulation system(ALS)	0	•	•	0	0
SR9	Instrument panel switch group system(CCP)	•	•	•	•	0
SR7 (2017)	Engine	•	•	•	•	•
SR7 (2017)	AT System(AT)	•	•	•	•	0
SR7 (2017)	Antilock Brake System(ABS)	•	•	•	•	0
SR7 (2017) SR7 (2017)	SRS System(SRS)	•	•	•	0	•
SR7 (2017) SR7 (2017)	Instrument Panel System(ICU) Tire Pressure Monitoring System(TPMS)				•	0
SR7 (2017)	VECU System (BCM)	•	•	•	•	•
SR7 (2017)	Around View Monitor (AVM)	•	•	•	•	0
SR7 (2017)	Electronic Power Steering System(EPS)	0	•	•	0	0
SR7 (2017)	Passive Entry Passive Start(PEPS)	•	•	•	•	•
SR7 (2017)	Automatic Air-conditioning System	•	•	•	•	0
SR7 (2017)	Communication System(TBOX)	•	•	•	•	0
SR7 (2017) SR7	Body assist control system(ABCM) Engine	•	•	•	•	•
SR7	AT System(AT)				•	0
SR7	Antilock Brake System(ABS)	•	•	•	•	0
SR7	SRS System(SRS)	•	•	•	•	•
SR7	Instrument Panel System(ICU)	•	•	•	0	•
SR7	VECU System(BCM)	•	•	•	•	•
SR7	Around View Monitor (AVM)	•	•	•	•	0
SR7	Electronic Power Steering System(EPS)	0	•	•	0	0
SR7 SR7	Passive Entry Passive Start(PEPS) Automatic Air-conditioning System		•	•	•	•
SR7	Communication System (TBOX)	•			•	0
SR7	Tire Pressure Monitoring System(TPMS)	•	•	•	•	0
Zema E30	Battery Management System(BMS)	•	•	•	•	0
Zema E30	Motor Control Unit(MCU)	•	•	•	•	0
Zema E30	ABS/Electronic Stability Control System(TRW)	•	•	•	•	0
Zema E30	SRS System(SRS)	•	•	•	•	•
Zema E30	Instrument Panel System(ICU)	•	•	•	0	•
Zema E30 Zema E30	VECU System(BCM)  Vehicle Control Unit(VCU)			•	0	0
Zema E30 Zema E30	Electronic Power Steering System(EPS)				•	0
Zema E30	Automatic Air-conditioning System	•	•	•	•	0
Zema E30	Communication System(TBOX)	•	•	•	•	0
E200	Battery Management System(BMS)	•	•	•	•	0
E200	Vehicle Control Unit(VCU)	•	•	•	•	0
E200	Motor Control Unit (MCU)	•	•	•	•	0
E200	ABS/Electronic Stability Control System(TRW)	•	•	•	0	0
E200 E200	Instrument Panel System(ICU) Electrical Parking Brake(EPB)	0			0	0
E200	SAC Electrical Parking Brake (EPB)	•	•	•	•	0
E200	VECU System (BCM)	•	•	•	•	•
E200	Electronic Power Steering System(EPS)	•	•	•	•	0
E200	Passive Entry Passive Start(PEPS)	•	•	•	•	•
E200	Electronic Stability Program(ESP)	•	•	•	•	0
E200	Communication System(TBOX)	•	•	•	0	0
T300	1.5L Engine Management System(EMS)	•	•	•	•	•
T300 T300	1.5T Engine Management System(EMS) 1.5L Transmission Control Unit(TCU)			•	•	0
T300	1.5L Transmission Control Unit(TCU)  1.5T Transmission Control Unit(Tenhle engine) (TCU)	•	•			0
T300	1.5T Transmission Control Unit (Tennile engine) (TCU)	•	•	•	•	0
T300	ABS/Electronic Stability Control System(TRW)	•	•	•	•	<u>_</u>
T300	SRS System(SRS)	•	•	•	0	•
T300	Instrument Panel System(ICU)	•	•	•	0	•
T300	Tire Pressure Monitoring System(TPMS)	•	•	•	•	0
T300	VECU System (BCM)	•	•	•	•	•
T300	ATECH BCM System (BCM)	•	•	•	•	
T300 T300	Around View Monitor(AVM)  Electronic Power Steering System(EPS)	0	•	•	0	0
T300	Passive Entry Passive Start(PEPS)	•	•	•	•	•
1000	rassive entry rassive start(FEFS)					

Vehicle Model	System Name	Information	Read	Clear	Read	ActiveTest
Т300	·		TroubleCode	TroubleCode	DataStream	
T300	Automatic Air-conditioning System Communication System(TBOX)	•		•	•	0
T700	1.8T Engine Management System(EMS)	•	•	•	•	•
T700	2.0T engine system(EMS)	•	•	•	•	•
T700	AT System(AT)	•	•	•	•	0
T700 T700	Transmission system 8AT(TCU) Electronic Stability Control(ESC)(Bosch)	•	•	•	•	•
T700	Electronic Stability Control (ESC) (Continent)	•		•	•	•
T700	SRS System(SRS)	•	•	•	•	•
T700	Instrument Panel System(ICU)	•	•	•	0	•
T700	Tire Pressure Monitoring System(TPMS)	•	•	•	•	0
T700 T700	Body assist control system(ABCM)  VECU System(BCM)	•		•	•	•
T700	Headlamp regulation system(ALS)	0		•	0	0
T700	Automatic Air-conditioning System	•	•	•	•	0
T700	Gateway System(GW)	•	•	•	0	0
T700	Electronic Power Steering System(EPS)	•	•	•	0	0
T700 T700	Communication System(TBOX)  Around View Monitor(AVM)				•	0
T700	DCM system (DCM)		•	•	•	•
T700	Adaptive Cruise Control system(ACC)	•	•	•	•	•
T700	Transmission driving mechanism control unit(GBC)	•	•	•	•	0
T700	Automatic Parking Assistant (APA)	•	•	•	0	•
T700 T700	GSM system(GSM) Head-up Display(HUD)	-	0	0	0	0
T600 COUPE	1.8T Engine Management System(EMS)	<del>-</del>	•	•	•	•
T600_COUPE	2. OT engine system(EMS)	•	•	•	•	•
T600_COUPE	1.5T Engine System(EMS)	•	•	•	•	•
T600_COUPE	AT System(AT)	•	•	•	•	0
T600_COUPE T600_COUPE	Automatic transmission 6AT(TCU) Electronic Stability Program(ESP)	•		•	•	0
T600_COUPE	SRS System(SRS)	•	•	•	•	•
T600_COUPE	Instrument Panel System(ICU)	•	•	•	0	•
T600_COUPE	Tire Pressure Monitoring System(TPMS)	•	•	•	•	0
T600_COUPE	VECU System (BCM)	•	•	•	•	•
T600_COUPE T600_COUPE	Passive Entry Passive Start(PEPS) Headlamp regulation system(ALS)	0	-	•	0	0
T600_COUPE	Gateway System(GW)	•			0	0
T600_COUPE	Electronic Power Steering System(EPS)	•	•	•	•	0
T600_COUPE	Automatic Air-conditioning System	•	•	•	•	0
T600_COUPE	Around View Monitor (AVM)	•	•	•	•	0
T600_COUPE T600_COUPE	Communication System(TBOX)  Body assist control system(ABCM)	•	•	•	•	0
T600_COUPE	Head-up Display(HUD)		0	0	0	0
T600 Sport	2. OT engine system(EMS)	•	•	•	•	•
T600 Sport	1.5T Engine System(EMS)	•	•	•	•	•
T600 Sport	AT System(AT)	•	•	•	•	0
T600 Sport T600 Sport	Transmission system 8AT(TCU) Automatic transmission 6AT(TCU)	-		-	-	
T600 Sport	Antilock Brake System(ABS)		•	•	•	0
T600 Sport	Electronic Stability Program(ESP)	•	•	•	•	•
T600 Sport	SRS System(SRS)	•	•	•	•	•
T600 Sport	Instrument Panel System(ICU)	•	•	•	0	•
T600 Sport T600 Sport	VECU System(BCM) Immobilizer System(IMMO)				•	0
T600 Sport	Keyless start-up system(HUF)(PEPS)	0	•	•	•	•
T600 Sport	Keyless start-up system(NAEN)(PEPS)	•	•	•	•	•
T600 Sport	Tire Pressure Monitoring System(TPMS)	•	•	•	•	0
T600 Sport	Headlamp regulation system(ALS)	0	•	•	0	0
T600 Sport T600 Sport	Headlamp control system(sports version)  Automatic Air-conditioning System	<u> </u>			<u> </u>	0
T600 Sport	Gateway System (GW)	•	•	•	•	0
T600 Sport	Electronic Power Steering System(EPS)	0	•	•	0	0
T600 Sport	Four-wheel Transfer Gear System(AWD)	•	•	•	0	0
T600 Sport T600 Sport	Communication System(TBOX)  Body assist control system(ABCM)	•	•	•	•	<u> </u>
Z500EV	Battery Management System(ABCM)	•	•	•	•	0
Z500EV Z500EV	Vehicle Control Unit (VCU)		•	•	•	0
Z500EV	Motor Control Unit(MCU)	•	•	•	•	0
Z500EV	ABS/Electronic Stability Control System(TRW)	•	•	•	•	0
Z500EV Z500EV	Instrument Panel System(ICU) Tire Pressure Monitoring System(TPMS)	•	•	•	<u> </u>	0
Z500EV Z500EV	On-board charger(ACDC)		•	•	•	0
Z500EV	VECU System (BCM)	•	•	•	•	•
Z500EV	SRS System(SRS)	•	•	•	•	0
Z500EV	Around View Monitor (AVM)	•	•	•	•	0
Z500EV Z500EV	Electronic Power Steering System(EPS)  Passive Entry Passive Start(PEPS)	0	•	•	<u> </u>	<u> </u>
Z500EV Z500EV	Automatic Air-conditioning System		•	•	•	0
Z500EV Z500EV	Communication System(TBOX)				•	0
Z500EV	DC-DC converter(DCDC)	•	•	•	•	0
Z500	Engine	•	•	•	•	•
Z500	AT System(AT)	•	•	•	•	0
Z500 Z500	Antilock Brake System(ABS)  SRS System(SRS)				•	0
Z500	Instrument Panel System(ICU)	<del>-</del>	•	•	•	•
Z500	VECU System(BCM)	•	•	•	•	•
Z500	Passive Entry Passive Start (PEPS)	•	•	•	•	•

Vehicle Model	System Name	Information	Read	Clear	Read	ActiveTest
Z500	Electronic Power Steering System(EPS)	0	TroubleCode	TroubleCode	DataStream  O	0
Z500	Around View Monitor(AVM)	•	•	•	•	0
Z500	Tire Pressure Monitoring System(TPMS)	•	•	•	•	0
Z500 Domy X7	Communication System(TBOX) 1.8T Engine Management System(EMS)	•	•	•	•	0
Domy X7	2. OT Engine Management System(EMS)	•	•	•	•	•
Domy X7	UAES 1.5T engine	•	•	•	•	•
Domy X7	AT System(AT)	•	•	•	•	0
Domy X7 Domy X7	Transmission system 8AT(TCU)  ABS/Electronic Stability Control System(TRW)	•	•	•	•	•
Domy X7	SRS System(SRS)	•	•	•	0	•
Domy X7	Instrument Panel System(ICU)	•	•	•	0	•
Domy X7	Tire Pressure Monitoring System(TPMS)	•	•	•	•	0
Domy X7 Domy X7	VECU System (BCM)	•	•	•	•	•
Domy X7 Domy X7	Passive Entry Passive Start(PEPS) Gateway System(GW)	<del> </del>	•	•	0	0
Domy X7	Electronic Power Steering System(EPS)	•	•	•	0	0
Domy X7	Automatic Air-conditioning System	•	•	•	•	0
Domy X7 Domy X7	Communication System(TBOX) FBCM	•	•	•	•	<u> </u>
Domy X7 Domy X7	RBCM	•	•	•	•	•
Domy X7	Around View Monitor (AVM)	•	•	•	•	0
Domy X7	Transmission driving mechanism control unit(GBC)	•	•	•	•	0
Domy X5	Engine	•	•	•	•	•
Domy X5 Domy X5	AT System(AT) Antilock Brake System(ABS)	•	•	•	•	0
Domy X5 Domy X5	SRS System(SRS)	•	•	•	•	0
Domy X5	Instrument Panel System(ICU)	•	•	•	0	•
Domy X5	VECU System(BCM)	•	•	•	•	•
Domy X5	Passive Entry Passive Start (PEPS)	•	•	•	•	•
Domy X5 Domy X5	Electronic Power Steering System(EPS)  Communication System(TBOX)	0		•	O	0
Domy X5	Tire Pressure Monitoring System(TPMS)		•	•	•	0
Z700	UAES 1.5T engine system(EMS)	•	•	•	•	•
Z700	UAES 1.8T engine system(EMS)	•	•	•	•	•
Z700	AT System(AT)	•	•	•	•	0
Z700 Z700	Antilock Brake System(ABS)  SRS System(SRS)	<del>  •</del>	•	•	•	0
Z700	Instrument Panel System(ICU)	•	•	•	0	•
Z700	VECU System(BCM)	•	•	•	•	•
Z700	Around View Monitor (AVM)	•	•	•	•	0
Z700 Z700	Passive Entry Passive Start(PEPS)  Electronic Power Steering System(EPS)	•	•	•	•	0
Z700	Body assist control system(ABCM)	•	•	•	•	•
Z700	Automatic Air-conditioning System	•	•	•	•	0
Z700	Communication System(TBOX)	•	•	•	•	0
Z700 Z700	Headlamp regulation system(ALS)  DCM system(DCM)	0	•	•	O	<u> </u>
Z700 Z700	Tire Pressure Monitoring System(TPMS)	<del>-</del>	•	•	•	0
Z100	Engine system(Wuhan LinControl)(EMS)	•	•	•	•	•
Z100	Engine	•	•	•	•	•
Z100 Z100	Antilock Brake System(ABS)  SRS System(SRS)	•	•	•	•	0
Z100 Z100	Instrument Panel System(ICU)	<del>-</del>	•	•	•	0
Z100	Electronic Power Steering System(EPS)	0	•	•	0	0
Z100	Immobilizer System(IMMO)	•	•	•	•	0
T600	2. OT engine system (EMS)	•	•	•	•	•
T600 T600	1.5T Engine System(EMS) AT System(AT)	<del>-</del>			•	0
T600	Transmission system 8AT(TCU)	•	•	•		•
T600	Automatic transmission 6AT(TCU)	•	•	•	•	•
T600	Antilock Brake System(ABS)	•	•	•	•	0
T600 T600	SRS System(SRS)  Instrument Panel System(ICU)	•	•	•	0	•
T600	VECU System(BCM)		•	•	<u> </u>	•
T600	Electronic Stability Program(ESP)	•	•	•	•	•
T600	Immobilizer System(IMMO)	•	•	•	•	0
T600 T600	Keyless start-up system(HUF)(PEPS)  Keyless start-up system(NAEN)(PEPS)	<u> </u>				•
T600	Tire Pressure Monitoring System(TPMS)	•	•	•	•	0
T600	Headlamp regulation system(ALS)	0	•	•	0	0
T600	Headlamp control system(sports version)	0	•	•	0	0
T600 T600	Gateway System(GW)  Electronic Power Steering System(EPS)	0				0
T600	Four-wheel Transfer Gear System(AWD)				0	0
T600	Communication System(TBOX)	•	•	•	•	0
T600	Body assist control system(ABCM)	•	•	•	•	•
Z300 Z300	Engine AT System(AT)	•	•	•	•	
Z300 Z300	AT System(AT) Antilock Brake System(ABS)	•	•	•	•	•
Z300	Beijing West ABS(ABS)	•	•	•	•	0
Z300	SRS System(SRS)	•	•	•	•	0
Z300	Instrument Panel System(ICU)	•	•	•	•	•
Z300 Z300	VECU System(BCM) Immobilizer System(IMMO)	•	•	•	•	0
Z300 Z300	Lianchuang Anti-Theft System(IMMO)	•	•	•	•	•
Z300	Electronic Stability Program(ESP)	•	•	•	•	0
Z300	Tire Pressure Monitoring System(TPMS)		•	•	•	0

Vehicle Model	System Name	Information	Read TroubleCode	Clear TroubleCode	Read DataStream	ActiveTest
Z300	Passive Entry Passive Start (PEPS)	•	•	•	•	•
T200	Delphi EOBD	•	•	•	•	•
T200	Marelli engine(EMS)	•	•	•	•	•
T200	UAES EOBD	•	•	•	•	•
T200	UAES M797	•	•	•	•	•
T200	AT System(AT)	0	•	•	•	0
T200	Delphi Anti-brake System(ABS)	•	•	•	•	•
T200	SABS(VW)ABS System(ABS)	•	•	•	•	0
T200	BOSCH Supplementary Restraint System(SRS)	•	•	•	•	0
T200	Delphi SRS(SRS)	•	•	•	•	0
T200	Immobilizer System(IMMO)	•	•	•	•	•
Alto JNJ7082	Engine	0	•	•	•	0
V10	Engine	•	•	•	•	•
Mutiplan	Engine	0	•	•	•	•
2008	Delphi EOBD	•	•	•	•	•
2008	Marelli engine(EMS)	•	•	•	•	•
2008	UAES EOBD	•	•	•	•	•
2008	UAES M797	•	•	•	•	•
2008	Antilock Brake System(ABS)	•	•	•	•	0
2008	BOSCH Supplementary Restraint System(SRS)	•	•	•	•	0
2008	Delphi SRS(SRS)	•	•	•	•	0
5008	Delphi EOBD	•	•	•	•	•
5008	Marelli engine(EMS)	•	•	•	•	•
5008	UAES EOBD	•	•	•	•	•
5008	UAES M797	•	•	•	•	•
5008	AT System(AT)	0	•	•	•	0
5008	Delphi Anti-brake System(ABS)	•	•	•	•	•
5008	SABS(VW)ABS System(ABS)	•	•	•	•	0
5008	BOSCH Supplementary Restraint System(SRS)	•	•	•	•	0
5008	Delphi SRS(SRS)	•	•	•	•	0
5008	Immobilizer System(IMMO)	•	•	•	•	•
Langjun	Engine	•	•	•	•	•
Langjun	AT System(AT)	•	•	•	•	•
Langjun	Antilock Brake System(ABS)	•	•	•	•	•
Langjun	SRS System(SRS)	•	•	•	•	0
Langjun	Instrument Panel System(ICU)	•	•	•	•	0
Langjun	VECU System(BCM)	•	•	•	•	0
Langjun	Immobilizer System(IMMO)	•	•	•	•	0
Langlang	Engine	•	•	•	•	•
Langlang	AT System(AT)	•	•	•	•	•
Langlang	Antilock Brake System(ABS)	•	•	•	•	•
Langlang	SRS System(SRS)	•	•	•	•	0
Langyue	Engine electronic control system(EMS)	•	•	•	•	•
Langyue	Gasoline electronic control system(EMS)	•	•	•	•	•
Langyue	AT System(AT)	•	•	•	•	•
Langyue	Antilock Brake System(ABS)	•	•	•	•	•
Langyue	SRS System(SRS)	•	•	•	•	0
Langyue	Instrument Panel System(ICU)	•	•	•	•	0
Langyue	VECU System(BCM)	•	•	•	•	0
Langyue	Immobilizer System(IMMO)	•	•	•	•	0